

WSTER WS-1934

WSTER WS-1934 Retro Classic Car Bluetooth Speaker User Manual

Model: WS-1934

1. PRODUCT OVERVIEW

The WSTER WS-1934 is a retro-styled Bluetooth replica speaker designed to resemble a classic car. It offers wireless HD sound, FM radio, TWS stereo pairing, LED party lights, and a built-in microphone for hands-free calls. Its unique design makes it suitable for both audio playback and decorative purposes.




Image: The WSTER WS-1934 speaker, designed as a green and cream classic car.

2. WHAT'S IN THE BOX

- WS-1934 Retro Classic Car Bluetooth Speaker
- Power Cable (Type-C)
- Quick Start Guide

3. CONTROLS AND PORTS

Familiarize yourself with the control buttons and ports located on the rear of the speaker for optimal operation.

Revel in the festivities with music playing non-stop



Image: Rear view of the WS-1934 speaker, highlighting the control panel with buttons for mode, play/pause, track navigation, and ports for DC 5V (Type-C), TF card, USB, Mic, and AUX.

Button Functions:

- **M/Mode Button:** Short press to switch between Bluetooth, FM Radio, USB, TF Card, and AUX modes.
- **Play/Pause Button:** Short press to play or pause music. Long press to initiate automatic FM channel search (in FM mode) or to answer/end calls (in Bluetooth call mode).
- **Previous Track/Volume Down Button:** Short press for previous track. Long press to decrease volume.
- **Next Track/Volume Up Button:** Short press for next track. Long press to increase volume.

Ports:

- **DC 5V (Type-C):** For charging the speaker.
- **TF Card Slot:** Insert a TF (MicroSD) card for music playback.
- **USB Port:** Insert a USB drive for music playback.
- **MIC:** Microphone input.

- **AUX:** 3.5mm auxiliary input for wired connection to audio devices.

4. SETUP AND INITIAL USE

4.1 Charging the Speaker

1. Connect the provided Type-C power cable to the DC 5V port on the rear of the speaker.
2. Connect the other end of the cable to a standard USB power adapter (not included) or a computer USB port.
3. The LED indicator will show charging status. Charge fully before first use.

4.2 Power On/Off

To power on the speaker, locate the power switch (often integrated with the mode button or a separate switch). The speaker will emit a car engine starting sound and the headlights will illuminate.

To power off, repeat the action or long-press the power button.



Image: The WSTER WS-1934 speaker with its headlights glowing, showcasing its classic car design.

5. OPERATING MODES

5.1 Bluetooth Mode

1. Power on the speaker. It will automatically enter Bluetooth pairing mode, indicated by a voice prompt and flashing LED headlights.
2. On your mobile device, enable Bluetooth and search for available devices.
3. Select "WS-1934" from the list to pair. A successful connection will be confirmed by a voice prompt.
4. You can now play audio from your device through the speaker.



Image: The WS-1934 speaker wirelessly connected to a smartphone via Bluetooth, ready for audio playback.

5.2 FM Radio Mode

1. Short press the **M/Mode** button until you hear the FM radio prompt.
2. Long press the **Play/Pause** button to initiate an automatic search for FM stations. The speaker will scan and save available stations.

3. Use the **Previous Track/Volume Down** and **Next Track/Volume Up** buttons to navigate between saved stations.

5.3 USB/TF Card Playback

1. Insert a USB drive into the USB port or a TF (MicroSD) card into the TF card slot.
2. The speaker will automatically switch to the corresponding mode and begin playing audio files. If not, short press the **M/Mode** button to select the correct mode.
3. Use the **Previous Track/Volume Down** and **Next Track/Volume Up** buttons to control playback.

5.4 AUX Mode

1. Connect an external audio device (e.g., MP3 player, computer) to the AUX port using a 3.5mm audio cable (not included).
2. Short press the **M/Mode** button until you hear the AUX mode prompt.
3. Control audio playback from your connected device.

5.5 TWS (True Wireless Stereo) Pairing

To achieve a stereo sound experience, you can pair two WS-1934 speakers together.

1. Ensure both WS-1934 speakers are powered on and in Bluetooth mode, but not yet connected to any device.
2. On one of the speakers (this will be the primary speaker), double-click the **Play/Pause** button. You will hear a