

[manuals.plus](#) /

› [MAXLEGEN](#) /

› [MAXLEGEN N40 10.1-inch Android 15 Tablet User Manual](#)

MAXLEGEN N40

MAXLEGEN N40 10.1-inch Android 15 Tablet User Manual

Model: N40

1. INTRODUCTION

This manual provides detailed instructions for the setup, operation, and maintenance of your MAXLEGEN N40 10.1-inch Android 15 Tablet. Please read this manual thoroughly to ensure proper use and to maximize the performance of your device.



Image 1.1: MAXLEGEN N40 Tablet with its accessories, including a keyboard, mouse, and stylus, ready for use.

2. WHAT'S IN THE Box

Upon unpacking, verify that all the following items are included:

- 1x MAXLEGEN N40 10.1-inch Android 15 Tablet
- 1x Protective Case
- 1x Bluetooth Keyboard
- 1x Mouse
- 1x Stylus
- 1x Earphones
- 3x Multilingual Keyboard Stickers (including Italian)
- 1x Charger
- 1x USB-C Cable
- 1x User Manual

Image 2.1: Visual representation of all components included in the MAXLEGEN N40 Tablet package.

3. SETUP

3.1 Initial Charging

Before first use, fully charge the tablet using the provided charger and USB-C cable. Connect the USB-C cable to the tablet's charging port and the charger to a power outlet. The battery indicator will show charging status.

3.2 Powering On/Off

- **To Power On:** Press and hold the power button located on the side of the tablet until the MAXLEGEN logo appears.
- **To Power Off:** Press and hold the power button, then select 'Power off' from the options displayed on the screen.

3.3 Connecting Accessories

Connecting the Mouse

1. Remove the USB receiver from the bottom of the mouse.
2. Connect the USB receiver to the USB-A (female) port of the OTG adapter.
3. Connect the OTG adapter to the USB-C port of the tablet.
4. Install two AAA batteries into the mouse. The red indicator light will illuminate.

Please ensure the sequence of operations is followed as indicated above. Otherwise, the mouse will not function.

Connecting the Bluetooth Keyboard

1. Turn on the power switch on the keyboard to activate it.
2. Press the "CONNECT" button on the keyboard.
3. On your tablet, activate the Bluetooth function. Go to Settings > Connected devices > Pair new device and select the device named "Bluetooth Keyboard 3.0" to pair.

3.4 Initial Android Setup

Upon first power-on, follow the on-screen prompts to complete the initial setup of the Android 15 operating system. This includes selecting your language, connecting to Wi-Fi, and signing in to your Google account.



Not only a Tablet, But also a Laptop

Comes with keyboard and protective case and
earphone

Image 3.1: The MAXLEGEN N40 Tablet transformed into a laptop-like setup with its Bluetooth keyboard and mouse, ideal for productivity.

4. OPERATING INSTRUCTIONS

4.1 Basic Navigation

The tablet features a 10.1-inch IPS touchscreen with a resolution of 1280x800 pixels. Navigate by tapping, swiping, and pinching gestures. The Android 15 operating system provides an intuitive user interface.



Image 4.1: The 10.1-inch IPS display of the MAXLEGEN N40 Tablet showcasing its visual clarity.

4.2 Network Connectivity


- **Wi-Fi:** The tablet supports dual-band 5G/2.4GHz Wi-Fi for fast and stable internet connections. To connect, go to Settings > Network & internet > Wi-Fi, then select your network and enter the password.
- **Bluetooth:** Bluetooth 5.0 is integrated for connecting wireless accessories like headphones, speakers, and the included keyboard and mouse. To pair, go to Settings > Connected devices > Pair new device.

4.3 Storage and Memory

The tablet comes with 36GB of RAM (12GB physical + 24GB virtual) and 128GB of internal storage (ROM). Storage can be expanded up to 2TB using a TF (MicroSD) card (sold separately).

2TB Storage & Expansion 2TB

36GB+128GB, with SanDisk MicroSD Card, Keep All of What You Like



*MicroSD card is sold separately

Image 4.2: The MAXLEGEN N40 Tablet highlighting its extensive storage capacity and expansion options up to 2TB.

4.4 Camera Functionality

The tablet is equipped with an 8MP rear camera and a 5MP front camera. Open the Camera application to capture photos and videos.

4.5 Multimedia and Streaming

With Widevine L1 support, the tablet allows for high-definition streaming from platforms like YouTube, Netflix, Prime Video, and HBO Max.



Image 4.3: The MAXLEGEN N40 Tablet showcasing its Widevine L1 support, enabling high-quality streaming from popular services.

4.6 Battery Management

The 8000mAh battery provides extended usage time. To optimize battery life, adjust screen brightness, close unused applications, and enable power-saving modes in Settings.

4.7 Additional Features

- **Screen Projection:** Connect your tablet to a larger display for presentations or media viewing.
- **Privacy Permissions:** Manage app permissions in Settings to control access to your data and device features.
- **Eye Comfort Mode:** Reduce blue light emission for more comfortable reading, especially in low-light conditions.
- **Child Protection Mode:** Utilize parental controls to manage content and usage for children.



Image 4.4: Examples of the MAXLEGEN N40 Tablet in use for working, learning, playing videos, and gaming.

5. MAINTENANCE

5.1 General Care

- Keep the tablet clean using a soft, dry cloth. Avoid liquid cleaners.
- Protect the screen with the included protective case.
- Avoid exposing the tablet to extreme temperatures, direct sunlight, or moisture.

5.2 Battery Care

- Do not allow the battery to fully discharge frequently.
- Use only the original charger and cable provided.
- If the tablet will not be used for an extended period, charge it to about 50% and store it in a cool, dry place.

5.3 Software Updates

Regularly check for system updates to ensure optimal performance and security. To update the system, go to Settings > About tablet > System update.

6. TROUBLESHOOTING

This section addresses common questions and issues you might encounter.

Image 6.1: A visual guide to common questions and solutions for the MAXLEGEN N40 Tablet.

6.1 Frequently Asked Questions

Q: How to set up the virtual navigation buttons?

A: Go to Settings > System > Gestures > System navigation > 3-button navigation.

Q: How to connect the mouse to the tablet?

A: Refer to section 3.3 "Connecting the Mouse" for detailed instructions.

Q: How to connect a Bluetooth keyboard to a tablet?

A: Refer to section 3.3 "Connecting the Bluetooth Keyboard" for detailed instructions.

Q: How to update the system?

A: Go to Settings > About tablet > System update.

7. SPECIFICATIONS

Feature	Specification
Brand	MAXLEGEN
Model Name	N40
Operating System	Android 15
Screen Size	10.1 Inches
Screen Resolution	1280 x 800 Pixels (IPS)
Processor	Octa-Core Rockchip, 2 GHz
RAM	36 GB (12GB physical + 24GB virtual)
Internal Storage (ROM)	128 GB
Expandable Storage	Up to 2TB via TF card (MicroSD)
Wi-Fi Connectivity	5G/2.4GHz (802.11ac, 802.11b, 802.11g, 802.11n)
Bluetooth	Bluetooth 5.0
Front Camera	5 MP
Rear Camera	8 MP
Battery Capacity	8000 mAh (approx. 8 hours average life)
Special Features	Expandable Memory, USB OTG Support, Detachable Keyboard
Color	Gray
Item Weight	1.3 Kilograms



Image 7.1: An infographic summarizing key features and specifications of the MAXLEGEN N40 Tablet.

8. WARRANTY AND SUPPORT

MAXLEGEN offers lifetime support for this tablet. If you have any questions or require technical assistance regarding your MAXLEGEN N40 Tablet, please do not hesitate to contact our customer support. Contact information can typically be found on the MAXLEGEN official website or through your purchase platform.