

Vente-unique Triseo

Vente-unique Triseo Shower Screen

Model: Triseo

INTRODUCTION

Thank you for choosing the Vente-unique Triseo Shower Screen. This manual provides essential information for the safe installation, proper use, and maintenance of your new shower screen. The Triseo model features a modern design with a black frame and partially opaque tempered glass, measuring approximately 100cm in width and 200cm in height, designed for walk-in shower configurations.

SAFETY INSTRUCTIONS

Please read all safety instructions carefully before installation and use. Failure to follow these instructions may result in injury or damage to the product.

- **Handle with Care:** Tempered glass, while strong, can shatter if struck forcefully at the edges or corners. Always handle glass panels with extreme care.
- **Protective Gear:** Wear appropriate personal protective equipment, including safety glasses and gloves, during installation.
- **Secure Installation:** Ensure the shower screen is securely mounted to a solid wall structure using appropriate fasteners. Improper installation can lead to the screen falling, causing severe injury.
- **Do Not Hang:** Do not hang towels or apply excessive weight to the shower screen or its stabilizing bar.
- **Regular Inspection:** Periodically check all screws and fixings to ensure they remain tight and secure.
- **Children and Pets:** Keep children and pets away from the installation area.

SETUP AND INSTALLATION

Installation should be performed by two adults. Ensure you have all necessary tools (e.g., drill, level, measuring tape, screwdriver) before beginning.

Components Overview




Image: Overview of the Vente-unique Triseo Shower Screen components, including the main glass panel with its black frame and the adjustable stabilizing bar.

Installation Steps

1. **Prepare the Area:** Ensure the shower tray or floor is clean and level. Mark the desired position of the shower screen on the wall and floor.
2. **Mount Wall Profile:** Attach the wall profile (if separate) to the wall using appropriate screws and wall plugs. Use a level to ensure it is perfectly vertical.
3. **Position Glass Panel:** Carefully lift the glass panel and insert it into the wall profile. Ensure the panel is seated correctly.
4. **Secure Glass Panel:** Secure the glass panel within the wall profile using the provided screws and seals.
5. **Install Stabilizing Bar:** Attach the stabilizing bar to the top edge of the glass panel and extend it to the opposite wall. Adjust its

length to fit the space.



Image: Detail of the adjustable stabilizing bar connection point at the top of the glass panel.

6. **Secure Stabilizing Bar:** Mark and drill holes for the stabilizing bar's wall mount. Secure the bar to the wall.
7. **Seal Edges:** Apply silicone sealant along the bottom and vertical edges where the glass meets the shower tray/floor and wall, as per manufacturer guidelines, to ensure a watertight seal. Allow adequate drying time before use.



Image: The Triseo Shower Screen after complete installation, showcasing its design within a modern bathroom.

OPERATING INSTRUCTIONS

The Triseo Shower Screen is designed to provide a fixed barrier for your walk-in shower area.

- **Intended Use:** This product is intended solely as a fixed shower enclosure panel.
- **Avoid Impact:** Do not strike the glass panel with hard objects.
- **Ventilation:** Ensure adequate ventilation in your bathroom to prevent excessive moisture buildup, which can affect the longevity of seals and finishes.

MAINTENANCE

Regular cleaning and maintenance will help preserve the appearance and functionality of your shower screen.

- **Glass Cleaning:** Clean the tempered glass regularly with a soft cloth and a non-abrasive glass cleaner. For best results, wipe down the glass after each use to prevent water spots and limescale buildup.
- **Frame Cleaning:** Clean the black frame with a soft, damp cloth and mild soap. Avoid harsh chemicals, abrasive cleaners, or scouring pads, as these can damage the finish.
- **Seal Inspection:** Periodically inspect the silicone seals for any signs of wear, cracking, or mold. Reapply sealant if necessary to maintain watertight integrity.
- **Fixing Check:** Annually, check all screws and mounting points to ensure they are still tight. Tighten gently if any looseness is detected.

TROUBLESHOOTING

If you encounter issues with your Triseo Shower Screen, refer to the following common problems and solutions.

Problem	Possible Cause	Solution
Water leakage at the base or sides.	Improperly applied sealant or worn seals.	Inspect and reapply silicone sealant where necessary. Replace old or damaged seals.
Shower screen feels wobbly or loose.	Loose mounting screws or stabilizing bar fixings.	Check and gently tighten all mounting screws and stabilizing bar connections. Ensure wall plugs are secure.
Glass appears cloudy or stained.	Limescale or soap scum buildup.	Clean with a non-abrasive glass cleaner. Consider using a squeegee after each shower to prevent buildup.

If the problem persists or you encounter issues not listed here, please contact Vente-unique customer support.

SPECIFICATIONS

- **Model:** Triseo
- **Brand:** Vente-unique
- **Material:** Tempered Glass, Metal Frame (Black finish)
- **Dimensions (Approximate):**
 - Width: 100 cm
 - Depth/Thickness: 0.6 cm (6 mm)
 - Height: 200 cm
- **Weight:** 35.6 kg
- **Features:** Graphic screen-printed glass, adjustable stabilizing bar.

WARRANTY AND SUPPORT

For information regarding the warranty period and terms for your Vente-unique Triseo Shower Screen, please refer to your purchase documentation or contact the retailer directly. For technical assistance or spare parts, please reach out to Vente-unique customer service.

Vente-unique Customer Service: Please visit the official Vente-unique website or your point of purchase for contact details.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0FHF53HK9>

More documents and user manuals: **<https://manuals.plus/>**