

## SS10-5808

### Generic Encore Showerhead Adapter with Hoop

Model: SS10-5808

#### 1. PRODUCT OVERVIEW

The Generic Encore Showerhead Adapter with Hoop is designed to provide a flexible connection point for handheld showerheads. This adapter features a 1/2 inch Male NPSM connection for attachment to a standard shower arm and a female connection with an integrated hoop. The hoop allows for convenient hanging and angling of a handheld showerhead, optimizing spray coverage and user comfort. It is constructed for durability and ease of installation in various plumbing setups.

#### 2. SAFETY INFORMATION

- Always turn off the main water supply before beginning any plumbing installation or maintenance.
- Use appropriate tools and avoid over-tightening connections, which can damage threads or components.
- Ensure all connections are secure to prevent leaks.
- If you are unsure about any step, consult a qualified plumber.

#### 3. PACKAGE CONTENTS

- 1 x Generic Encore Showerhead Adapter with Hoop (Model SS10-5808)

#### 4. SETUP AND INSTALLATION

1. **Prepare the Shower Area:** Turn off the water supply to your shower. Remove your existing showerhead or any current adapter from the shower arm. Clean any old sealant or debris from the shower arm threads.
2. **Apply Thread Sealant (Optional but Recommended):** For a watertight seal, apply plumber's tape (PTFE tape) clockwise around the threads of the shower arm.
3. **Attach the Adapter to the Shower Arm:** Screw the female end of the Encore Showerhead Adapter onto the shower arm. Hand-tighten first, then use an adjustable wrench to gently tighten until secure. Avoid over-tightening.
4. **Connect Handheld Shower Hose:** Screw the handheld shower hose onto the male NPSM connection of the adapter. Hand-tighten, then use a wrench to gently snug it up. Ensure a washer is properly seated in the hose connection.
5. **Check for Leaks:** Turn the water supply back on slowly and check all connections for leaks. If leaks occur, tighten slightly or reapply thread sealant.



*This image displays the chrome-plated showerhead adapter. One end features a male threaded connection for attachment to a shower arm, while the other end has a female threaded connection with an internal hoop designed to hold a handheld showerhead. A hexagonal nut is visible on the side for secure tightening.*

## 5. OPERATION

Once installed, the Encore Showerhead Adapter functions as a fixed point for your handheld showerhead. The integrated hoop allows you to hang your handheld showerhead securely, providing flexibility to adjust its angle for optimal spray coverage. Simply place the handheld showerhead into the hoop to position it as desired.

## 6. MAINTENANCE

- **Cleaning:** Periodically clean the adapter with a soft cloth and mild soap to remove water spots and mineral buildup. Avoid abrasive cleaners or harsh chemicals that could damage the finish.
- **Leak Checks:** Regularly inspect all connections for any signs of leaks. Tighten connections if necessary.
- **Gasket Inspection:** If you experience persistent leaks, check the condition of the rubber gaskets or washers within the connections. Replace them if they appear worn or damaged.

## 7. TROUBLESHOOTING

- **Leakage at Connections:**

- Ensure connections are hand-tightened and then gently snugged with a wrench.
- Verify that plumber's tape (PTFE tape) was applied correctly to the shower arm threads.
- Check for damaged or missing rubber washers/gaskets in the connections and replace if necessary.

- **Handheld Showerhead Does Not Stay in Hoop:**

- Ensure the handheld showerhead is properly seated within the hoop.
- Verify that the showerhead's design is compatible with the hoop's size and shape.

## 8. SPECIFICATIONS

<b>Model Number</b>	SS10-5808
<b>Connection Size</b>	1/2 inch
<b>Connection Type</b>	Male NPSM
<b>Material</b>	Other (Chrome-plated)
<b>Product Dimensions</b>	1 x 1 x 5 inches
<b>Brand</b>	Generic

## 9. WARRANTY AND SUPPORT

For warranty information or technical support regarding your Generic Encore Showerhead Adapter with Hoop, please refer to the retailer's return policy or contact the seller directly. Keep your purchase receipt for any warranty claims.