

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [AECOJOY](#) /

› [AECOJOY Outdoor Swivel Bar Stools Set of 4 Instruction Manual](#)

AECOJOY SS16222BK-AA

AECOJOY Outdoor Swivel Bar Stools Set of 4 Instruction Manual

Model: SS16222BK-AA

INTRODUCTION

Thank you for choosing the AECOJOY Outdoor Swivel Bar Stools Set of 4. This manual provides essential information for the safe assembly, operation, maintenance, and care of your new patio furniture. Please read these instructions carefully before assembly and retain them for future reference.

IMPORTANT SAFETY INFORMATION

WARNING:

- Always use caution when swiveling the chairs to prevent tip-overs.
- This product is designed for adult use and may not be suitable for children.
- Keep children and pets away from the chairs when in use.
- Ensure all bolts and fasteners are securely tightened before use and periodically check for tightness.
- Do not exceed the maximum weight capacity of 350 pounds per stool.

PACKAGE CONTENTS

The AECOJOY Outdoor Swivel Bar Stools Set of 4 includes:

- 4 x Swivel Bar Stools (disassembled)
- 4 x Seat Cushions
- 4 x Backrest Cushions
- Assembly Hardware Kit
- Assembly Tools
- Instruction Manual

Please verify all components are present before beginning assembly. If any parts are missing or damaged, please contact customer support.

SETUP AND ASSEMBLY

Assembly of the AECOJOY Outdoor Swivel Bar Stools is designed to be straightforward. With the included tools and clear instructions, two people can typically complete the assembly of all four stools in under 30 minutes.

1. Unpack all components and lay them out on a clean, soft surface to prevent scratching.
2. Identify all parts according to the parts list in the included instruction manual.
3. Follow the step-by-step diagrams and instructions provided in the manual to assemble each stool.
4. Ensure all bolts and fasteners are tightened securely, but do not overtighten until all parts are aligned.
5. Once fully assembled, place the seat and backrest cushions onto the stools.



Image: Key features of the AECOJOY Outdoor Swivel Bar Stool, including the cushion, metal legs, swivel, and backrest design.



SWIVEL OUTDOOR BAR STOOL



Swivel Spin

Image: Demonstration of the 360-degree swivel capability and its underlying mechanism.

OPERATING INSTRUCTIONS

The AECOJOY Outdoor Swivel Bar Stools are designed for comfortable outdoor seating and interaction.

- **Swivel Function:** The stools feature a 360-degree swivel design, allowing you to easily turn and engage with your surroundings without moving the base of the chair. Use this feature smoothly and avoid sudden, forceful movements.
- **Comfort:** The soft seat and backrest cushions, combined with the ergonomic design, provide a comfortable seating experience even for extended periods. The high-density mesh fabric of the chairs promotes airflow, keeping you cool in warmer weather.
- **Footrest:** Utilize the integrated ring footrest for added comfort and support, especially for users between 5'3" and 6'3" in height.



Image: A set of four AECOJOY swivel bar stools in an outdoor patio setting.

MAINTENANCE

Proper maintenance will extend the life and appearance of your AECOJOY Outdoor Swivel Bar Stools.

- **Cleaning:** Wipe the metal frames with a damp cloth and mild soap. Rinse thoroughly and dry completely to prevent water spots. For cushions, spot clean with a mild detergent and water. Allow to air dry completely before storage.
- **Frame Care:** The metal frame is powder-coated for resistance against rust, corrosion, and fading. While designed for all-weather use, storing the stools in a covered area during harsh weather conditions (heavy rain, snow, extreme temperatures) will help preserve their finish.
- **Fastener Checks:** Periodically inspect all bolts and fasteners to ensure they remain tight. Retighten as necessary to maintain stability and safety.
- **Cushion Care:** Although the cushions are designed for outdoor use, prolonged exposure to direct sunlight and rain can affect their longevity. Consider storing cushions indoors when not in use for extended periods.

TROUBLESHOOTING

This section addresses common issues you might encounter.

Problem	Possible Cause	Solution
Stool feels wobbly or unstable.	Loose fasteners or uneven surface.	Check and tighten all assembly bolts. Ensure the stool is placed on a flat, level surface.
Swivel mechanism is stiff or noisy.	Lack of lubrication or debris in the mechanism.	Clean the swivel mechanism and apply a silicone-based lubricant if necessary. Avoid oil-based lubricants that can attract dirt.
Cushions appear flattened or discolored.	Prolonged exposure to elements or heavy use.	Fluff cushions regularly. Store cushions indoors when not in use to protect from UV and moisture. Spot clean as needed.

If you encounter issues not listed here or require further assistance, please contact AECOJOY customer support.

SPECIFICATIONS

Feature	Detail
Model Number	SS16222BK-AA
Material	Metal & Fabric
Product Dimensions (L x W x H)	27 x 28 x 44 inches
Item Weight (per stool)	Approximately 29.5 pounds
Weight Capacity (per stool)	Up to 350 pounds
Special Features	360-degree Swivel, All-Weather Design, Breathable Mesh Fabric
Color	Beige (cushions)
Set Quantity	4 Stools

PARAMETERS



Image: Dimensional specifications and weight capacity of the AECOJOY swivel bar stool.

WARRANTY AND SUPPORT

AECOJOY provides a **1-year manufacturer warranty** against defective workmanship or missing parts from the date of purchase.

For any problems, questions, or warranty claims, please contact AECOJOY customer support. Have your model number (SS16222BK-AA) and proof of purchase ready when contacting support.

You can find more information and contact details on the official AECOJOY store page: [AECOJOY Store](#).



Related Documents - [SS16222BK-AA](#)

