

[Manuals.plus](#) /

› [Bellemave](#) /

› Bellemave Twin Floor Bed with High Fence Instruction Manual

## Bellemave Twin Floor Bed with High Fence

# Bellemave Twin Floor Bed with High Fence Instruction Manual

Model: Twin Floor Bed with High Fence (White Fence Twin)

### IMPORTANT SAFETY INFORMATION

Please read and understand all instructions before assembly and use. Keep this manual for future reference.

- Always assemble according to the provided instructions to ensure stability.
- Be aware of potential sharp edges and check for any splinters regularly.
- Keep the bed away from walls or other structures to prevent entrapment.
- Never leave children unattended while they are sleeping or playing near the bed.

### PRODUCT OVERVIEW

The Bellemave Twin Floor Bed with High Fence is designed to provide a safe and comfortable sleeping environment for children, facilitating an easy transition to an independent bed. This Montessori-style bed features a high surrounding fence and a small, functional door.



Image: The Bellemave Twin Floor Bed with High Fence in white, showcasing its full structure and design.

### Key Features:

- **High Fence Design:** Equipped with a 21.46-inch high surrounding fence for enhanced safety.
- **One-Piece Fence Construction:** Unlike segmented designs, the four guardrails are fully connected for improved stability.
- **Functional Door:** Features a small door that can be opened and closed, adding convenience and a playful element.
- **Sturdy Construction:** Crafted from high-quality pine wood and MDF for durability and stability.
- **No Box Spring Needed:** Designed for a mattress to be placed directly on the floor, offering comfortable support without a box spring.

### SETUP AND ASSEMBLY

This bed frame is designed for easy assembly. Please ensure all parts are present before beginning. Refer to the detailed assembly instructions included in your product packaging for step-by-step guidance.

### Before You Begin:

- Unpack all components and lay them out on a clean, soft surface to prevent scratches.
- Verify that all hardware and parts listed in the assembly manual are accounted for.
- Gather necessary tools (typically a screwdriver and Allen wrench, often included).



Image: Illustration comparing the one-piece fence construction of this bed (labeled 'OURS') with a segmented fence design (labeled 'OTHERS'), highlighting the integrated design for stability.

The bed ships in one box for convenient delivery. Follow the provided diagrams and instructions carefully to ensure correct and secure assembly.


## **OPERATING INSTRUCTIONS**

The Bellemave Twin Floor Bed is designed for simple and safe use.

### **Using the Door:**

- The bed features a small, hinged door for easy entry and exit.
- To open, gently unlatch the door mechanism and swing it outwards.
- To close, swing the door back into position and secure the latch firmly.

# Dimensions



**Twin Bed inner Size: 75.16" x 38.98"**

Image: A side view of the bed, illustrating the small, functional door that allows for easy access.



Image: A close-up view of the door's latch mechanism, demonstrating how it secures the door in a closed position.

Ensure the door is properly latched when the bed is in use to maintain a secure sleeping area.

## MAINTENANCE

Regular maintenance will help preserve the quality and longevity of your Bellemave Twin Floor Bed.

- **Cleaning:** Wipe down the bed frame with a soft, damp cloth. Avoid using harsh chemicals or abrasive cleaners, which can damage the finish.
- **Inspections:** Periodically check all screws and connections to ensure they remain tight. Re-tighten as necessary to maintain structural integrity.
- **Wood Care:** Protect the wood from extreme temperature changes and direct sunlight to prevent warping or fading.

## TROUBLESHOOTING

If you encounter any issues with your Bellemave Twin Floor Bed, consider the following common solutions:

- **Loose Connections:** If the bed feels wobbly or parts seem loose, re-tighten all screws and bolts. It is recommended to check these periodically.

- **Door Not Securing Properly:** Ensure the door is correctly aligned with the frame and the latch mechanism is fully engaged. If the latch is loose, inspect its attachment points and tighten any screws.
- **Missing Parts:** If you discover missing components during assembly, please contact customer support immediately with your purchase details.
- **Squeaking Noises:** Check all joints and connections. Applying a small amount of lubricant (e.g., paraffin wax) to metal-on-metal contact points or wood joints can help reduce squeaking.

## SPECIFICATIONS

Feature	Detail
Size	Twin
Product Dimensions	78.19"L x 41.77"W x 21.46"H
Special Feature	High Fence
Color	White Fence
Finish Type	Painted
Included Components	Door
Compatible Mattress Size	Twin Size
Material	Wood
Assembly Required	Yes
Item Weight	21 pounds
Model Number	Twin Floor Bed with High Fence
ASIN	B0FHGG9G47
UPC	197793831505



Image: A diagram illustrating the key dimensions of the Bellemave Twin Floor Bed, including length, width, and fence height.



Image: A visual comparison highlighting the 21.46-inch fence height of the Bellemave bed (labeled 'OURS') against a shorter 14.55-inch fence found on other beds (labeled 'OTHERS').

## **WARRANTY AND SUPPORT**

Bellemave is committed to providing quality products. For any questions, concerns, or support needs regarding your Twin Floor Bed, please refer to the following information:

### **Warranty Information:**

Protection plans are available for purchase separately, offering extended coverage for 2-year or 3-year durations. Please consult your retailer for details on available protection plans and their terms.

### **Customer Support:**

For direct assistance, please contact Bellemave customer support via email:

Email: [US-VC@bellemavehome.com](mailto:US-VC@bellemavehome.com)

When contacting support, please provide your product model number (Twin Floor Bed with High Fence) and purchase details to expedite assistance.