

[Manuals.plus](#) /

> [Muvai](#) /

> Muvai 59-inch Reversible L-Shaped Electric Standing Desk User Manual

Muvai Muvai

Muvai 59-inch Reversible L-Shaped Electric Standing Desk User Manual

1. INTRODUCTION

This manual provides comprehensive instructions for the assembly, operation, and maintenance of your Muvai 59-inch Reversible L-Shaped Electric Standing Desk. Please read this manual thoroughly before installation and use to ensure proper function and safety. This desk features a reversible L-shaped design, electric height adjustment, and memory presets for an optimized workspace.



2. SAFETY INFORMATION

- Always follow the assembly instructions carefully.
- Keep hands and body parts away from moving parts during height adjustment.
- Do not exceed the maximum weight limit of 176 lbs (80 kg).
- Ensure the desk is properly anchored or placed on a stable surface to prevent tipping.
- Always unplug the desk when not in use or when performing maintenance.
- Avoid placing liquids directly on the control panel or near electrical components.

3. PACKAGE CONTENTS

Verify that all components are present before beginning assembly. Refer to the detailed parts list in the included printed manual for specific item identification. Key components include:

- Desktop panels (splice board)
- Leg columns with motors
- Crossbars and support beams
- Control panel and power adapter
- Mounting hardware (screws, bolts, tools)
- Cable management accessories (cup holder, headphone hook, cable tray)

4. ASSEMBLY INSTRUCTIONS

Assembly typically takes 30-59 minutes. It is recommended to have two people for certain steps. Follow the sequence below carefully.

4.1. Desktop Assembly


The desktop consists of three splice plates. Connect them using the provided screws and accessories. The L-shape is reversible for left or right-handed configurations.

Reversible Desktop

Both available for left-hander and right-hander

L

R



HOLDER



HOOK

Figure 2: Reversible desktop configuration.

4.2. Frame Assembly

Attach the leg columns and crossbars to form the desk frame. Ensure all connections are secure. The frame is constructed from sturdy SPCC steel.



Figure 3: High-carbon steel structure of the desk leg.

4.3. Motor and Control Panel Installation

Install the electric motor and connect the control panel. The control panel allows for easy height adjustments and memory presets.

Intelligent Control Panel




Figure 4: Intelligent Control Panel.

4.4. Cable Management

Utilize the included cable management tray and clips to organize wires and maintain a tidy workspace.

ORGANIZE YOUR WORKSTATION



Figure 5: Cable management solution.

4.5. General Assembly Video Guides

The following videos provide general assembly guidance for L-shaped standing desks. While not specific to the Muvai model, they illustrate common installation techniques.

General L-Shaped Electric Standing Desk Installation Guide (MEXIN)

Your browser does not support the video tag.

Video 1: General installation steps for an L-shaped electric standing desk.

Acrolix L-shaped Standing Desk Installation

Your browser does not support the video tag.

Video 2: Another general guide for assembling an L-shaped standing desk.

5. OPERATING INSTRUCTIONS

5.1. Height Adjustment

Use the UP (^) and DOWN (v) buttons on the control panel to adjust the desk height. The desk can be adjusted between 28.3 inches and 46.4 inches (72 cm - 118 cm).

5.2. Memory Presets

The control panel features three preset memory height functions. To save a height setting, adjust the desk to your desired height, then press and hold one of the numbered preset buttons (1, 2, or 3) until you hear a beep or see a confirmation on the display. To recall a saved height, simply press the corresponding preset button.

6. MAINTENANCE

- Regularly check all screws and bolts to ensure they are tight.
- Clean the desktop surface with a soft, damp cloth. Avoid harsh chemicals.
- Keep the motor and electrical components free from dust and moisture.
- Do not lubricate the lifting columns unless specified by the manufacturer.

7. TROUBLESHOOTING

7.1. Desk Not Moving

- Check all power connections to ensure they are securely plugged in.
- Verify that the power outlet is functional.
- Perform a reset: Press and hold the 'S' or 'Reset' button (if available) for several seconds until the desk moves to its lowest position and resets.

7.2. Uneven Height Adjustment

- Ensure the desk is not overloaded or unevenly weighted.
- Perform a reset as described above.

7.3. Noise During Operation

- A low noise motor (under 45dB) is normal. Excessive noise may indicate loose connections; check all bolts.

8. SPECIFICATIONS

Feature	Detail
Brand	Muvai
Model Number	Muvai
Color	White
Product Dimensions	60D x 150W x 72H Centimetres (59 inches width)
Material	Metal frame, Engineered Wood top
Special Features	Adjustable Height, Reversible L-Shape, Memory Presets, Low Noise Motor

Item Weight	29.9 kg
Height Adjustable Range	28.3" - 46.4"
Load Capacity	176 lbs

9. WARRANTY AND SUPPORT

Muvai provides a 2-Year Manufacturer Warranty for this product. For any questions or concerns, please contact customer support. Friendly technical support is available 7 days a week, 24 hours a day.

Contact information may be found on your purchase receipt or the product packaging.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question