



[Manuals.plus](#) /

› [DATAFY](#) /

› DATAFY FYQ-K1-Ring Remote Page Turner Instruction Manual

DATAFY FYQ-K1-Ring

DATAFY FYQ-K1-Ring Remote Page Turner Instruction Manual

Model: FYQ-K1-Ring

INTRODUCTION

This manual provides detailed instructions for the setup, operation, maintenance, and troubleshooting of your DATAFY FYQ-K1-Ring Remote Page Turner. This device is designed to enhance your reading experience on various e-readers and tablets, and also functions as a remote control for camera and video applications.

PRODUCT OVERVIEW

The DATAFY FYQ-K1-Ring Remote Page Turner consists of two main components: a wearable ring remote and a screen sensor clip. It comes with essential accessories for charging and storage.

What's Included:

- Ring Remote Control x 1
- Screen Sensor Clip x 1
- Type-C Charging Cable x 1
- Storage Bag x 1
- User Manual x 1



Image: Components included with the DATAFY FYQ-K1-Ring Remote Page Turner.

SETUP

1. Charging the Device

Both the ring remote and the screen sensor clip are rechargeable via the provided Type-C USB cable. Ensure both units are fully charged before first use for optimal performance.

- **Quick Charge Time:** Approximately 1.5 hours.
- **Single Use Time:** Up to 25 hours.
- **Standby Time:** Up to one week.

The device features an automatic shutdown function after 30 minutes of inactivity to conserve battery. Manual shutdown is not required.



Image: Charging the DATAFY Remote Page Turner components.

2. Pairing the Remote and Clip

The remote and clip need to be paired before each use. Follow these steps:

1. Press the button on the back of the screen sensor clip. A blue light will illuminate.
2. Press the button on the ring remote. The blue light on the clip will flash, indicating successful pairing.
3. The device is now ready for use.

Free Up Your Hands



Image: Steps for initial setup and pairing.

Your browser does not support the video tag.

Video: A user demonstrates the pairing process and functionality of the page turner ring with an e-reader.

OPERATING INSTRUCTIONS

1. E-Reader Page Turning

The DATAFY FYQ-K1-Ring is compatible with various capacitive touchscreen e-readers and tablets. It allows for hands-free page turning, enhancing comfort during reading.

- **Compatible Devices:** Kindle, Kindle Paperwhite, Kindle Oasis, Kindle Kids Edition, Kindle Voyage, Kobo eReaders, iPhone, iPad, Android Tablets, Surface, Smartphones.
- **Incompatible Devices:** Kindle 7th/8th Generation, Amazon Fire HD 10 (10th/11th generation).

Usage:

1. Attach the screen sensor clip to your e-reader or tablet. Ensure the silicone pad of the clip touches the screen correctly for proper function. The clip is designed to fit devices up to 18.5mm (0.73 inches) thick, accommodating most cases.
2. Wear the ring remote on your finger.
3. Press the button on the ring remote to turn pages forward.
4. If using with an iPad or cell phone, ensure the reading app's scrolling function is turned off to allow page-by-page turning.
5. If the clip covers text, adjust the margins within your e-reader's settings.

Case-Compatible Design

Smooth page flipping for any case size



Our clips fit all kindle cases

18.50mm




Image: Universal compatibility with e-readers and tablets.

Universal Page Turner Multi-compatible

Compatible with supports all capaci-tive touch screens


iPhone iPad Android



Tip: If you can't use the page turner to turn pages using your iPad or cell phone reading, please turn off the scrolling function on thereading app

Kindle and Kobo E-Reader

Reading e-books



✗ The older kindles models ✗ Kindle 7/8 ✗ Kindle fre HD 10(10th/11th)

Image: Case-friendly design of the screen sensor clip.

Image: Correct and incorrect clip placement.

Your browser does not support the video tag.

Video: Demonstration of the page turner in use with a Kindle, allowing hands-free reading.

Your browser does not support the video tag.

Video: Instructions on how to use the page turner with an iPad, including disabling continuous scrolling.

2. Camera and Video Remote Control

The DATAFY FYQ-K1-Ring can also function as a remote shutter for smartphones and touchscreen cameras, enabling hands-free photo taking and video recording.

1. Attach the screen sensor clip to your smartphone or touchscreen camera, ensuring it is positioned over the shutter or record button.
2. Wear the ring remote.
3. Press the button on the ring remote to activate the shutter or start/stop video recording.
4. For touchscreen cameras, ensure the touch photo mode is enabled in the camera settings.



Mute Button Design

Tiny and Portable

Image: Using the device for remote camera and video recording.

Your browser does not support the video tag.

Video: Demonstration of the page turner's compatibility with touchscreen cameras for remote photo capture.


MAINTENANCE

Cleaning

Wipe the device with a soft, dry cloth. Avoid using harsh chemicals or abrasive materials that could damage the surface or internal components.

Storage

When not in use, store the remote page turner and its components in the provided storage bag to protect them from dust and damage.



The silicone pad touches the front of the screen. It can work.

The silicone pad doesn't touch the screen. Don't work!

The silicone pad doesn't touch the screen. Don't work!

Don't Clip on this area, or it will show menu bar.

Place the clip correctly

Place the clip incorrectly

Image: The page turner is tiny and portable, fitting easily into the storage bag.

TROUBLESHOOTING

Clip Covers Text on E-Reader

If the screen sensor clip obstructs text on your e-reader, adjust the left and right margins within your device's display settings.

Refer to your e-reader's user manual for specific instructions on adjusting margins.

Your browser does not support the video tag.

Video: Guide on how to adjust margins on a Kindle to prevent the page turner clip from covering text.

Device Not Responding or Pairing Issues

If the page turner is not responding or fails to pair, try the following:

- Ensure both the ring remote and the screen sensor clip are sufficiently charged.
- Re-attempt the pairing process as described in the 'Setup' section.
- If the device temporarily stops working, manually turn the page on your e-reader once. The page turner should then resume normal function.

Page Turning Multiple Pages or Not Turning

If the device turns multiple pages at once or fails to turn a page, ensure the screen sensor clip is securely and correctly positioned on your device's screen, with the silicone pad making proper contact. Re-pairing the device may also resolve this issue.

SPECIFICATIONS

Feature	Detail
Product Dimensions	2.83 x 1.14 x 0.7 inches
Item Weight	2.08 ounces
Model Number	FYQ-K1 PRO
Batteries	1 C battery required (included)
Special Feature	Page turner, Remote Control Video Shooting, Remote control camera to take pictures
Color	Agave Green
Max Number of Supported Devices	1
Compatible Devices	Supports capacitive screen devices only: E-reader, Surface, Kindle, iPhone, Kobo, Android, iPad, Tablets, Smartphone, Kindle Paperwhite, Kindle Oasis. (Incompatible Devices: Kindle 7/8th Generation, Amazon Fire HD 10th/11th generation)

WARRANTY AND SUPPORT

Warranty Information

The DATAFY FYQ-K1-Ring Remote Page Turner is backed by a thirty-six month Term of Service, which includes a 1-Year Free Replacement policy.

Customer Support

For any questions, concerns, or assistance, please contact DATAFY customer service. 24/7 customer service support is available to help you with your product.



Image: 24/7 Customer Service Support.

You can also visit the official [DATAFY Store](#) for more product information and resources.