

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [VEGER](#) /

> [VEGER V1202 10000mAh 22.5W Fast Charging Portable Charger User Manual](#)

VEGER V1202

VEGER V1202 10000mAh 22.5W Fast Charging Portable Charger User Manual

MODEL: V1202

1. Introduction

Thank you for choosing the VEGER V1202 10000mAh 22.5W Fast Charging Portable Charger. This compact and versatile power bank is designed to keep your devices powered on the go, featuring built-in cables and multiple output options for convenience.

Its slim design and high capacity make it an ideal companion for travel, daily commutes, or any situation where a power outlet is unavailable.

2. Key Features

- **10000mAh High Capacity:** Provides multiple charges for most smartphones.
- **22.5W Fast Charging:** Supports Power Delivery (PD) for rapid charging of compatible devices.
- **Built-in Cables:** Includes integrated USB-C and Lightning cables for hassle-free charging without carrying extra wires.
- **Multiple Outputs:** Features 2 built-in cables (USB-C, Lightning) and 2 additional ports (USB-A, USB-C) for simultaneous charging of up to 4 devices.
- **Multiple Inputs:** Can be recharged via the built-in USB-C cable, the dedicated USB-C input port, or the iOS-compatible input port.
- **Digital Display:** Clear LED display shows the exact battery percentage.
- **Ultra-Compact & Lightweight:** Designed for portability, weighing only 7.8 ounces and measuring 4.57 x 2.83 x 0.66 inches.
- **Travel Safe:** FAA-compliant (38.5Wh) for carry-on luggage.

3. Package Contents



Image: Contents of the VEGER V1202 package, including the portable charger, user manual, and storage pouch.

- VEGER V1202 Portable Charger with Built-in Cables

- User Manual (this document)
- Storage Pouch

4. Product Overview



Image: Close-up of the VEGER V1202 showing the built-in USB-C and Lightning cables neatly integrated into the device.



Image: The digital display on the VEGER V1202 showing the remaining battery percentage, indicating 100% charge.

4.1. Ports and Cables

- **Built-in USB-C Cable:** For charging USB-C compatible devices (input/output).
- **Built-in Lightning Cable:** For charging iOS devices (output only).
- **USB-A Output Port:** Standard USB port for charging various devices.
- **USB-C Input/Output Port:** Versatile port for both charging devices and recharging the power bank.
- **iOS-compatible Input Port:** Dedicated port for recharging the power bank using a Lightning cable.

4.2. Digital Display

The integrated LED digital display provides real-time information on the power bank's remaining battery percentage, allowing you to monitor its charge status accurately.

5. Setup

5.1. Initial Charging of the Power Bank

Before first use, fully charge your VEGER V1202 power bank. This ensures optimal battery performance and longevity.



Image: The VEGER V1202 being recharged using its built-in USB-C cable connected to a wall adapter.




Image: The VEGER V1202 being recharged using its built-in Lightning cable connected to a wall adapter.

To recharge the power bank:

1. Connect the built-in USB-C cable or the built-in Lightning cable to a compatible USB wall adapter (not included).
2. Alternatively, use an external USB-C cable to connect the power bank's USB-C input port to a wall adapter.
3. The digital display will show the charging status and current battery percentage.
4. Once the display shows 100%, the power bank is fully charged.

6. Operating Instructions

6.1. Charging Your Devices



Image: The VEGER V1202 power bank connected to and charging four different electronic devices simultaneously, including a tablet, two smartphones, and wireless earbuds.



Image: Three scenarios showing the VEGER V1202 being used: a couple camping and charging a phone, two people gaming with Nintendo Switches, and a person working on a tablet outdoors.

The VEGER V1202 offers multiple ways to charge your electronic devices:

- **Using Built-in Cables:** Pull out the integrated USB-C or Lightning cable and connect it directly to your device.
- **Using USB-A Port:** Connect your device's charging cable to the USB-A output port on the power bank.
- **Using USB-C Output Port:** Connect your device's USB-C charging cable to the USB-C input/output port on the power bank.

The power bank will automatically begin charging your device. The digital display will show the power bank's remaining charge.

Note: Fast charging may not be available when charging multiple devices concurrently.

7. Device Compatibility



Image: A chart illustrating the wide compatibility of the VEGER V1202 with various devices, including iPhones, iPads, Samsung phones, Nintendo Switch, and other Android devices.

The VEGER V1202 is compatible with a wide range of devices, including but not limited to:

- iPhone 16/15/14/13 Series and all previous iPhone models
- iPad Pro/Air/Mini series
- Samsung Galaxy S25/24 Series and other Samsung/Google Pixel/Xiaomi/Huawei/OPPO Android phones
- AirPods/Pro/Max series
- iWatch 10/Ultra 2/SE and all previous iWatch series
- Nintendo Switch
- Bluetooth Speakers, Desk/Handheld Fans, Heated Vests, and other USB-powered gadgets.

8. Important Safety Information

- Do not expose the power bank to extreme temperatures (hot or cold).
- Avoid dropping, disassembling, or attempting to repair the device.
- Keep away from water and high humidity.
- Use only certified charging cables and adapters.
- Keep out of reach of children.
- The power bank is FAA-compliant (38.5Wh) for carry-on baggage on flights.

9. Specifications

Feature	Detail
Model Number	V1202
Battery Capacity	10000 Milliamp Hours (38.5Wh)
Product Dimensions	4.57 x 2.83 x 0.66 inches
Item Weight	7.8 ounces
Input Ports	Built-in USB-C Cable, USB-C Port, iOS-compatible Input Port
Output Ports	Built-in USB-C Cable, Built-in Lightning Cable, USB-A Port, USB-C Port

Fast Charging	22.5W Power Delivery (PD)
Special Features	Built-in Cables, Digital Display, Fast Charging, Lightweight, Slim
Battery Type	1 Lithium Polymer battery (included)

10. Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the power bank. Avoid liquid cleaners.
- **Storage:** Store the power bank in a cool, dry place away from direct sunlight and extreme temperatures. If storing for extended periods, charge it to about 50-75% every 3 months to maintain battery health.
- **Protection:** Use the included storage pouch to protect the power bank from scratches and minor impacts.

11. Troubleshooting

- **Power Bank Not Charging:** Ensure the charging cable and wall adapter are functioning correctly and properly connected. Try a different cable or adapter.
- **Device Not Charging:** Check if the power bank has sufficient charge. Ensure the cable is securely connected to both the power bank and your device. Try a different cable or port.
- **Slow Charging:** Verify that your device supports fast charging and that you are using a compatible cable and port (e.g., USB-C PD). Charging multiple devices simultaneously may reduce charging speed.
- **Digital Display Not Working:** Press the power button to activate the display. If it remains unresponsive, the power bank may be fully discharged or require service.

12. Warranty and Support

VEGER products come with a standard manufacturer's warranty. For detailed warranty information, product support, or technical assistance, please refer to the warranty card included in your package or visit the official VEGER website. You may also contact VEGER customer service directly through the contact information provided on the product packaging or website.

13. Official Product Videos

VEGER 10000mAh Portable Charger with 2 Built-in Cables

Your browser does not support the video tag.

Video: An official product video from VEGER-US showcasing the 10000mAh portable charger with its two built-in cables, highlighting its features and design.