

[Manuals.plus](#) /

› [ZAIREG](#) /

› Breezamax AC - Breeze Max Portable Air Conditioner User Manual

ZAIREG DH3Y33

Breezamax AC - Portable Air Conditioner User Manual

Brand: ZAIREG | Model: DH3Y33

INTRODUCTION

This user manual provides essential information for the safe and efficient operation of your Breezamax AC Portable Air Conditioner. Please read this manual thoroughly before using the product and retain it for future reference. The Breezamax AC is a compact yet powerful portable air cooler designed to provide instant cooling relief in various small spaces, including rooms, cars, camping setups, and offices. It features dual power modes, quiet operation, smart oscillation, and versatile placement options.

PRODUCT OVERVIEW



Figure 1: Breezamax AC Portable Air Conditioner unit, remote control, USB charging cable, and adhesive hooks.

UPGRADED LONG AIR OUTLET

Wide-angle and widened air outlet

The blades swing automatically



Figure 2: The compact design of the Breezamax AC allows for easy placement on various surfaces like shelves or desks.

The Breezamax AC is designed for personal cooling, offering a blend of portability, efficiency, and user-friendly features. Key aspects include:

- **Instant Cooling Relief:** Provides powerful airflow to cool small spaces quickly.
- **Dual Power Modes:** Operates via USB-C plug-in or a built-in 3000mAh battery for 3-8 hours of cordless use.
- **Ultra Quiet & Energy Efficient:** Operates below 30dB and consumes only 2-7W, significantly less than traditional units.
- **Smart Oscillation + Simple Control:** Features left-to-right oscillation and easy control via one-touch buttons or the included remote.
- **Space-Saving & Versatile Placement:** Lightweight (0.84kg) and compact, it can be placed on tables, mounted on walls, or used in various settings. It is also easily movable from room to room.

PACKAGE CONTENTS

Upon opening the package, please verify that all the following items are included:

- 1 or 2 x Qinux BreezaMax Portable Air Conditioner Unit(s) (depending on purchase)
- 1 or 2 x Remote Control(s)
- 1 or 2 x USB Charging Cable(s)
- 5 or 10 x Adhesive Hooks (depending on purchase)



Figure 3: Illustration of the typical package contents for the Breezamax AC.

SETUP AND INSTALLATION

The Breezamax AC is designed for easy and versatile placement without the need for tools or complex installation.

1. **Choose Placement:** The unit can stand upright, lay flat, or be wall-mounted. Consider the area you wish to cool and the most effective airflow direction.
2. **Standing Upright or Laying Flat:** Simply place the unit on a stable, flat surface. Ensure the air intake and outlet are not obstructed.
3. **Wall Mounting:** Use the included adhesive hooks. Clean the wall surface thoroughly before applying the hooks to ensure strong adhesion. Once the hooks are securely attached, hang the Breezamax AC unit. No drilling is required.

CAN STAND OR LAY FLAT



Figure 4: The Breezamax AC can be used in both upright and flat orientations.

MULTIPLE SCENE USAGE



Figure 5: Wall mounting is simple with the provided adhesive hooks, requiring no tools.

OPERATING INSTRUCTIONS

The Breezamax AC offers intuitive controls for ease of use.

Powering On/Off

- **Using the Unit Buttons:** Locate the power button on the unit. Press once to turn on, press again to turn off.
- **Using the Remote Control:** Point the remote at the unit and press the power button.

Adjusting Fan Speed

- The Breezamax AC features 3-speed settings. Use the speed control buttons on the unit or remote to cycle through low, medium, and high settings.

Activating Oscillation

- To activate the smart oscillation feature, press the oscillation button on the unit or remote. The unit will swing left to right to cool a wider area. Press again to stop oscillation.

Charging the Unit

- Connect the provided USB charging cable to the unit's USB-C port and a compatible USB power adapter (not included) or a computer USB port.
- The built-in 3000mAh battery provides 3-8 hours of cordless operation, depending on the fan speed setting.



Figure 6: The unit features an upgraded long air outlet for wide-angle cooling and automatic blade swing.

MAINTENANCE

To ensure optimal performance and longevity of your Breezamax AC, follow these simple maintenance guidelines:

- **Cleaning:** Regularly wipe the exterior of the unit with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- **Air Intake/Outlet:** Ensure the air intake and outlet grilles are free from dust and debris. You may use a soft brush or vacuum cleaner with a brush attachment to gently clean these areas.
- **Storage:** If storing the unit for an extended period, ensure it is clean and dry. Store it in a cool, dry place away from direct sunlight.

Caution: Do not immerse the unit in water or any other liquid. Always unplug the unit before cleaning.

TROUBLESHOOTING

If you encounter any issues with your Breezamax AC, please refer to the following common troubleshooting steps:

Problem	Possible Cause	Solution
Unit does not turn on.	No power or low battery.	Ensure the unit is plugged in or fully charged. Check the USB cable connection.
Weak airflow.	Air intake/outlet obstructed or low fan speed.	Clear any obstructions from the grilles. Increase the fan speed setting.
Remote control not working.	Remote battery depleted or obstruction.	Replace the remote control battery. Ensure there is no obstruction between the remote and the unit's sensor.
Unit is noisy.	Unit not on a stable surface or internal issue.	Place the unit on a flat, stable surface. If noise persists, contact customer support.

If the problem persists after attempting these solutions, please contact customer support for further assistance.

SPECIFICATIONS

Feature	Detail
Product Model	DH3Y33
Product Color	White / Blue (as purchased)
Product Weight	0.84 kg (1.9 pounds)
Product Dimensions	328 x 74.8 x 74.1 mm (13 x 3 x 3 inches)
Rated Power	5W
Noise Level	Below 30dB (advertised as 1dB, but 30dB is more realistic for "ultra quiet")
Battery Capacity	3000mAh (built-in)
Battery Life	3-8 hours (cordless)
Power Input	USB-C
Special Features	Remote Controlled, Silent Mode, Fast Cooling, Smart Oscillation
Installation Type	Desktop, Wall-mounted

SAFETY INFORMATION

Your safety is paramount. Please adhere to the following safety guidelines:

- **No Exposed Blades:** The Breezamax AC is designed with no exposed blades, making it safe for homes with children and pets. There is no risk of injury from moving parts.
- **Power Source:** Only use the provided USB charging cable and a compatible power adapter. Do not use damaged cables or adapters.
- **Placement:** Place the unit on a stable, level surface to prevent tipping. Ensure adequate clearance around the air intake and outlet for proper airflow.
- **Water and Moisture:** Do not expose the unit to water or excessive moisture. Do not operate in wet

environments.

- **Disassembly:** Do not attempt to disassemble or repair the unit yourself. Refer all servicing to qualified personnel.
- **Cleaning:** Always unplug the unit before cleaning.

WARRANTY AND SUPPORT

For warranty information, technical support, or any inquiries not covered in this manual, please contact ZAIREG customer service through the retailer where you purchased the product or visit the official ZAIREG website. Please have your product model number (DH3Y33) and purchase date available when contacting support.

© 2025 ZAIREG. All rights reserved.