

Raycon RBO715

Raycon Essential Open Earbuds User Manual

Model: RBO715 | Brand: Raycon

INTRODUCTION

Welcome to the user manual for your Raycon Essential Open Earbuds. These true wireless open-ear Bluetooth headphones are designed for comfort and awareness, allowing you to enjoy high-quality audio while staying connected to your surroundings. Featuring an ultra-lightweight design, comfort hook, IPX5 water resistance, and up to 36 hours of battery life, these earbuds are perfect for an active lifestyle.



Figure 1: Raycon Essential Open Earbuds (Black)

PACKAGE CONTENTS

Please ensure all items are present in your package:

- Raycon Essential Open Earbuds (Left and Right)
- Charging Case
- USB Charging Cable
- User Manual (this document)





Figure 2: Earbuds in Charging Case

KEY FEATURES

Open-Ear Design: Experience crystal-clear sound while staying fully aware of your surroundings. The open-ear design delivers high-quality audio without blocking your environment — perfect for workouts, outdoor runs, or multitasking throughout the day.



OPEN-EAR DESIGN

Buds float over ear canals for a breathable and open fit. Stay present, alert, and comfy all day long.



Figure 3: Open-Ear Design for Environmental Awareness

Featherlight Fit: The Essential Open Earbuds are so lightweight and comfortable, you might forget you're even wearing them. The minimalist, ear-hugging design ensures a secure fit that won't budge during intense movement, all while keeping you stylish and streamlined.



ULTRA LIGHTWEIGHT

Coming in at just 13.3g, experience sound that floats like a feather.



Figure 4: Ultra-Lightweight Design (13.3g)

Built for On-The-Go (IPX5 Water Resistant): Sweat-resistant and made for motion, these wireless earbuds are ideal for gym sessions, cycling, and daily hustle. They're pocket-sized and portable – the perfect essential earbuds that fit into your life with zero bulk. The IPX5 rating means they are resistant to splashes and sweat.



IPX5 WATER RESISTANT

Made to weather any kind of sweat or storm.
Do your worst.



Figure 5: IPX5 Water Resistance

Long Battery Life + Easy Charging: Stay powered through your day with all-day battery life and a sleek charging case that fits in the palm of your hand. Fast charging means less downtime and more freedom to move. Enjoy up to 8 hours of non-stop playback and a total of 36 hours with the charging case.



36 HOURS OF BATTERY

8 hours nonstop + 36 hours total with the case. Stay juiced up and ready to go.

Figure 6: Extended Battery Life

Flexible Ear Hook: The ergonomic ear hook bends to fit the shape of any ear, ensuring a secure and comfortable fit.



FLEXIBLE EAR HOOK

Ergonomic earhook
bends to fit the
shape of any ear.



Figure 7: Flexible Ear Hook Design

Compact Design: Slide in your pocket or toss in your bag. Portable, fun-sized, and ready for any adventure.



COMPACT DESIGN

Slide in your pocket or toss in your bag. Portable, fun-sized, and ready for any adventure.



Figure 8: Compact and Portable Design

Multipoint Connection: Connect to two devices and switch between them seamlessly — without the juggling.



MULTIPOINT CONNECTION

Connect to two devices and switch between them seamlessly — without the juggling.

Figure 9: Multipoint Connection Capability

SETUP GUIDE

1. Charging Your Earbuds

Before first use, fully charge your Raycon Essential Open Earbuds and their charging case.

1. Place both earbuds into the charging case. Ensure they are seated correctly.
2. Connect the provided USB charging cable to the charging port on the case and plug the other end into a USB power source (e.g., wall adapter, computer USB port).
3. The indicator light on the charging case will show charging status. Once fully charged, the light will change or turn off.

Your browser does not support the video tag.

Video 1: Demonstrates charging the earbuds and case, as well as wearing them. This video is provided by the seller and is relevant for setup and operation.

2. Pairing with Your Device

The earbuds will automatically enter pairing mode when taken out of the case for the first time.

1. Open the charging case and remove both earbuds. They will automatically power on and enter pairing mode.
2. On your device (smartphone, tablet, computer), go to Bluetooth settings.
3. Search for "Raycon Essential Open Earbuds" in the list of available devices.
4. Select the earbuds to connect. You will hear an audible confirmation once connected.

For subsequent connections, the earbuds will automatically connect to the last paired device when removed from the case, if Bluetooth is enabled on the device.

OPERATING INSTRUCTIONS

Wearing the Earbuds

Gently loop the ear hook over your ear and position the earbud speaker near your ear canal. Adjust for a comfortable and secure fit.




Figure 10: Proper Wearing of Essential Open Earbuds

Touch Controls

The Essential Open Earbuds feature touch controls for various functions. Please note that the touch controls are sensitive. Refer to the quick start guide or the Raycon app for a full list of touch control functions, as specific actions (e.g., play/pause, skip track, answer call) are typically managed via taps on the earbud surface.

Common Touch Control Functions (Example)

Action	Function
Single Tap	Play/Pause Music, Answer/End Call

Action	Function
Double Tap (Right Earbud)	Next Track
Double Tap (Left Earbud)	Previous Track
Long Press	Activate Voice Assistant

Note: Specific touch control gestures may vary. Consult the official Raycon support resources for the most accurate and up-to-date information.

MAINTENANCE

Cleaning

To maintain optimal performance and hygiene, regularly clean your earbuds and charging case.

- Use a soft, dry, lint-free cloth to wipe the earbuds and charging case.
- For stubborn dirt, slightly dampen the cloth with water. Avoid excessive moisture.
- Do not use abrasive cleaners, solvents, or aerosol sprays.
- Ensure the charging contacts on both the earbuds and the case are clean and dry before charging.

Storage

When not in use, store your earbuds in their charging case to protect them and keep them charged.

- Store in a cool, dry place, away from extreme temperatures and direct sunlight.
- Avoid storing in humid environments.

Battery Care

To prolong battery life:

- Avoid fully draining the battery frequently.
- Charge the earbuds regularly, even if not used for extended periods.
- Use only the provided charging cable or a certified equivalent.

TROUBLESHOOTING

If you encounter issues with your Raycon Essential Open Earbuds, try the following solutions:

Problem	Possible Solution
Earbuds won't turn on.	Ensure the earbuds and charging case are fully charged. Place earbuds in the case, close it, then open it again.

Problem	Possible Solution
Earbuds won't pair with device.	<ul style="list-style-type: none"> Make sure Bluetooth is enabled on your device. Ensure earbuds are in pairing mode (indicator lights flashing). Forget the device from your phone's Bluetooth list and try pairing again. Move earbuds closer to your device. Turn off and on your device's Bluetooth.
Sound breaks up or is intermittent.	<ul style="list-style-type: none"> Ensure there are no obstructions between the earbuds and your device. Move closer to your device. Avoid environments with strong Wi-Fi or other wireless interference. Disconnect from other Bluetooth devices if using multipoint connection.
Touch controls are too sensitive or unresponsive.	<ul style="list-style-type: none"> Ensure your fingers are clean and dry when using touch controls. Try a different tapping pressure or duration. Check for firmware updates via the Raycon app, if available.
One earbud has no sound.	<ul style="list-style-type: none"> Place both earbuds back in the charging case, close the lid, wait a few seconds, then remove them. Ensure both earbuds are charged. Try re-pairing the earbuds with your device.

SPECIFICATIONS

Feature	Detail
Model Name	Raycon Essential Open Earbuds
Model Number	RBO715
Connectivity Technology	Wireless (Bluetooth 6.0)
Ear Placement	Open Ear
Form Factor	Over Ear (with hook design)
Control Type	Touch Control
Water Resistance Level	IPX5 (Water Resistant)
Battery Life (Earbuds)	Up to 8 hours
Total Battery Life (with Case)	Up to 36 hours

Feature	Detail
Item Weight	5 ounces (earbuds + case)
Earbud Weight	Approx. 13.3g per earbud
Manufacturer	Raycon Global
ASIN	B0FHJ7G4WF
UPC	811162032989

WARRANTY AND SUPPORT

Warranty Information

Raycon products typically come with a limited manufacturer's warranty. Please refer to the official Raycon website or the warranty card included with your product for specific terms, conditions, and duration of the warranty.

Customer Support

For further assistance, technical support, or warranty claims, please contact Raycon customer support:


- **Website:** Visit the official Raycon website for FAQs, support articles, and contact options.
(www.rayconglobal.com)
- **Email/Phone:** Specific contact details can usually be found on the support section of their website.

Please have your product model number (RBO715) and purchase information ready when contacting support.

© 2025 Raycon Global. All rights reserved.

This manual is for informational purposes only. Specifications are subject to change without notice.

Documents - Raycon – RBO715



[Raycon Essential Open Earbuds User Guide](#)

Comprehensive user guide for Raycon Essential Open Earbuds, covering setup, features like Multipoint, troubleshooting, safety, and specifications.

lang:en score:43 filesize: 2.76 M page_count: 15 document date: 2025-07-17



[Raycon Essential Open Earbuds Quick Start Guide](#)

Concise guide to setting up and using Raycon Essential Open Earbuds, covering pairing, functions, sound profiles, and safety information.

lang:en score:28 filesize: 1.08 M page_count: 8 document date: 2025-08-22