

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [GloryAir](#) /

> [GloryAir HQ-JS2316R 9L Warm & Cool Mist Humidifier Instruction Manual](#)

GloryAir HQ-JS2316R

GloryAir HQ-JS2316R 9L Warm & Cool Mist Humidifier

Instruction Manual

1. INTRODUCTION

Thank you for choosing the GloryAir HQ-JS2316R 9L Warm & Cool Mist Humidifier. This manual provides essential information for safe operation, effective use, and proper maintenance of your new humidifier. Please read it thoroughly before use and retain it for future reference.

2. PACKAGE CONTENTS

Verify that all items are present in the package:

- 1 x GloryAir 9L Humidifier Unit
- 1 x User Manual
- 1 x Remote Control
- 1 x Cleaning Brush
- 1 x Extension Tube
- 1 x Mist Outlet

Safe for Kids, Convenient to Control



Figure 1: Humidifier package contents including the main unit, remote, extension tube, and manual.

3. SPECIFICATIONS

Brand	GloryAir
Model Name	HQ-JS2316R
Operation Mode	Ultrasonic
Water Tank Capacity	9 Liters (2.38 Gallons)
Max Coverage Area	750 Square Feet
Max Warm Mist Output	450 mL/h
Warm Mist Temperature	113°F - 131°F
Max Runtime	60 Hours (on lowest cool mist setting)
Noise Level	≤ 35dB
Power	170 Watts

Voltage	120 Volts (AC)
Product Dimensions	9.25"D x 9.25"W x 26.18"H
Item Weight	6.42 Pounds

4. SETUP

4.1 Unpacking and Placement

- Carefully remove all components from the packaging.
- Place the humidifier on a flat, stable, and water-resistant surface. Ensure it is at least 6 inches (15 cm) away from walls and furniture.
- Avoid placing the humidifier directly on carpet or near heat sources.

4.2 Assembling the Mist Outlet

- Choose between the standard mist outlet or the 18-inch extension tube for higher mist dispersion.
- Align the chosen mist outlet with the opening on the top of the humidifier and firmly press it into place. The 360° adjustable nozzle allows you to direct the mist as desired.

4.3 Filling the Water Tank

- Open the top cover of the humidifier.
- Pour clean, cool tap water directly into the water tank. Do not exceed the 'MAX' fill line indicated on the unit.
- Close the top cover securely.



Figure 2: Humidifier in operation, showing mist output.

5. OPERATING INSTRUCTIONS

5.1 Power On/Off

- Plug the power cord into a standard electrical outlet.
- Press the 'ON/OFF' button on the touch panel or remote control to turn the humidifier on or off.

5.2 Mist Mode Selection (Warm/Cool Mist)

- Press the 'MIST' button to cycle through low, medium, and high cool mist levels.
- Press the 'WARM MIST' button to activate the warm mist function. The warm mist temperature ranges from 113°F to 131°F.

Efficient Whole-house Warm Mist

With a temperature of **113°F - 131°F**



Figure 3: Efficient whole-house warm mist feature.

5.3 Smart Humidity Control

- Press the 'HUMIDITY' button to set your desired humidity level between 45% and 95%.
- The humidifier will automatically adjust its output to maintain the target humidity and shut off when the level is reached.

GloryAir | HQ-JS2316R

Package List



Figure 4: Smart humidity control with adjustable levels.

5.4 Timer Function

- Press the 'TIMER' button to set an operating duration from 1 to 24 hours. The humidifier will automatically turn off after the set time.

5.5 Sleep Mode

- Press the 'SLEEP' button to activate Sleep Mode. All display lights will turn off for undisturbed rest, while the humidifier continues to operate quietly ($\leq 35\text{dB}$).



Figure 5: Sleep mode for quiet, undisturbed operation.

5.6 7-Color Mood Lighting

- Press the 'COLOR LIGHT' button to cycle through 7 different mood lighting colors.

5.7 Aroma Diffuser Function

- Locate the dedicated aromatherapy tray on the side of the unit.
- Add 3-5 drops of your preferred essential oil to the tray.
- **Important:** Do not add essential oils directly into the water tank, as this may damage the unit and void the warranty.

5.8 Child Lock

- Press the 'CHILD LOCK' button to prevent accidental changes to settings, ensuring safe operation around children.



Figure 6: Child Lock feature for enhanced safety.

5.9 Remote Control

- The included remote control allows you to adjust all settings from a distance of 10-20 feet.

6. MAINTENANCE

6.1 Daily Maintenance

- Empty and rinse the water tank daily.
- Refill with fresh, cool water.

6.2 Weekly Cleaning

- Unplug the humidifier before cleaning.
- Remove the base chamber from the main water tank and empty all water.
- Prepare a 1:5 vinegar solution (1 part white vinegar to 5 parts water).
- Fill the tank and base with the solution and soak tubing & parts for 20 minutes.
- Use the provided cleaning brush and a soft cloth to wipe all parts.
- Rinse thoroughly with clean water until the vinegar smell is gone.
- Allow all parts to air dry completely before reassembling.



Figure 7: Step-by-step cleaning guide for the humidifier.

7. SAFETY PRECAUTIONS

- DO NOT fill past the MAX line.
- DO NOT drop essential oil directly into the sink or water tank. Use the dedicated aromatherapy tray only.
- DO NOT add water directly into the mist tube or base chamber.
- DO NOT place the humidifier tilted; ensure it is on a flat, stable surface.
- Always unplug the unit before moving or cleaning.
- The humidifier features auto shut-off when empty and dry burn protection for safety.



Figure 8: Important safety warnings for humidifier use.

8. TROUBLESHOOTING

If you encounter any issues, please refer to the following common problems and solutions:

- **No Mist Output:** Check if the water tank is empty. Ensure the unit is properly assembled and plugged in. Clean the transducer if mineral buildup is present.
- **Unusual Odor:** Empty and clean the water tank and base thoroughly. Refill with fresh water.
- **Excessive Noise:** Ensure the unit is on a flat, stable surface. Check if the water level is too low.
- **White Dust:** This is common with hard water. Use distilled or demineralized water to reduce mineral buildup. Clean the unit regularly.

For further assistance, please contact GloryAir customer support.

9. WARRANTY AND SUPPORT

The GloryAir HQ-JS2316R Humidifier is backed by a **1-year warranty** from the date of purchase. This warranty covers manufacturing defects and workmanship under normal use. Please retain your proof of purchase for warranty claims. For technical support, warranty claims, or any questions regarding your product, please contact GloryAir customer service through the retailer where the product was purchased or visit the official GloryAir website.

10. OFFICIAL PRODUCT VIDEOS

GloryAir 9L Cool & Warm Humidifiers for Bedroom

Your browser does not support the video tag.

This video provides an overview of the GloryAir 9L Cool & Warm Humidifier, showcasing its features and benefits for bedroom use.

GloryAir 9L Cool & Warm Mist Humidifier for Large Room Home

Your browser does not support the video tag.

A detailed video demonstrating the GloryAir 9L Humidifier's performance and suitability for large rooms and home environments.