



Manuals.plus /

› Devoko /

› Devoko Dressing Table with LED Mirror (Model 0501) - Instruction Manual

## Devoko 0501

# Devoko Dressing Table with LED Mirror (Model 0501) - Instruction Manual

Comprehensive guide for assembly, operation, and maintenance.

## INTRODUCTION

Thank you for purchasing the Devoko Dressing Table with LED Mirror, Model 0501. This manual provides detailed instructions for the safe assembly, operation, and maintenance of your new dressing table. Please read this manual thoroughly before beginning assembly and retain it for future reference.

## SAFETY INFORMATION

- Always assemble the product on a soft, clean surface to prevent scratches.
- Ensure all parts are present and undamaged before assembly. Do not proceed with assembly if any parts are missing or damaged.
- Keep small parts and packaging materials away from children and pets to prevent choking hazards.
- Tighten all screws and fasteners securely, but do not overtighten.
- Do not stand or sit on the dressing table.
- Use only the provided hardware for assembly.
- If using an electric screwdriver, set it to a low torque to avoid damaging the wood.
- The LED mirror is an electrical component. Do not expose it to water or excessive moisture. Disconnect from power before cleaning.

## PACKAGE CONTENTS

Please verify that all components listed below are included in your package. Refer to the included parts list in your physical manual for specific part numbers and quantities.

- Dressing Table Panels (Desktop, Side Panels, Drawer Components, Shelves)

- LED Mirror Unit
- Assembly Hardware (Screws, dowels, cam locks, etc.)
- Instruction Manual

**Tools Recommended (Not Included):** Phillips head screwdriver, Electric screwdriver (low torque setting recommended).

## SETUP AND ASSEMBLY

---

Follow the step-by-step instructions provided in the physical manual. All parts are numbered for easy identification. It is recommended to have two people for assembly.

### General Assembly Steps:

1. **Unpack and Identify Parts:** Carefully unpack all components and lay them out on a protected surface. Match each part to the corresponding number in the parts list.
2. **Assemble Base Structure:** Begin by connecting the main desktop panel to the side support panels using the provided hardware.
3. **Install Drawers:** Assemble the drawer boxes and install the drawer slides onto the table frame and drawers. Insert the assembled drawers into their respective slots.
4. **Attach Shelving Units:** Secure the upper and lower shelving units to the main structure as indicated in the manual. Note that the side storage cabinet can be installed on either the left or right side.
5. **Mount LED Mirror:** Carefully attach the LED mirror unit to the designated area on the desktop or back panel. Ensure all electrical connections are secure.
6. **Final Tightening:** Once all components are assembled, gently tighten all screws and fasteners to ensure stability. Do not overtighten.



*Image 1: Fully assembled Devoko Dressing Table with LED Mirror. This image shows the overall design, including the mirror, drawers, and shelves.*



**Adjustable Brightness**

**Open Shelves**

**2 Large Drawers**

**108\*40cm Large Desktop**

**Side Storage Cabinet**

Image 2: Overview of the Devoko Dressing Table highlighting key features such as adjustable brightness, open shelves, two large drawers, a 108x40cm desktop, and a side storage cabinet.

# ◦ SIDE STORAGE CABINET

Under table side shelf can be mounted on the left or right side



Image 3: Illustration of the flexible installation for the side storage cabinet, which can be mounted on either the left or right side of the table.

## OPERATING INSTRUCTIONS

### LED Mirror Operation:

The integrated LED mirror features adjustable lighting with three color modes and brightness control.

- **Power On/Off:** Locate the touch switch on the mirror surface. Tap once to turn the LED lights on or off.
- **Change Light Color:** With the lights on, tap the touch switch repeatedly to cycle through the three light color modes: Cold White, Warm White, and Warm Yellow.
- **Adjust Brightness:** To adjust the brightness, press and hold the touch switch. The brightness will gradually increase or decrease. Release the switch when the desired brightness level is reached.



Image 4: Visual representation of the three distinct lighting effects available on the LED mirror: Cold White, Warm White, and Warm Yellow. The image also indicates that brightness can be adjusted by long-pressing the switch.

### Storage Features:

The dressing table is equipped with various storage options to organize your items.

- **Drawers:** Utilize the two large drawers for storing cosmetics, accessories, or personal items.
- **Open Shelves:** The four open shelves provide easy access and display space for frequently used items or decorative pieces.
- **Side Storage Cabinet:** The integrated side storage offers additional space for taller items or magazines.

### MAINTENANCE

- **Cleaning the Surface:** Wipe the table surfaces with a damp cloth, then immediately dry with a clean, dry cloth. Avoid abrasive cleaners or harsh chemicals that may damage the finish.
- **Cleaning the Mirror:** Use a soft, lint-free cloth and a glass cleaner specifically designed for mirrors. Do not spray

cleaner directly onto the mirror; instead, apply it to the cloth first. Ensure the mirror is disconnected from power before cleaning.

- **Hardware Check:** Periodically check all screws and fasteners to ensure they remain tight. Retighten if necessary to maintain stability.
- **Avoid Direct Sunlight:** Prolonged exposure to direct sunlight may cause fading or damage to the finish.
- **Avoid Excessive Moisture:** Keep the dressing table away from areas with high humidity or direct water exposure.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
LED Mirror does not turn on.	Power cable not connected or loose. Power outlet not functioning. Touch switch malfunction.	Ensure the power cable is securely plugged into both the mirror and a working electrical outlet. Test the outlet with another device. Contact customer support if the issue persists after checking power.
Table feels unstable or wobbly.	Screws or fasteners are loose. Uneven floor surface.	Check and tighten all assembly hardware. Place shims under the table legs if the floor is uneven.
Drawers do not slide smoothly.	Drawer slides are misaligned. Obstruction in the drawer track.	Recheck drawer slide installation according to the assembly manual. Ensure no items are blocking the tracks.

## SPECIFICATIONS

Feature	Detail
Model Number	0501
Brand	Devoko
Product Dimensions (Overall)	15.75"D x 42.52"W x 53.54"H (40cm D x 108cm W x 136cm H)
Desktop Dimensions	Approximately 108cm x 40cm
Mirror Dimensions	60cm x 45cm (LED integrated)
Item Weight	62.5 pounds (approx. 28.35 kg)
Material	Engineered Wood, Glass
Color	White
Assembly Required	Yes
LED Light Features	3 Color Modes (Cold White, Warm White, Warm Yellow), Adjustable Brightness



Image 5: Detailed diagram illustrating the product dimensions in centimeters, including the mirror, desktop, drawers, and side storage.

## WARRANTY AND CUSTOMER SUPPORT

For warranty information, please refer to the documentation included with your purchase or contact Devoko customer support directly. If you encounter any issues or have questions regarding your Devoko Dressing Table, please reach out to our customer service team for assistance.

**Contact Information:** Please visit the official Devoko website or refer to your purchase receipt for the most current customer support contact details.

