

[manuals.plus](#) /› [NARVI](#) /› [NARVI BARI 1719 WDN+WH Ceiling Fan with Retractable Blades and LED Light User Manual](#)

NARVI BARI 1719 WDN+WH

NARVI BARI 1719 WDN+WH Ceiling Fan User Manual

Model: BARI 1719 WDN+WH

1. INTRODUCTION

Thank you for choosing the NARVI BARI 1719 WDN+WH Ceiling Fan. This modern and functional ceiling fan is designed to provide both efficient air circulation and adjustable lighting for your space. Featuring a quiet DC motor, three retractable blades, and an integrated LED light with adjustable intensity and color temperature, it offers comfort and versatility year-round. The fan also includes Bluetooth connectivity and a remote control for convenient operation.

Please read this manual carefully before installation and use to ensure proper operation and safety.

Image 1: The NARVI BARI 1719 WDN+WH ceiling fan in a contemporary living space.

2. SAFETY WARNINGS

To ensure safe operation and prevent damage, please observe the following safety instructions:

Image 2: Original safety warnings document.

2.1. Electrical Installation

- Before any intervention, always disconnect the power supply from the main circuit breaker.
- Installation must only be performed by a qualified and authorized electrician.
- Verify that the ceiling structure and support can safely bear the total weight of the fan.
- Do not install the fan in humid areas or locations where there is a risk of contact with water.

2.2. Safe Use

- Keep the area around the fan clear of children, pets, and any objects.

- The blades deploy automatically; ensure the surrounding space is unobstructed.
- Do not touch the blades while they are in motion or during the retraction process.
- Do not manually force or manipulate the retractable blade system.

2.3. LED Light

- Do not look directly at the LED light when it is illuminated.
- Do not attempt to replace the LEDs if they are not designed to be user-removable.
- Always use original and manufacturer-approved components for any replacements.

2.4. Maintenance and Cleaning

- Clean the fan exclusively with a dry or slightly damp cloth.
- Avoid using abrasive products, harsh chemicals, or solvents.
- Periodically inspect all screws and moving parts; tighten them if necessary.
- If you detect abnormal noises or irregular operation, immediately turn off the fan and contact technical service.

Final Note:

Compliance with these warnings ensures safe, durable, and efficient operation of the fan. The manufacturer is not responsible for damages caused by improper use or installations performed by unqualified personnel.

3. INSTALLATION

Professional installation by a qualified electrician is highly recommended to ensure safety and proper functionality. Before beginning installation, ensure all components are present and undamaged.

3.1. Pre-Installation Checks

- Ensure the power supply to the installation area is disconnected.
- Verify that the ceiling can support the fan's weight (7.2 kg).
- Unpack all components and check against the packing list (not provided in this manual, refer to product packaging).

3.2. Dimensions and Mounting

The fan comes with two downrods (stems) allowing for adjustable height: 20 cm or 10 cm. Choose the appropriate downrod for your ceiling height and desired fan position.

Image 3: Dimensional overview of the NARVI BARI 1719 WDN+WH ceiling fan.

- **Diameter (Open):** 107 cm
- **Diameter (Closed):** 50 cm
- **Height (with 20cm downrod):** 37 cm
- **Height (with 10cm downrod):** 27 cm
- **Canopy Diameter:** 15 cm

Follow the detailed instructions provided in the separate installation guide (if included with your product) for mounting the bracket, assembling the fan, and wiring the electrical connections.

4. OPERATION

The NARVI BARI 1719 WDN+WH ceiling fan is operated via the included remote control and features Bluetooth connectivity for additional control options.

4.1. Remote Control Functions

The remote control allows you to manage all fan and light functions:

- **Power On/Off:** Turns the fan and light on or off.
- **Fan Speed:** Adjusts between 6 fan speeds.
- **Light On/Off:** Controls the LED light independently.
- **Light Intensity (Dimming):** Adjusts the brightness of the LED light.
- **Color Temperature:** Cycles through 3000K (warm white), 4200K (neutral white), and 6500K (cool white). The fan features a memory function that retains the last selected color temperature.
- **Winter/Summer Mode:** Reverses the fan direction for optimal air circulation in different seasons. Summer mode creates a downdraft for cooling, while winter mode creates an updraft to redistribute warm air.
- **Timer:** Sets the fan to turn off automatically after 2, 4, or 8 hours.
- **Bluetooth:** Activates or deactivates the Bluetooth audio function.

4.2. Bluetooth Connectivity

To connect your device via Bluetooth:

1. Ensure the fan's Bluetooth function is active (refer to remote control instructions).
2. On your smartphone or other Bluetooth-enabled device, search for available Bluetooth devices.
3. Select the fan's Bluetooth name (usually 'NARVI' or similar) from the list.
4. Once paired, you can play audio through the fan's integrated speaker.

5. MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your NARVI ceiling fan.

5.1. Cleaning

- Always turn off the power supply to the fan before cleaning.
- Clean the fan housing and blades with a soft, dry, or slightly damp cloth.
- Do not use abrasive cleaners, chemical solvents, or harsh detergents, as these can damage the finish and components.

5.2. Inspection

- Periodically check all mounting screws and connections to ensure they are secure. Tighten any loose screws.
- Inspect the retractable blade mechanism for any obstructions or signs of wear.

6. TROUBLESHOOTING

If you encounter any issues with your fan, please refer to the following common troubleshooting steps:

- **Fan does not turn on:** Check the main power supply and ensure the circuit breaker is on. Verify all electrical connections are secure.
- **Light does not work:** Ensure the light function is activated via the remote control. If the LED is integrated and not user-replaceable, contact technical service.
- **Abnormal noises or wobbling:** Turn off the fan immediately. Check all mounting screws and ensure the fan is securely attached to the ceiling. Ensure blades are clean and free of obstructions.
- **Remote control not working:** Check the batteries in the remote control and replace them if necessary. Ensure there are no obstructions between the remote and the fan's receiver.
- **Bluetooth connection issues:** Ensure the fan's Bluetooth is active and your device is within range. Try unpairing and re-pairing the device.

If problems persist after attempting these steps, please contact NARVI customer support or a qualified technician.

7. SPECIFICATIONS

Feature	Specification
Brand	NARVI
Model	BARI 1719 WDN+WH
Manufacturer	NARVI
Product Dimensions	39 x 39 x 39 cm (packaged); 107 cm (open diameter)
Style	Modern
Color	White and Beech Wood Color
Material	Polycarbonate
Product Weight	7.2 kg (packaged); 5.9 kg (net)
Motor Type	DC Motor (30W)
LED Light Power	45W x 2
Color Temperature	3000K-4200K-6500K (Adjustable)
Luminous Flux	6,480 lumens
Light Life Expectancy	30,000 hours
Blades	3 Retractable, Transparent

Feature	Specification
Speeds	6 Adjustable Speeds
Features	Bluetooth, Remote Control, Dimmable LED, Color Memory, Winter/Summer Mode, Timer (2, 4, 8 hours)
Voltage	180-245V
Country of Origin	China

8. WARRANTY AND SUPPORT

The NARVI BARI 1719 WDN+WH Ceiling Fan comes with a **3-year warranty** from the date of purchase, covering manufacturing defects.

For warranty claims, technical support, or any questions regarding your product, please contact your retailer or NARVI customer service. Please have your proof of purchase and product model number (BARI 1719 WDN+WH) ready when contacting support.

© 2026 NARVI. All rights reserved.