STRICH SKT-02 & SPB-M50

STRICH SKT-02 Keyboard Stand & SPB-M50 Piano Bench Instruction Manual

Models: SKT-02 (Keyboard Stand) & SPB-M50 (Piano Bench)

1. PRODUCT OVERVIEW

This manual provides essential instructions for the assembly, operation, and maintenance of your STRICH SKT-02 Z-style keyboard stand and SPB-M50 adjustable piano bench. Designed for versatility and stability, this set accommodates 54-88 key digital pianos and offers adjustable comfort for various users.

Image: The complete STRICH SKT-02 keyboard stand and SPB-M50 piano bench set, ready for use.

Key Features:

- **Adjustable Versatility:** The SKT-02 Z keyboard stand is fully adjustable in both height and width, accommodating a variety of digital pianos, keyboards, synthesizers, mixers, and MIDI keyboards from 54 to 88 keys. The SPB-M50 adjustable piano bench can be set from 46 cm to 54 cm, with four height levels, ensuring the perfect fit for different postures, heights, and instrument setups.

- **Premium Materials:** The keyboard stand is made of durable metal, resistant to deformation and capable of supporting

heavy loads. The Z-frame structure provides greater stability and load-bearing capacity compared to traditional stands. The piano bench is crafted from robust metal with a cushioned seat featuring high-quality soft padding and PU leather, ensuring stability, comfort, and durability for prolonged use.

- **Stable Fixation:** The keyboard stand includes adjustable supports, anti-slip rubber feet, and two secure straps that fasten your keyboard to the stand, preventing unwanted movement or tipping. It also features a headphone hook for added convenience. The piano bench is equipped with rubber feet to enhance stability and prevent slipping.
- **Easy Assembly & Disassembly:** Both the keyboard stand and piano bench are designed for quick assembly and disassembly with simple structures, complete with an instruction manual for easy setup, making them perfect for musicians on the go.
- **Portable & Lightweight:** The lightweight design of the piano bench and keyboard stand makes them easy to transport and set up in various environments, whether at home, in a studio, or on stage. The adjustable features ensure they can be tailored to different spaces and performance settings, offering maximum flexibility.

2. SAFETY INFORMATION

Please read and understand all safety warnings and instructions before assembling and using this product. Failure to follow these instructions may result in injury or damage to the product.

- **Weight Capacity:** Do not exceed the maximum weight recommendation of 200 pounds for the keyboard stand and 270 pounds for the piano bench. Overloading can cause instability and product failure.
- **Proper Assembly:** Always assemble the product according to the instruction manual. Ensure all screws, knobs, and fasteners are securely tightened before use.
- **Stable Surface:** Place the stand and bench on a flat, stable, and level surface to prevent tipping.
- **Children and Pets:** Keep children and pets away from the product during assembly. Small parts may pose a choking hazard.
- **Regular Inspection:** Periodically check all components for wear, damage, or loose connections. Discontinue use if any damage is found and contact customer support.
- **Avoid Pinch Points:** Be mindful of moving parts during adjustment to avoid pinching fingers or other body parts.

3. PACKAGE CONTENTS

Please verify that all components are present before beginning assembly. If any parts are missing or damaged, contact customer support.

SKT-02 Keyboard Stand Components:

- Left Z-frame leg assembly (1)
- Right Z-frame leg assembly (1)
- Horizontal support bar (1)
- Adjustable keyboard support arms (2)
- Locking knobs for height/width adjustment (multiple)
- Anti-slip rubber feet (4) or optional caster wheels (4)
- Keyboard securing straps (2)
- Headphone hook (1)
- Assembly tool (Allen wrench)

SPB-M50 Piano Bench Components:

- Bench seat with padding (1)
- Bench leg frames (2)
- Horizontal support bar (1)

- Adjustable height knobs (2)
- Assembly screws and tool

Image: Detailed product dimensions for both the keyboard stand and piano bench.

4. ASSEMBLY INSTRUCTIONS

4.1. SKT-02 Keyboard Stand Assembly

1. **Attach Feet/Wheels:** Decide whether to use the anti-slip rubber feet or the caster wheels. Screw them into the bottom of the Z-frame leg assemblies.

2. **Connect Z-frames:** Insert the horizontal support bar into the designated slots on both Z-frame leg assemblies. Secure with the central locking knob.

3. **Adjust Height and Width:** Loosen the side locking knobs on the Z-frames to adjust the height. Loosen the central locking knob to adjust the width. Tighten all knobs once desired dimensions are achieved.

4. **Install Keyboard Support Arms:** Attach the two adjustable keyboard support arms to the top of the Z-frames. Ensure they are securely fastened.

5. **Attach Securing Straps:** Thread the keyboard securing straps through the holes on the support arms and fasten them. These will hold your keyboard in place.

6. **Install Headphone Hook:** Attach the headphone hook to one of the Z-frame legs for convenient storage.

Your browser does not support the video tag.

Video: Assembly guide for the STRICH SKT-02 Piano Keyboard Stand, demonstrating step-by-step setup and adjustments.

Your browser does not support the video tag.

Video: Detailed assembly and feature overview of the STRICH Z-shape Piano Stand, highlighting its stability and adjustability.

4.2. SPB-M50 Piano Bench Assembly

1. **Attach Leg Frames:** Connect the two bench leg frames using the horizontal support bar. Secure with the provided screws and Allen wrench.

2. **Attach Seat:** Place the cushioned bench seat onto the assembled leg frame, aligning the screw holes. Secure the seat to the frame using the provided screws.

3. **Adjust Height:** Loosen the adjustable height knobs on the side of the bench legs. Raise or lower the seat to the desired height (four levels available) and tighten the knobs securely.

Your browser does not support the video tag.

Video: Assembly instructions for the STRICH Piano Bench SPB-M50, showing how to put together and adjust the bench.

Your browser does not support the video tag.

Video: Overview of the STRICH H-shape Piano Chair, demonstrating its features and adjustable height settings.

5. OPERATING INSTRUCTIONS

5.1. Adjusting the Keyboard Stand (SKT-02)

- **Height Adjustment:** Loosen the two large knobs on the side of each Z-frame leg. Carefully raise or lower the top support arms to the desired height. Ensure both sides are adjusted evenly. Tighten the knobs firmly to secure the height.

- **Width Adjustment:** Loosen the central knob on the horizontal support bar. Slide the Z-frames inward or outward to match the width of your keyboard. Ensure the keyboard rests securely on the support arms. Tighten the central knob firmly.

- **Securing the Keyboard:** Once the keyboard is placed on the stand, use the provided straps to secure it to the support arms. This prevents accidental movement or falling.

Image: The keyboard stand and bench showing various adjustment points for height and width.

5.2. Adjusting the Piano Bench (SPB-M50)

- **Height Adjustment:** Locate the two adjustable height knobs on the side of the bench legs. Loosen both knobs. Carefully raise or lower the bench seat to one of the four available height levels. Ensure both sides are adjusted to the same level. Tighten the knobs firmly to secure the bench height.

6. MAINTENANCE

Proper maintenance ensures the longevity and safe operation of your STRICH keyboard stand and piano bench.

- **Cleaning:** Wipe down metal surfaces with a soft, damp cloth. For the PU leather seat, use a mild soap solution and a soft cloth, then wipe dry. Avoid abrasive cleaners or solvents.
- **Inspection:** Periodically check all screws, bolts, and adjustment knobs to ensure they are tight. Re-tighten if necessary. Inspect the rubber feet or caster wheels for wear and tear.
- **Storage:** When not in use for extended periods, store the stand and bench in a dry, cool place away from direct sunlight and extreme temperatures. The set can be disassembled for compact storage.

7. TROUBLESHOOTING

If you encounter any issues, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Stand/Bench is wobbly	Loose fasteners; uneven surface	Ensure all screws and knobs are tightened. Move to a flat, level surface. Adjust individual feet if applicable.
Difficulty adjusting height/width	Knobs too tight; mechanism stuck	Loosen knobs completely before attempting adjustment. Apply a small amount of silicone lubricant if mechanism is stiff.
Keyboard slides on stand	Keyboard not secured; anti-slip pads missing/worn	Use the provided securing straps. Check if anti-slip pads are present and in good condition.

If the problem persists, please contact STRICH customer support for further assistance.

8. SPECIFICATIONS

Detailed specifications for the STRICH SKT-02 Keyboard Stand and SPB-M50 Piano Bench.

Feature	Detail
Product Dimensions	15.9"D x 22.1"W x 23.2"H (Overall)
Color	Black
Furniture Finish	Metal
Brand	STRICH
Maximum Weight Recommendation (Stand)	200 Pounds
Maximum Weight Recommendation (Bench)	270 Pounds
Manufacturer	STRICH
Item Weight	25.9 pounds (Combined)
Item Model Number	SKT-02 & SPB-M50
Material	Metal
Frame Material	Metal
Style	Modern

9. Warranty and Support

STRICH products are manufactured with quality and durability in mind. For specific warranty information, please refer to the product packaging or contact STRICH customer support directly.

If you require assistance with assembly, operation, or troubleshooting, please visit the official STRICH website or contact our customer service team. Have your model number (SKT-02 & SPB-M50) and purchase date ready when contacting support.