

[Manuals.plus](#) /

› [HUANLEGO](#) /

› HUANLEGO Shoe Cabinet Storage for Entryway (Model HLG088, Grey 2 Drawer) - Instruction Manual

HUANLEGO HLG088

HUANLEGO Shoe Cabinet Storage for Entryway (Model HLG088, Grey 2 Drawer) - Instruction Manual

Model: HLG088

INTRODUCTION

Thank you for purchasing the HUANLEGO Grey 2-Drawer Fluted Shoe Cabinet. This manual provides essential information for the correct assembly, safe operation, and proper maintenance of your new shoe storage unit. Please read these instructions thoroughly before beginning assembly and retain them for future reference.



A full view of the assembled HUANLEGO Grey 2-Drawer Fluted Shoe Cabinet.

SAFETY INFORMATION

Important: Always secure the cabinet to the wall using the anti-tipping devices provided. This prevents accidental tipping or shaking, ensuring the safety of your household, especially children and pets. Do not attempt to move the cabinet when it is fully loaded. Always follow the assembly instructions carefully to ensure safety and stability.



Anti-Toppling Device

Ensure Your Family's Safety

Close-up of the anti-tipping device securely attached to the wall and the top of the shoe cabinet, ensuring stability.

SETUP

The shoe cabinet comes with detailed instructions and all necessary hardware. For optimal assembly and safety, it is recommended to have two people for the assembly process.

Unpacking


- Carefully open the packaging and remove all components.
- Verify that all parts listed in the included hardware kit and parts list are present and undamaged.
- Place all components on a soft, clean surface to prevent scratches during assembly.

Assembly

- Refer to the step-by-step assembly instructions provided in the package. Each component has an assembly number label for easy identification.

- Ensure all screws and fasteners are tightened securely, but do not overtighten.
- Install the anti-tipping device as instructed in the safety section to anchor the cabinet to the wall.

PRODUCT SIZE



Detailed diagram showing the dimensions of the shoe cabinet, including overall height, width, depth, and internal drawer measurements.

OPERATING INSTRUCTIONS

Using the Flip Drawers

The shoe cabinet features two fluted flip drawers. To open a drawer, gently pull the handle outwards. The drawer will tilt forward, revealing the shoe compartments. To close, push the drawer back into the cabinet until it is flush with the cabinet front.

Adjusting Shelves

Each flip drawer contains an adjustable shelf. You can remove or adjust the position of these shelves to accommodate various shoe sizes and styles, including low boots, high heels, and flats. Simply lift the shelf and reposition it into the

desired slots or remove it entirely for taller items.

Adjustable Position Panel



Illustration demonstrating how to adjust or remove the internal shelf within a flip drawer to accommodate different shoe heights, such as boots or high heels.




Waterproof Desktop

Additional storage space on top surface for keys, wallets, and decorative items

Fluted Flip Drawer

Fluted design adds unique texture and visual interest that elevates the appearance for your home



Metal Handles

Classic L-shaped handle enhance both durability and functionality



Shoe Bench

Practical shoe bench can withstand daily use while maintaining their appearance over time



A collage highlighting various features: a waterproof top surface, the distinctive fluted drawer design, durable metal handles, and the integrated shoe bench area.

MAINTENANCE

Proper care will extend the life and appearance of your shoe cabinet.

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners, as these can damage the engineered wood finish.
- **Spills:** Immediately wipe up any spills to prevent moisture damage.
- **Dusting:** Regularly dust with a dry, soft cloth.
- **Ventilation:** The ventilated back design helps prevent odor buildup. Ensure the cabinet is not placed in an area with excessive humidity.

TROUBLESHOOTING

If you encounter any issues with your shoe cabinet, refer to the following common problems and solutions:

Problem	Possible Solution
Drawers do not close smoothly.	Check for obstructions inside the drawer. Ensure all assembly screws are properly tightened. Verify that shoes are not overfilling the compartments.
Cabinet feels unstable.	Ensure the anti-tipping device is correctly installed and securely anchored to the wall. Check that the cabinet is on a level surface.
Missing parts during assembly.	Double-check all packaging materials. Contact customer support with your purchase details and the specific missing part number.

SPECIFICATIONS

Feature	Detail
Brand	HUANLEGO
Model Number	HLG088
Color	Grey
Material	Engineered Wood
Product Dimensions (D x W x H)	9.4"D x 29.9"W x 40"H
Item Weight	44 pounds
Number of Drawers	2 (Flip Drawers)
Number of Shelves	2 (Adjustable within drawers)
Mounting Type	Wall Mount (Anti-tipping device included)
Style Name	Mid-Century Modern
Additional Features	Anti-Tipping, Removable Shelf, Space Saving, Fluted Panel Door Style

WARRANTY AND SUPPORT

Warranty Information

Warranty details for your HUANLEGO shoe cabinet are typically included with your purchase documentation. Please refer to the warranty card or contact the manufacturer directly for specific terms and conditions.

Customer Support

For any questions, missing parts, or assistance with assembly or operation, please contact the HUANLEGO professional online customer service team. Refer to the contact information provided in your product packaging or visit the official HUANLEGO website for support options. We are committed to resolving any issues and providing necessary replacements.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0FHQ1SP5J>

More documents and user manuals: <https://manuals.plus/>