

[Manuals.plus](#) /

› [GNMN](#) /

› GNMN V7 Wireless Earbuds User Manual

## GNMN GNMN V7

# GNMN V7 Wireless Earbuds User Manual

Model: GNMN V7 | Brand: GNMN

## INTRODUCTION

Thank you for choosing the GNMN V7 Wireless Earbuds. These earbuds are designed to provide a superior audio experience with features tailored for active lifestyles, including a secure fit, long battery life, and IPX7 waterproofing. This manual provides detailed instructions on how to set up, operate, and maintain your earbuds to ensure optimal performance.

## WHAT'S IN THE BOX

- Wireless Bluetooth Headphones
- Charging Case with LED Indicator
- USB-C Charging Cable
- Eartips (multiple sizes)
- User Manual



Image: GNMN V7 Wireless Earbuds, charging case, and accessories.

## SETUP

---

### 1. Charging the Earbuds and Case

Before first use, fully charge the earbuds and the charging case. Connect the provided USB-C charging cable to the charging port on the case and a power source. The LED display on the case will show the charging status.

# Super Long Battery Life

**96** Hrs  
charging case



**8** Hrs  
single charge



Image: The GNMN V7 charging case connected to a USB-C cable, showing the LED battery display.

## 2. Pairing with Your Device

1. Ensure the charging case has sufficient power.
2. Open the charging case. The earbuds will automatically enter pairing mode.
3. On your device (smartphone, tablet, laptop), go to Bluetooth settings and turn on Bluetooth.
4. Select "V7" from the list of available devices.
5. Once connected, you will hear a confirmation sound, and the earbuds will be ready for use.


Your browser does not support the video tag.

Video: Demonstrates the quick pairing process of the GNMN V7 Wireless Earbuds with a smartphone.

## OPERATING INSTRUCTIONS

### Wearing the Earbuds

The GNMN V7 earbuds feature soft ear-hooks for a secure and comfortable fit, especially during physical activities. Choose the correct size eartips for optimal sound and comfort.



## Stable & Comfortable Fit




Image: A person wearing the GNMN V7 earbuds, highlighting the stable and comfortable fit provided by the ear-hooks and multiple eartip sizes.

## Touch Controls

The earbuds are equipped with sensitive touch controls for easy management of various functions:

| Function                 | Action                                              |
|--------------------------|-----------------------------------------------------|
| Play/Pause               | Single tap on either earbud                         |
| Next Song                | Double tap right earbud                             |
| Previous Song            | Double tap left earbud                              |
| Volume Up                | Long press right earbud                             |
| Volume Down              | Long press left earbud                              |
| Answer/End Call          | Single tap on either earbud during a call           |
| Reject Call              | Long press on either earbud during an incoming call |
| Activate Voice Assistant | Triple tap on either earbud                         |

# Rich, Vivid Sound



Image: Diagram illustrating the touch control functions on the GNMN V7 earbuds.

## Battery Life and Display

The earbuds offer up to 8 hours of playback on a single charge, and the charging case provides multiple additional charges for a total of up to 96 hours of continuous playback. The charging case features a dual LED display that shows the battery level of the case and the charging status of each earbud.

# IPX7 Waterproof



Image: Visual representation of the GNMN V7 earbuds' long battery life and the charging case's LED display.

## IPX7 Waterproof Rating

The GNMN V7 earbuds are IPX7 waterproof, making them resistant to sweat and rain. This feature makes them ideal for workouts and outdoor activities. **Note:** The charging case is not waterproof.

# Effortless Touch Setup




Image: The GNMN V7 earbuds with water droplets, illustrating their IPX7 waterproof capability.

## MAINTENANCE

- **Cleaning:** Regularly clean the earbuds, especially the eartips and charging contacts, with a soft, dry cloth. Do not use harsh chemicals or abrasive materials.
- **Storage:** When not in use, store the earbuds in their charging case to protect them and keep them charged.
- **Avoid Extreme Temperatures:** Do not expose the earbuds or charging case to extreme temperatures (hot or cold) or direct sunlight for prolonged periods.

- **Water Exposure:** While the earbuds are IPX7 waterproof, avoid prolonged submersion in water. Ensure they are dry before placing them back in the charging case.

## TROUBLESHOOTING

| Problem                          | Possible Solution                                                                                                              |
|----------------------------------|--------------------------------------------------------------------------------------------------------------------------------|
| Earbuds not pairing              | Ensure earbuds are charged. Turn off and on Bluetooth on your device. Forget "V7" in Bluetooth settings and re-pair.           |
| Only one earbud working          | Place both earbuds back in the charging case, close the lid, wait a few seconds, then open again. Ensure both are charged.     |
| Low volume or poor sound quality | Adjust volume on both earbuds and your device. Ensure eartips are properly sealed in your ear. Clean eartips and speaker mesh. |
| Charging case not charging       | Check USB-C cable and power adapter. Ensure the cable is fully inserted into the charging port.                                |
| Earbuds not charging in case     | Ensure charging contacts on earbuds and in case are clean and dry. Verify earbuds are correctly seated in the case.            |

## SPECIFICATIONS

| Feature                                  | Detail                        |
|------------------------------------------|-------------------------------|
| Model Name                               | GNMN V7                       |
| Connectivity Technology                  | Wireless (Bluetooth)          |
| Wireless Communication Technology        | Bluetooth                     |
| Battery Life (Single Charge)             | Up to 8 hours                 |
| Total Playback Time (with Charging Case) | Up to 96 hours                |
| Water Resistance Level                   | IPX7 (Earbuds only)           |
| Control Type                             | Touch Control, Volume Control |
| Earpiece Shape                           | Hook (Over Ear)               |
| Material                                 | Plastic                       |
| Product Dimensions                       | 1.38 x 1.42 x 2.32 inches     |
| Item Weight                              | 3.52 ounces                   |

## WARRANTY AND SUPPORT

GNMN products come with a standard limited warranty. For specific warranty terms and conditions, please refer to the warranty card included in your product packaging or visit the official GNMN website. If you encounter any issues or require technical assistance, please contact GNMN customer support:

- **Online Support:** Visit the [GNMN Store on Amazon](#) for FAQs and support resources.
- **Email Support:** Refer to your product packaging or the official website for direct email contact.

Please have your product model number (GNMN V7) and purchase details ready when contacting support.

© 2025 GNMN. All rights reserved.

## ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

### Name

Anonymous

### Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

### Question

Example: How do I reset this device or fix this error?

### Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question