

[Manuals.plus](#) /

› [chartustriable](#) /

› chartustriable Farmhouse TV Stand for 70 Inch TVs - User Manual

chartustriable Farmhouse TV Stand for 60 Inch TV

chartustriable Farmhouse TV Stand for 70 Inch TVs - User Manual

Model: Farmhouse TV Stand for 60 Inch TV

INTRODUCTION

This manual provides detailed instructions for the assembly, operation, and maintenance of your chartustriable Farmhouse TV Stand. Please read this manual thoroughly before beginning assembly or use to ensure proper installation and to maximize the lifespan of your product. Keep this manual for future reference.



Image: The chartustriable Farmhouse TV Stand, fully assembled and styled in a living room.

PRODUCT FEATURES

- **Barn Style Design:** Features a classic barn door aesthetic, suitable for various home decor styles.
- **Waterproof Material:** Constructed from thick, waterproof material for enhanced moisture resistance and long-term durability.
- **Thickened Desktop:** The 1.2-inch thick desktop provides a sturdy and stable surface with a strong load-bearing capacity for various items.
- **Metal Slide Sliding Door:** Equipped with metal slide rails for smooth and quiet operation of the barn-style sliding doors.
- **Three-level Adjustable Shelves:** Interior shelves offer three height adjustment levels to accommodate different storage needs and optimize space utilization.



Image: Detail view of the barn sliding door and metal slide rails.




Image: Illustration of the three-level adjustable shelves.

SPECIFICATIONS

Feature	Detail
Brand	chartustriable
Color	Grey
Product Dimensions	70.9"D x 15.7"W x 27.6"H
Special Feature	Adjustable Shelf
Mounting Type	Floor Mount
Room Type	Bedroom, Living Room
Door Style	Flat Panel

Weight Limit	150 Pounds
Included Components	Shelves
Item Weight	70 Pounds
Assembly Required	Yes




Image: Detailed dimensions of the TV stand.

SETUP AND ASSEMBLY

Assembly of the chartustriable Farmhouse TV Stand is required. Please follow the instructions provided in the separate assembly guide included with your product. Ensure all parts are present before beginning assembly. A typical assembly process involves:

1. Unpacking all components and verifying against the parts list.
2. Assembling the main frame of the stand.
3. Attaching the back panels.
4. Installing the sliding door hardware and doors.
5. Inserting and adjusting the interior shelves.

It is recommended to have at least two people for assembly to ensure stability and prevent damage.

OPERATING INSTRUCTIONS

The chartustriable Farmhouse TV Stand is designed for straightforward use.

- **Sliding Barn Doors:** To open or close the cabinet compartments, gently slide the barn doors along the top metal rails. Ensure no obstructions are in the path of the doors.
- **Adjustable Shelves:** The interior shelves can be adjusted to three different heights. To adjust, remove the shelf, reposition the shelf pins to the desired height, and then place the shelf back onto the pins. Ensure the shelf is level and securely seated before placing items on it.
- **Weight Capacity:** Do not exceed the maximum weight limit of 150 pounds for the tabletop. Distribute weight evenly across shelves and the tabletop.

MAINTENANCE

Regular maintenance will help preserve the appearance and functionality of your TV stand.

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid using harsh chemicals or abrasive cleaners, as these can damage the finish. For spills, wipe immediately.
- **Dusting:** Dust regularly with a dry, soft cloth.
- **Hardware Check:** Periodically check all screws and fasteners to ensure they are tight. Retighten if necessary to maintain structural integrity.
- **Avoid Direct Sunlight:** Prolonged exposure to direct sunlight can cause fading or discoloration.
- **Moisture Protection:** Although the material is waterproof, avoid prolonged exposure to standing water. Use coasters under drinks to prevent water rings.

TROUBLESHOOTING

If you encounter any issues with your TV stand, refer to the following common solutions:

- **Wobbly Stand:** Ensure all assembly screws are securely tightened. Verify that the stand is placed on a flat, level surface. Adjust glides or shims if necessary.
- **Sliding Doors Sticking:** Check the metal slide rails for any debris or obstructions. Clean the rails with a soft cloth. Ensure the doors are properly seated on the rails.
- **Misaligned Parts During Assembly:** If parts do not align, carefully review the assembly instructions. Disassemble the affected section and reassemble, ensuring all pieces are oriented correctly. Do not force parts together.
- **Missing Parts:** If any parts are missing upon unpacking, contact customer support immediately for assistance.

WARRANTY AND SUPPORT

For any questions, concerns, or assistance with your chartustriable Farmhouse TV Stand, please contact our customer support team. We are committed to providing a satisfactory user experience.

- **Customer Service:** 24-hour customer service is available to assist you. Refer to your purchase documentation for specific contact details or visit the official chartustriable store on Amazon.
- **Protection Plans:** Extended protection plans may be available for purchase. Please check your retailer for details.



Image: Customer service representatives ready to assist.