

Hotpoint HPT 93D BS IT

Hotpoint HPT 93D BS IT 9 Kg Heat Pump Tumble Dryer User Manual

Comprehensive instructions for setup, operation, and maintenance.

1. INTRODUCTION

Thank you for choosing the Hotpoint HPT 93D BS IT 9 Kg Heat Pump Tumble Dryer. This manual provides essential information for the safe and efficient use of your appliance. Please read these instructions carefully before installation and operation, and keep them for future reference.



Image 1: Front view of the Hotpoint HPT 93D BS IT 9 Kg Heat Pump Tumble Dryer. This image displays the appliance's main body, control panel, and loading door.

The Hotpoint HPT 93D BS IT is a 9 kg capacity heat pump tumble dryer designed for efficient and gentle drying of various fabric types. It features advanced technologies such as PetHair Care for effective pet hair removal, Gentle Care for delicate garments, and a wrinkle prevention function to simplify ironing.

2. SAFETY INFORMATION

Always adhere to the following safety precautions to prevent personal injury or damage to the appliance.

- Ensure the appliance is properly grounded before use.
- Do not allow children to play with or operate the dryer.
- Never dry items that have been soiled with flammable substances (e.g., cooking oil, gasoline).
- Clean the lint filter before or after every load to maintain efficiency and prevent fire hazards.
- Do not block the ventilation openings of the dryer.
- Unplug the appliance from the power supply before performing any cleaning or maintenance.
- Do not install the dryer in an area where it may be exposed to freezing temperatures.

3. PRODUCT OVERVIEW

3.1 Components and Controls

Familiarize yourself with the main components and control panel of your Hotpoint tumble dryer.



Image 2: Close-up view of the control panel. This image highlights the program selector knob, digital display, and various function buttons.

The control panel features a central program selector knob, a digital display for time and status, and touch-sensitive buttons for additional functions and settings.

3.2 Key Features

- **PetHair Care:** Utilizes steam to effectively remove pet hair from clothes without damaging fabrics.
- **Gentle Care:** Provides optimal drying results at low temperatures, preventing damage or shrinkage to delicate garments.
- **Sport Cycle:** Specifically designed for drying synthetic, cotton, mixed fabrics, or waterproof items like multi-functional jackets.
- **Drying Level Adjustment:** Allows selection of the desired dryness level for fabrics, influencing program duration.
- **Wrinkle Prevention:** A function that minimizes creasing and facilitates ironing, especially if laundry is not removed immediately after the cycle.

4. SETUP

4.1 Unpacking

Carefully remove all packaging materials from the dryer. Inspect the appliance for any signs of damage during

transit. Report any damage to your retailer immediately.

4.2 Installation

- **Placement:** Position the dryer on a firm, level floor. Ensure adequate ventilation around the appliance. Do not install behind a lockable door, a sliding door, or a door with a hinge on the opposite side to that of the tumble dryer, in such a way that a full opening of the tumble dryer door is restricted.
- **Leveling:** Adjust the feet at the bottom of the dryer to ensure it is perfectly level. This prevents excessive vibration and noise during operation.
- **Electrical Connection:** Connect the dryer to a properly grounded electrical outlet. Ensure the voltage and frequency match the specifications on the rating plate. Do not use extension cords or multiple adapters.
- **Drainage (Optional):** If you wish to drain the condensed water directly, connect the supplied drainage hose to a suitable drain point. Otherwise, the water will collect in the water container.



Image 3: Angled view of the Hotpoint HPT 93D BS IT dryer. This perspective helps visualize the appliance's dimensions and potential placement.

5. OPERATING INSTRUCTIONS

5.1 Before First Use

Before drying clothes for the first time, run a short cycle with a damp cloth to remove any manufacturing residues from the drum.

5.2 Loading the Dryer

- Sort laundry by fabric type and desired dryness level.
- Do not overload the dryer. The maximum capacity for this model is 9 kg.
- Ensure all items are thoroughly spun in a washing machine to remove excess water.
- Check pockets for any objects that could damage the dryer or clothes.



Image 4: Dryer with door open. This image illustrates the spacious drum for loading laundry.

5.3 Selecting a Program

Turn the program selector knob on the control panel to choose the appropriate drying program for your laundry. The available programs include:

- **Rapid 30:** Quick drying for small loads.
- **Baby:** Gentle drying for baby clothes.
- **Shirts:** Specific program for shirts to minimize wrinkles.
- **Jeans:** Optimized for denim fabrics.
- **Duvet:** For larger, bulky items like duvets.

- **Sheets:** For bed linens.
- **Gentle Care:** For delicate items requiring low temperatures.
- **PetHair Care:** Steam-assisted program for pet hair removal.
- **Time Drying:** Manual setting for drying duration.
- **Cotton:** Standard program for cotton items.
- **Eco:** Energy-efficient drying.
- **Synthetics:** For synthetic fabrics.
- **Mixed:** For mixed fabric loads.
- **Sport:** For sportswear and technical fabrics.
- **Cool Refresh:** A short cycle to refresh clothes without heat.

Additional options like drying level, anti-crease, and delayed start can be selected using the touch buttons on the control panel.

5.4 Starting a Cycle

After selecting the program and any desired options, press the Start/Pause button to begin the drying cycle.

5.5 End of Cycle

The dryer will signal the end of the cycle. Remove laundry promptly to minimize wrinkles. If the wrinkle prevention function is active, the drum will periodically tumble the clothes after the cycle finishes.

6. MAINTENANCE

Regular maintenance ensures optimal performance and extends the lifespan of your dryer.

6.1 Cleaning the Lint Filter

The lint filter should be cleaned after every drying cycle. Open the dryer door and pull out the filter located inside the door opening. Remove accumulated lint by hand or with a soft brush. Rinse under running water if necessary and ensure it is completely dry before reinserting.



Image 5: Lint filter inside the drum. This image shows the location and appearance of the filter that needs regular cleaning.

6.2 Emptying the Water Container

If the dryer is not connected to a direct drain, the condensed water will collect in the water container. Empty the container after each cycle to prevent the 'Water Tank Full' indicator from illuminating and stopping the dryer. The container is typically located at the top left of the appliance.

6.3 Cleaning the Condenser

The condenser should be cleaned periodically (e.g., every few months) to maintain drying efficiency. Refer to the specific instructions in your full manual for accessing and cleaning the condenser unit, usually located behind a lower access panel.



Image 6: Lower front panel. This image indicates the area where the condenser unit is typically accessed for cleaning.

6.4 General Cleaning

Wipe the exterior of the dryer with a soft, damp cloth. Do not use abrasive cleaners or solvents. Clean the drum interior with a damp cloth if necessary.

7. TROUBLESHOOTING

Before contacting customer service, consult the following table for common issues and their solutions.

Problem	Possible Cause	Solution
Dryer does not start	Power cord unplugged; Door not closed properly; Start/Pause button not pressed; Fuse blown.	Check power connection; Ensure door is securely latched; Press Start/Pause; Check household fuse/circuit breaker.
Clothes are not drying properly	Lint filter clogged; Water container full; Incorrect program selected; Overloaded dryer.	Clean lint filter; Empty water container; Select appropriate program; Reduce load size.
Excessive noise or vibration	Dryer not level; Foreign objects in drum.	Adjust leveling feet; Check drum for loose items.
Water tank full indicator on, but tank is empty	Sensor malfunction or blockage.	Consult the full user manual or contact customer support.

8. SPECIFICATIONS

Feature	Detail
---------	--------

Feature	Detail
Brand	Hotpoint
Model Number	HPT 93D BS IT (869991720490)
Type	Heat Pump Tumble Dryer
Drying Capacity	9 kg
Energy Efficiency Class	D
Dimensions (H x W x D)	84.6 x 59.8 x 60.7 cm
Weight	42 kg
ASIN	B0FHQLPRMJ

9. WARRANTY AND SUPPORT



This Hotpoint appliance comes with a manufacturer's warranty. For specific details regarding your warranty coverage and duration, please refer to the warranty card included with your product or visit the official Hotpoint website.





For technical assistance, spare parts, or to schedule a service appointment, please contact Hotpoint Customer Service. You can typically find contact information on the Hotpoint website or in the documentation provided with your dryer.


If you purchased this product through Amazon, you may also refer to Amazon's return policy for information on returns and refunds within 30 days of receipt. For defective or damaged products, consult Amazon's help page on returns. For Marketplace purchases, refer to the specific Marketplace help page.

Note: The product includes a power cable. Other accessories may be sold separately.

Related Documents - HPT 93D BS IT

	<p>Hotpoint Tumble Dryer Quick Guide and Maintenance</p> <p>A quick guide for operating and maintaining your Hotpoint tumble dryer, including program details, options, troubleshooting, and care instructions.</p>
	<p>Hotpoint BHWD129 Washer Dryer Operating Instructions</p> <p>Comprehensive operating instructions for the Hotpoint BHWD129 Washer Dryer, covering control panel functions, indicator lights, wash cycles, and drying options.</p>

	<p>Hotpoint Tumble Dryer Quick Guide - Operation and Maintenance</p> <p>Concise guide for Hotpoint tumble dryers, covering control panel, first-time use, daily operation, programs, options, care, maintenance, and troubleshooting. Includes essential safety and usage information.</p>
	<p>Hotpoint Tumble Dryer Quick Guide: Operation, Programs, and Maintenance</p> <p>A concise guide to operating your Hotpoint tumble dryer, covering control panel functions, program selection, daily use, care and maintenance, and troubleshooting tips.</p>
	<p>Hotpoint Dryer User Manual - CHDC82 Series</p> <p>This user manual provides detailed instructions for operating, installing, and maintaining your Hotpoint CHDC82 series tumble dryer. It includes safety warnings, program descriptions, troubleshooting tips, and technical specifications.</p>
	<p>Hotpoint Washer Dryer User Guide</p> <p>User guide for the Hotpoint Washer Dryer, detailing control panel functions, wash cycles, operation, maintenance, and troubleshooting tips for optimal performance.</p>



[\[pdf\]](#) Label

ENERGY LABEL MLS e team 7 0 eteam eu Hotpoint HPT 93D BS IT tumble dryer Freestanding Front load 9 kg White EU Energy Label 35 KB 869991720490 mmo 133114467 1752846033 5854 42 objects

icecat biz |||

HOTPOINT **HPT 93D BS IT** 128 100 A B C D 88 A B 64 C D 9,0 kg 3:29 ...

lang: **score:38** filesize: 35.07 K page_count: 1 document date: 0000-00-00

Hotpoint

Asciugatrice
Manuale utente
Dryer
User Manual



HPT 93D BS IT



IT/EN
2960314716_IT/04-06-25,(15/05)



[\[pdf\]](#) User Manual SAR Rating

User s Manual Önder ALAYOĞLU Manuale utenteHotpoint Ariston Délica HPT 93D BS IT Asciugatrice libera installazione a Pompa di Calore 9 kg Classe D Funzione Vapore PetHaircare Gentlecaremmo 133114467 1752846018 9226 30objects icecat biz objects mmo 30 |||

Asciugatrice Manuale utente Dryer User Manual**HPT 93D BS IT** IT/EN

2960314716_IT/ 04-06-25. 15:06 Caro cliente, invitiamo a leggere questa guida prima di utilizzare questo prodotto Grazie per aver scelto il Hotpoint . Vorremmo che lei potesse raggiungere un livello di efficienza ottimale da que...

lang:it **score:34** filesize: 4.76 M page_count: 68 document date: 2025-06-12

Scheda informativa del prodotto - (UE) 2019/2017			
Marchio a nome del fornitore: HOTPOINT			
Indirizzo del fornitore: BEO EUROPE MANAGEMENT S.R.L., VIA VARENSA, 304 20158 MILANO ITALY			
Identificativo del modello: HPT 93D BS IT			
Tipo asciugatrice		a pompa di calore	
Parametri di prodotto generali			
Parametro	Valore	Parametro	Valore
Capacità nominale (kg)	9.0	Dimensioni in cm	Altezza 85
			Larghezza 60
			Profondità 61
Indice di efficienza energetica (IEE)	69.6	Classe di efficienza energetica	D
Efficienza di condensazione (EU 2017/2450)	88	Classe di efficienza della condensazione (se applicabile)	B
Consumo procedente di energia per ciclo di asciugatura (il consumo di energia effettivo dipende dalle modalità prese dell'apparecchio)		1.28	
Durata del programma (h:min)	Capacità nominale 3:29	Tipo	A libera installazione
	Media 2:05		
Emissioni di rumore aerea (dB(A) re 1pW)	64	Classi di emissione di rumore aerea	B
Modalità sporta (W) (se del caso)	-	Modalità stand-by (W) (se del caso)	0.50
Auxiliary heater (W) (se del caso)	4.00	Modalità stand-by in rete (W) (se del caso)	-

[Hotpoint HPT 93D BS IT Heat Pump Tumble Dryer - Product Information Sheet](#)

Detailed product information sheet for the Hotpoint HPT 93D BS IT heat pump tumble dryer, including technical specifications, energy efficiency ratings, dimensions, and warranty details, compliant with EU 2019/2017 regulations.

lang:it **score:34** filesize: 47.43 K page_count: 2 document date: 2025-07-18