

Svoko LT-145

Svoko Handheld Vacuum Cleaner LT-145 User Manual

Model: LT-145

1. INTRODUCTION

Thank you for choosing the Svoko Handheld Vacuum Cleaner LT-145. This compact and powerful cordless vacuum is designed for efficient cleaning in various environments, including cars, offices, and homes. Featuring a brushless motor, dual suction modes, and a versatile 4-in-1 design, it provides effective cleaning for dust, crumbs, pet hair, and other debris. Please read this manual thoroughly before use to ensure proper operation and maintenance.

2. SAFETY INSTRUCTIONS

To reduce the risk of fire, electric shock, or injury, please observe the following safety precautions:

- Read all instructions before using the appliance.
- Do not use outdoors or on wet surfaces.
- Do not allow to be used as a toy. Close attention is necessary when used by or near children.
- Use only as described in this manual. Use only manufacturer's recommended attachments.
- Do not use with damaged cord or plug. If appliance is not working as it should, has been dropped, damaged, left outdoors, or dropped into water, return it to a service center.
- Do not pull or carry by cord, use cord as a handle, close a door on cord, or pull cord around sharp edges or corners. Do not run appliance over cord. Keep cord away from heated surfaces.
- Do not unplug by pulling on cord. To unplug, grasp the plug, not the cord.
- Do not handle plug or appliance with wet hands.
- Do not put any object into openings. Do not use with any opening blocked; keep free of dust, lint, hair, and anything that may reduce airflow.
- Keep hair, loose clothing, fingers, and all parts of body away from openings and moving parts.
- Do not pick up anything that is burning or smoking, such as cigarettes, matches, or hot ashes.
- Do not use to pick up flammable or combustible liquids, such as gasoline, or use in areas where they may be present.
- Do not pick up toxic material, such as chlorine bleach, ammonia, or drain cleaner.
- Do not use without dust bag and/or filters in place.
- Turn off all controls before unplugging.
- Use extra care when cleaning on stairs.

- Do not charge the unit outdoors.
- Only use the charger specified by the manufacturer.

3. PACKAGE CONTENTS

Please check the package for the following items:

- Svoko Handheld Vacuum Cleaner LT-145
- Long Strip Nozzle
- Blowing Nozzle A
- Blowing Nozzle B
- Floor Brush
- Exhaust Nozzle
- Small Brush
- Type-C Charging Cable
- User Manual

4. PRODUCT OVERVIEW

Familiarize yourself with the main components of your Svoko Handheld Vacuum Cleaner LT-145.



Figure 4.1: Main unit of the Svoko Handheld Vacuum Cleaner LT-145. This image shows the compact design and the transparent dustbin, highlighting the main body of the vacuum.

The vacuum features a powerful brushless motor, a transparent dust collection bin, and an integrated LED light for improved visibility during cleaning. The control button allows for power on/off and switching between suction modes.

5. SETUP AND CHARGING

5.1 Initial Charge

Before first use, fully charge the vacuum cleaner. Connect the Type-C charging cable to the vacuum's charging port and plug the other end into a compatible USB power adapter (not included) or a USB port. The LED indicator will show red during charging and turn green when fully charged. A full charge typically takes approximately 3 hours.




Figure 5.1: Illustration of the Svako LT-145's battery capacity and Type-C charging port. It indicates a 6000 mAh battery, providing 40 minutes runtime in Eco Mode and 13 minutes in Turbo Mode, with a 3-hour full charge time.

5.2 Attaching Accessories

Select the appropriate nozzle or brush for your cleaning task. Align the accessory with the vacuum's suction port and push firmly until it clicks into place. To remove, pull the accessory away from the vacuum.

4-IN-1 HANDHELD CLEANER



Blowing Function



Extended Nozzle



Long Strip Nozzle



Blowing Nozzle A



Floor Brush



Blowing Nozzle B



Exhaust Nozzle



Small Brush

Figure 5.2: Overview of the 4-in-1 functionality and included accessories for the Svoko LT-145. This image displays various nozzles like the Long Strip Nozzle, Blowing Nozzle A and B, Floor Brush, Exhaust Nozzle, and Small Brush, demonstrating their uses for different cleaning and blowing tasks.

6. OPERATING INSTRUCTIONS

6.1 Power On/Off and Suction Modes

Press the power button once to turn on the vacuum in Eco Mode. This mode provides up to 40 minutes of continuous cleaning. Press the power button again to switch to Turbo Mode, which offers maximum suction power for tougher messes,

with a runtime of approximately 13 minutes. Press the button a third time to turn off the vacuum.




Figure 6.1: A person using the Svoko LT-145 handheld vacuum cleaner inside a car, demonstrating its portability and effectiveness for automotive cleaning. The image highlights the vacuum's strong suction capabilities with visual cues of debris being lifted.

6.2 LED Illumination

The integrated LED headlight automatically activates when the vacuum is turned on. This feature helps illuminate dark areas, revealing hidden dust and debris in crevices, under furniture, and in other poorly lit spaces, ensuring thorough cleaning.

HIGH-BRIGHTNESS LED

Fine dust revealed clear even in dark.



Figure 6.2: The Svoko LT-145 handheld vacuum cleaner demonstrating its high-brightness LED light, which helps reveal fine dust in dark areas for more effective cleaning.

6.3 Using the Blowing Function

Some accessories allow the vacuum to function as a blower. Attach the appropriate blowing nozzle to the exhaust port of the vacuum. This function is useful for clearing dust from keyboards, vents, or inflating small items like air mattresses with the correct nozzle.

7. MAINTENANCE

7.1 Emptying the Dust Bin

For optimal performance, empty the dust bin regularly. Press the dust release button to detach the dust bin from the main unit. Dispose of the collected debris. The one-touch release mechanism ensures a mess-free process.

7.2 Cleaning the Filters

The Svoko LT-145 features a dual filtration system consisting of a stainless steel filter and a HEPA filter. Both filters are washable and designed to capture fine dust and allergens.

- Remove the dust bin and then carefully remove both the stainless steel and HEPA filters.
- Rinse the filters under running water until clean. Do not use harsh detergents.
- Allow the filters to air dry completely for at least 24 hours before reassembling. Ensure they are completely dry to prevent mold or damage to the vacuum.
- Reinsert the HEPA filter first, followed by the stainless steel filter, and then reattach the dust bin to the main unit.

DUAL FILTRATION SYSTEM

Captures even microparticles

Stainless Steel Filter

1 Layer

- ✓ Washable durable design
- ✓ Traps large debris
- ✓ Protects internal components

2 Layer

HEPA Filter

- ✓ High-efficiency HEPA technology
- ✓ Removes 99% of particles
- ✓ Replaceable for lasting performance

Figure 7.1: Diagram illustrating the dual filtration system of the Svoko LT-145. It shows the two layers: a stainless steel filter for large debris and a HEPA filter for microparticles, both designed to be washable and durable.

8. TROUBLESHOOTING

Problem	Possible Cause	Solution
Vacuum does not turn on.	Battery is depleted.	Charge the vacuum cleaner fully.

Problem	Possible Cause	Solution
Low suction power.	Dust bin is full. Filters are clogged. Nozzle/hose is blocked.	Empty the dust bin. Clean or replace the filters. Check and clear any blockages in the nozzle or hose.
Vacuum stops during operation.	Battery is low. Overheating protection activated.	Recharge the battery. Turn off the vacuum and allow it to cool down for at least 30 minutes before resuming use.
LED indicator not working.	Faulty LED or internal issue.	Contact customer support.

9. SPECIFICATIONS

Feature	Detail
Brand	Svoko
Model Name	LT-145
Suction Power	Up to 21,000 Pa (21 kPa)
Motor Type	Brushless Motor (85,000 RPM)
Power Modes	Eco Mode, Turbo Mode
Runtime (Eco Mode)	Approx. 40 minutes
Runtime (Turbo Mode)	Approx. 13 minutes
Charging Port	Type-C USB
Charging Time	Approx. 3 hours
Filter Type	Dual Filtration (Stainless Steel + HEPA)
Special Features	Cordless, LED Illumination, 4-in-1 Functionality (Vacuum, Blower, Inflator, Deflator)
Weight	Approx. 0.8 lbs (0.36 kg)
Dimensions (L x W x H)	16.8 cm x 6.4 cm x 22.1 cm
Voltage	5V
Capacity	150 microliters per minute
UPC	762531350299, 732265220502
ASIN	B0FHQM1D6W

10. WARRANTY AND SUPPORT

Svoko products are manufactured to high-quality standards. For warranty information, technical support, or customer service

inquiries, please refer to the contact information provided with your purchase or visit the official Svoko website. Please retain your proof of purchase for warranty claims.

© 2026 Svoko. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question