

YUAHA CU0019, MR0084, MR0086, MR0087, MR0101, MR0102, MR0107

Receiver Multiple Device Compatibility User Manual

Model: CU0019, MR0084, MR0086, MR0087, MR0101, MR0102, MR0107

Brand: YUAHA

1. PRODUCT OVERVIEW

This single-channel USB receiver is designed to provide wireless connectivity for multiple compatible devices, enhancing efficiency in various work environments. It supports a range of models, allowing for seamless switching between different peripherals.

Key Features:

- **Multi-Device Compatibility:** Supports models such as M170, M171, M185, M186, and is suitable for CU0019 series, including MR0084, MR0086, MR0087, MR0101, MR0102, MR0107.
- **Easy Connection:** Facilitates quick connection to your computer, suitable for fast-paced work environments.
- **Stable Performance:** Utilizes advanced technology to ensure stable and interference-free operation.
- **Portable Design:** Small and compact, making it easy to carry and ideal for travel.



Image 1.1: The YUAHA USB receiver, displaying its model number CU0019. This compact device enables wireless connectivity for compatible peripherals.

2. SETUP INSTRUCTIONS

Follow these steps carefully to pair your compatible device with the YUAHA USB receiver. Ensure the device has a fully charged battery before beginning the pairing process.

1. **Prepare Device:** Turn off the power switch on your compatible device (e.g., mouse).
2. **Insert Receiver:** Insert the USB receiver into an available USB port on your computer.
3. **Initiate Pairing (Step 1):** Press and **hold** the Right Button on your device. Continue holding this button until Step 6 is completed.
4. **Initiate Pairing (Step 2):** While still holding the Right Button, turn on the power switch on your device.

5. **Initiate Pairing (Step 3):** Click the Left Button on your device once.
6. **Initiate Pairing (Step 4):** Click the Middle Button (scroll wheel) on your device once.
7. **Complete Pairing:** Release the Right Button. The device and USB receiver should automatically pair.

Important Note: If pairing is unsuccessful, unplug the receiver from the USB port, then plug it back in, and repeat all steps above precisely. Do not skip any steps. Sufficient battery power in the device is crucial for successful pairing.



Image 2.1: Example of a compatible device (M185 mouse, model MR0084) showing its underside. Ensure your device's battery is charged before pairing.

3. OPERATING INSTRUCTIONS

Once successfully paired, the receiver allows your compatible device to function wirelessly with your computer. The receiver supports multiple compatible devices, enabling you to switch between them as needed.

- **Automatic Connection:** After initial pairing, the device should automatically connect to the receiver when both are powered on and within range.
- **Switching Devices:** If you have multiple compatible devices paired with the same receiver, you can typically switch between them by simply activating the desired device. The receiver will recognize the

active device.

- **Driver Installation:** The receiver is designed for easy connection, often requiring no additional driver installation on most modern operating systems. If prompted, allow your system to install necessary drivers automatically.

4. MAINTENANCE

Proper care of your YUAHA USB receiver will ensure its longevity and optimal performance.

- **Keep Dry:** Avoid exposing the receiver to liquids or high humidity.
- **Clean Gently:** Use a soft, dry cloth to clean the receiver. Do not use harsh chemicals or abrasive materials.
- **Protect from Damage:** Store the receiver in a safe place when not in use to prevent physical damage, especially to the USB connector.
- **Temperature:** Operate and store the receiver within normal room temperatures.

5. TROUBLESHOOTING

If you encounter issues with your YUAHA USB receiver, try the following troubleshooting steps:

- **Device Not Pairing:**
 - Ensure the compatible device has a sufficient battery charge.
 - Unplug the receiver from the USB port, wait a few seconds, and then plug it back in.
 - Carefully repeat all steps in the "Setup Instructions" section (Section 2), ensuring no steps are skipped.
 - Try a different USB port on your computer.
- **Intermittent Connection:**
 - Ensure the receiver is not obstructed by other objects or electronic devices that might cause interference.
 - Move the device closer to the receiver.
 - Check for any software updates for your operating system or device drivers.
- **Device Not Responding:**
 - Verify the device's power switch is in the "ON" position.
 - Replace the battery in your compatible device if it's low.
 - Re-pair the device with the receiver as per the setup instructions.

6. SPECIFICATIONS

Feature	Detail
Item Type	New version single channel receiver
Supported Frequency	2.4GHz
Compatibility (M/N)	CU0019 series, MR0084, MR0086, MR0087, MR0101, MR0102, MR0107

Compatibility (Models)	M170, M171, M185, M186
Package Includes	1PC receiver
Dimensions (Approx.)	1.8 cm / 0.7 inches (length of exposed part)



Image 6.1: The compact size of the YUAHA USB receiver, shown with approximate dimensions for reference.

7. WARRANTY AND SUPPORT

Information regarding specific warranty terms or dedicated customer support channels for this product is not provided in the available documentation. For any inquiries or support needs, please refer to the seller or the platform where the product was purchased.

It is recommended to retain your purchase receipt as proof of purchase for any potential warranty claims or support requests.

