



[Manuals.plus](#) /

› [ILIFE](#) /

› ILIFE V5s Plus Robot Vacuum and Mop User Manual

ILIFE V5s Plus

ILIFE V5s Plus Robot Vacuum and Mop

USER MANUAL

Introduction

Thank you for choosing the ILIFE V5s Plus Robot Vacuum and Mop. This device is designed to provide efficient cleaning for your home, combining both vacuuming and mopping functions. It features smart navigation, app control, and automatic self-charging for convenience. Please read this manual thoroughly before use to ensure proper operation and maintenance.



The ILIFE V5s Plus Robot Vacuum and Mop, ready for use.

Safety Instructions

Before operating the ILIFE V5s Plus, please observe the following safety precautions:

- Read all instructions carefully before using the appliance.
- Keep the robot and its accessories out of reach of children.
- Do not operate the robot in wet environments or near water.
- Ensure the charging dock is placed on a flat surface against a wall, with clear space around it.
- Remove any loose cables, small objects, or fragile items from the cleaning path to prevent entanglement or damage.
- Do not use the robot to pick up large debris, sharp objects, or liquids other than water for mopping.
- Only use the original power adapter and charging dock provided with the robot.

What's in the Box

Verify that all components are present in the package:

- Main body (battery included)
- Charging dock
- Remote control (battery not included)
- AC adapter
- Cleaning tool
- Mop cloth
- Water tank
- User manual
- High performance filter
- Extra side brushes

Setup

1. Initial Charging

Place the charging dock against a wall in an open area. Connect the AC adapter to the charging dock and plug it into a power outlet. Place the robot onto the charging dock, ensuring the charging pins align. The robot will begin charging automatically. Allow for a full charge before first use (approximately 3-5 hours).

Convenient Auto-charging

V5s Plus will go back to its dock to charge automatically when in low battery



The robot automatically returns to its charging dock when the battery is low.

2. App Download and WiFi Connection

Download the 'ILIFEHOME' app from your smartphone's app store. Follow the in-app instructions to connect your robot to your home WiFi network. Ensure your WiFi is 2.4GHz, as the app does not support 5G WiFi.

Smart App Control

Easy to schedule your robot's cleaning routine via ILIFEHOME App.



Control the robot and schedule cleaning via the ILIFEHOME app.

3. Preparing the Cleaning Area

Before each cleaning cycle, clear the floor of any obstacles such as cables, toys, or small rugs that could entangle the robot. For mopping, ensure the water tank is filled and the mop cloth is attached.

Operating Instructions

1. Power On/Off


To power on the robot, press the 'CLEAN' button on the robot or use the remote control/app. To power off, press and hold the 'CLEAN' button until the indicator lights turn off, or use the app.

2. Cleaning Modes

The ILIFE V5s Plus offers multiple cleaning modes:

- **Auto Mode:** The robot automatically cleans the area, adjusting its path as needed.
- **Spot Mode:** Focuses on a specific dirty area, cleaning in a spiral pattern.
- **Edge Mode:** Cleans along walls and furniture edges.
- **Max Mode:** Increases suction power for deeper cleaning.
- **Scheduling Cleaning Mode:** Set a cleaning schedule via the app for automated cleaning.

Multiple Modes To Meet Your Need



The robot utilizes various cleaning modes to suit different needs.

3. Vacuuming and Mopping

The V5s Plus functions as both a vacuum and a mop. For vacuuming, ensure the dustbin is installed. For mopping, replace the dustbin with the water tank and attach a clean mop cloth. The intelligent control water tank offers three-level water outlet: gentle, standard, and strong, which can be controlled by the App.



2 in 1 Robot Vacuum and Mop Combo

The ILIFE V5s Plus offers both vacuuming and mopping capabilities.

4. Voice Control

The ILIFE V5s Plus is compatible with Amazon Alexa and Google Assistant. Connect your robot to your smart home system to start or stop cleaning tasks using voice commands.

Compatible with Amazon Alexa

Set cleaning schedules for voice control and hands-free convenience.



Control your robot with voice commands through Alexa or Google Assistant.

5. Automatic Charging

When the battery is low or a cleaning cycle is complete, the robot will automatically return to its charging dock. Ensure the charging dock is accessible and free from obstructions.



Always prepare for cleaning

V5s Plus automatically returns to the charging base when power is low, ensuring it's always charged and ready to vacuum

The robot automatically returns to its charging base when power is low.

Maintenance


Regular maintenance ensures optimal performance and extends the lifespan of your ILIFE V5s Plus.

1. Emptying and Cleaning the Dustbin

Open the top cover of the robot and remove the dustbin. Empty the dustbin into a trash receptacle. Clean the dustbin and filter with the provided cleaning tool or a soft brush. Rinse the dustbin with water if necessary, ensuring it is completely dry before reinstallation.

2. Filling and Cleaning the Water Tank

Remove the water tank from the robot. Open the water tank cap and fill it with clean water. Securely close the cap and reinsert the water tank into the robot. After mopping, empty any remaining water and rinse the tank. Allow it to air dry.



The water tank for the mopping function.

3. Cleaning Side Brushes

Regularly check the side brushes for tangled hair or debris. Remove any obstructions using the cleaning tool or scissors. Replace worn-out side brushes with new ones.

4. Cleaning Sensors

Wipe the anti-drop sensors and anti-collision sensors on the robot's underside and front bumper with a clean, dry cloth to ensure proper navigation.

Troubleshooting

If you encounter issues with your ILIFE V5s Plus, refer to the following common problems and solutions:

- **Robot does not power on:** Ensure the battery is charged. Check if the power switch on the side of the robot is turned on.
- **Robot does not charge:** Verify the charging dock is powered and the robot is correctly aligned with the charging pins. Clean the charging contacts on both the robot and the dock.
- **Robot gets stuck frequently:** Clear the cleaning area of obstacles. Check for tangled hair in the side brushes or wheels.
- **Poor cleaning performance:** Empty the dustbin and clean the filter. Clean the side brushes. Ensure the water tank is properly filled for mopping.
- **Unable to connect to App:**
 1. Make sure to select the correct Wi-Fi and login with the correct Wi-Fi password.
 2. The ILIFE Robot does not support 5G Wi-Fi. Make sure to use a 2.4G Wi-Fi connection.
 3. Make sure the Wi-Fi signal is covered and strong.
 4. Allow the ILIFEHOME APP to have access to your location services and wireless data.

Specifications

Feature	Detail
Brand	ILIFE
Model Name	V5s Plus
Surface Recommendation	Hard Floor
Suction Power	2 kpa
Usage Time	Up to 110 minutes
Water Tank Capacity	300mL
Dust Box Capacity	300mL
Dust Box Filter Type	High efficiency filter + nylon mesh
Cleaning Modes	Auto/Spot/Edge/Max
Control Type	Remote Control/ App Control/ Alexa/ Google Assistant
Product Dimensions	30L x 30W x 8.1H Centimetres
Battery Type	Lithium Ion
Voltage	110 Volts

Warranty

The ILIFE V5s Plus Robot Vacuum and Mop comes with a **1-year manufacturer's warranty**. Please retain your proof of purchase for warranty claims. The warranty covers defects in materials and workmanship under normal use. It does not cover damage caused by misuse, accidents, unauthorized modifications, or normal wear and tear.

Support

For further assistance, technical support, or warranty inquiries, please contact ILIFE customer service:

- **Email:** service_us_ca@iliferobot.com

Product Overview Video

Watch this video for a general overview of the ILIFE V5s Plus features and operation.

Your browser does not support the video tag.

Official product overview of the ILIFE V5s Plus Robot Vacuum and Mop.