Glocusent N13

Glocusent Portable Sound Machine N13 User Manual

Model: N13 | Brand: Glocusent

1. PRODUCT OVERVIEW

The Glocusent Portable Sound Machine N13 is a versatile device designed to create a calming audio environment for babies, children, and adults. It features a wide selection of non-looping sounds, a powerful speaker, and convenient portability for use at home or while traveling.

Image: Glocusent Portable Sound Machine N13 and its retail packaging.

2. PACKAGE CONTENTS

Upon unboxing, please ensure all items are present:

- 1 x Glocusent Portable Sound Machine N13
- 1 x USB-C Charging Cable
- 1 x Hanging Hook
- 1 x User Manual

Image: The Glocusent Portable Sound Machine N13, USB-C charging cable, hanging hook, and user manual.

3. SETUP

3.1 Charging the Device

Before first use, fully charge the sound machine using the provided USB-C cable. Connect the USB-C end to the device's charging port and the USB-A end to a compatible power adapter (not included).

Image: The sound machine attached to a stroller, illustrating its portability and long-lasting battery life.

3.2 Attaching the Hanging Hook

For portability, attach the included hanging hook to the designated loop on the device. This allows for easy attachment to strollers, cribs, or diaper bags.

3.3 Controls Overview

Familiarize yourself with the device's buttons for optimal use:

Image: A detailed diagram highlighting the functions of each button on the Glocusent Portable Sound Machine N13, including Play/Pause, Volume +/-, On/Off, Menu/OK, Previous, Next, Quick Soothing, and USB-C Port.

4. OPERATING INSTRUCTIONS

4.1 Power On/Off

Press and hold the power button to turn the device on or off.

4.2 Sound Selection

The device offers 62 non-looping sounds, including white noise, nature sounds (rain, ocean, thunder, birdsong), lullabies, and cheer-up music. Press the 'Sound' button (often indicated by music notes or a wave icon) and use the volume buttons to scroll through the options.

Image: A visual representation of the 62 non-looping sound categories available on the device, including Cheer Up Music, Lullaby, Calm Down Noise, and Sleep Aid Noise, shown in various settings with babies and adults.

4.3 Volume Adjustment

Press the 'Volume+' or 'Volume-' buttons to adjust the sound level. The device features a wide 0-80 dB volume range.

4.4 Timer Settings

To set an auto-off timer, press the 'Timer' button. Use the volume buttons to select the desired duration: 30, 60, 90, or 120 minutes. The device can also run continuously.

Image: The Glocusent Sound Machine next to a sleeping baby and adult, highlighting the four timer options (30, 60, 90, 120 minutes) for better sleep during travel.

4.5 Bluetooth Connectivity

The device can function as a wireless speaker. Enable Bluetooth on your smartphone or other device and select 'N13' from the available devices to connect. This allows you to play your own music, podcasts, or audiobooks.

4.6 Quick Soothing Feature

The Quick Soothing feature allows you to save a favorite sound for instant activation. This is useful for quickly calming a baby or for immediate relaxation.

Image: A split image showing a crying baby being soothed by the Glocusent Sound Machine using the Quick Soothing feature, transitioning to a happy baby.

4.7 Child Lock

Activate the child lock feature to prevent accidental changes to settings, ensuring uninterrupted use, especially around curious children.

Image: A baby crawling near the sound machine, with an illustration of the child lock icon, indicating the feature prevents accidental setting changes.

4.8 Product Usage Scenarios

The Glocusent Portable Sound Machine N13 is suitable for various situations:

- **Daytime Rest:** Helps create a peaceful environment for naps.
- **Traveling:** Compact design and hanging loop make it ideal for on-the-go use in strollers, car seats, or hotels.
- **Sleeping:** Masks disruptive noises for deeper, more restful sleep for all ages.
- **Working/Studying:** Provides background noise to enhance focus and reduce distractions.

Image: A four-panel image showing the Glocusent Sound Machine being used for daytime rest, while traveling with a baby, for sleeping, and during work.

5. MAINTENANCE

To ensure the longevity and optimal performance of your Glocusent Portable Sound Machine N13, follow these maintenance guidelines:

- **Cleaning:** Wipe the device with a soft, dry cloth. Do not use liquid cleaners or abrasive materials.
- **Storage:** Store in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** For best battery life, avoid fully discharging the battery frequently. Recharge when the battery indicator is low.

6. TROUBLESHOOTING

If you encounter any issues with your Glocusent Portable Sound Machine N13, please refer to the following common solutions:

- **Device not turning on:** Ensure the device is fully charged. Connect it to a power source using the provided USB-C cable.
- **No sound:** Check the volume level. Ensure the device is not muted or connected to headphones if not intended.
- **Bluetooth connection issues:** Ensure Bluetooth is enabled on your external device and the sound machine is in pairing mode. Try restarting both devices.
- **Buttons unresponsive:** Check if the child lock feature is activated. Deactivate it if necessary.

For further assistance, please contact Glocusent customer support.

7. SPECIFICATIONS

Feature	Detail
Product Dimensions	5.1 x 3.3 x 5.1 inches
Item Weight	7.09 ounces
Model Number	N13 (GLCSNTN1303)
Battery	1 Nonstandard Battery (2000mAh rechargeable)
Battery Life	Up to 30 hours of continuous use
Color	White
Material	Acrylonitrile Butadiene Styrene (ABS)
Power Source	Battery Powered
Sound Options	62 non-looping sounds
Speaker	5W stereo speaker
Volume Range	0-80 dB
Timer Settings	30/60/90/120 minutes, or continuous

8. SAFETY INFORMATION

Please read and adhere to the following safety guidelines:

- Do not use the device in the bath or near water.
- Use only the provided USB-C charging cable and a compatible power adapter to charge the device.
- Avoid exposure to loud noises for extended periods to prevent potential hearing damage.
- Keep out of reach of small children unless supervised, especially the charging cable and small parts.

9. WARRANTY AND SUPPORT

Glocusent offers a 60-day happiness promise for this product. The unique design is protected by an original patent, and the device is FCC, CPC & RoHS certified.

For any questions, concerns, or support needs, please refer to the contact information provided in your product packaging or visit the official Glocusent website.

10. INSTRUCTIONAL VIDEOS

10.1 Clear Operation Steps

Your browser does not support the video tag.

Video: A demonstration of the Glocusent Sound Machine's operation, including switching between 4 modes, Bluetooth connection, quick soothing, and child lock features.

10.2 Portable White Noise Machine Overview

Your browser does not support the video tag.

Video: An overview of a portable white noise machine, highlighting its long-lasting battery and suitability for babies.

10.3 Sleep Music Portable Preview

Your browser does not support the video tag.

Video: A brief preview showcasing the portable sleep music function of the device.

Related Documents - N13

GLOCUSENT PORTABLE SOUND MACHINE — glocusent | Light Up Your Chapters	**Glocusent Portable Sound Machine N14 User Manual and Features** Detailed guide for the Glocusent Portable Sound Machine N14, covering its features, functions, specifications, charging instructions, precautions, and customer support. Includes multilingual content summary.
glocusent — RECHARGEABLE MUSIC STAND LIGHT	**Glocusent Rechargeable Music Stand Light - User Guide & Specifications** Detailed information about the Glocusent Rechargeable Music Stand Light (Model A16), including features, specifications, instructions, and support. Features 57 LED beads, adjustable brightness and color temperature, and a long-lasting battery.
	Glocusent 16LEDs Clip-on Mini Book Light: User Manual and Specifications Comprehensive user guide and technical specifications for the Glocusent 16LEDs Clip-on Mini Book Light. Discover its features including 16 LEDs, 3 color modes (amber, warm, natural), 5 brightness levels, and up to 80 hours of battery life. Learn operation, charging, and maintenance.

[Glocusent Innovative Rotatable Book Light - User Manual and Specifications](#)
Detailed information and specifications for the Glocusent Innovative Rotatable Book Light, including features, instructions, precautions, and product details.

[Glocusent Upgraded LED Neck Reading Light: User Guide, Features, and Specifications](#)
Explore the Glocusent Upgraded LED Neck Reading Light. This guide provides detailed instructions on operation, charging, and specifications, along with insights into the product's design and company philosophy. Features adjustable brightness and color temperatures for optimal reading comfort.

[Glocusent Rechargeable Camping Lantern User Manual](#)
Comprehensive user manual for the Glocusent Rechargeable Camping Lantern, detailing features, instructions, precautions, and specifications. Learn how to use and maintain your lantern for various outdoor and emergency situations.