

[Manuals.plus](#) /

› [AROEVE](#) /

› AROEVE 2.5L Humidifier with Essential Oil Diffuser (Model DH-JSD06) - User Manual

AROEVE DH-JSD06

AROEVE 2.5L Humidifier with Essential Oil Diffuser

Model: DH-JSD06

INTRODUCTION

Thank you for choosing the AROEVE 2.5L Humidifier with Essential Oil Diffuser. This manual provides important information regarding the safe operation, setup, maintenance, and troubleshooting of your new humidifier. Please read it thoroughly before use and retain it for future reference.

IMPORTANT SAFETY INSTRUCTIONS

- Always place the humidifier on a firm, flat, waterproof surface at least 15 cm (6 inches) away from walls and appliances.
- Do not place the humidifier on carpets, towels, or any soft surfaces that may block the bottom air inlet.
- Keep the humidifier out of reach of children and pets.
- Do not immerse the base unit in water or other liquids.
- Use only clean, cool tap water. Distilled or demineralized water is recommended to prevent mineral buildup.
- Only add water-soluble essential oils to the designated essential oil compartment. Non-soluble oils can damage the device and reduce its effectiveness.
- Unplug the humidifier before filling, cleaning, or moving it.
- Do not block the mist outlet.
- If the humidifier emits an unusual smell or sound, unplug it immediately.
- This appliance is for household use only.

PACKAGE CONTENTS

- AROEVE 2.5L Humidifier
- Water Tank
- Power Cable
- Instruction Manual

PRODUCT OVERVIEW

The AROEVE 2.5L Humidifier is designed to provide optimal humidity for rooms up to 25 m², featuring a large water tank, quiet operation, and aromatherapy capabilities.

Sommeil Paisible pour Enfants

Brumes Douces Nuit Silencieuse

25 h

Durée Maximale

25dB

Notre humidificateur

35dB

Autres humidificateurs

20dB

Bruissement de feuilles

25dB Ultra-silencieux

Lumière Désactivable

Note : 25dB (test labo, réglage minimal). Pour un fonctionnement ultra-silencieux : utiliser le mode basse vitesse

This image illustrates the humidifier's large 2.5-liter water tank, providing up to 25 hours of continuous operation on the lowest setting.

Alivio Cutáneo & Bienestar Emocional

Aire Agradable Ambiente Reconfortante

5µm

Niebla Micro

15min

Alivio Rápido

35cm

Alcance de Niebla

Nota: Usar únicamente aceites esenciales hidrosolubles. Los aceites puros pueden dañar el dispositivo y afectar la difusión. Duración máxima de 25 horas (prueba de laboratorio en configuración mínima). La duración real puede variar según la humedad ambiental

The image highlights the humidifier's ability to produce a fine 5-micrometer mist, reaching a height of 35 cm for quick humidification within 15 minutes.




This visual shows the humidifier's effective coverage area of 20-25 square meters, with a mist output of 250 ml per hour, suitable for maintaining optimal humidity.

SETUP

1. Placement

Place the humidifier on a flat, stable surface. Ensure there is enough space around the unit for proper air circulation. Avoid placing it directly on wooden furniture or near heat sources.

Humedad Jungla para 25m²



Important placement guidelines: Ensure the humidifier is not placed on soft surfaces like carpets or towels, which can block the air inlet. Also, avoid enclosing the unit to ensure proper mist flow and prevent damage.

2. Filling the Water Tank

The AROEVE humidifier offers two convenient ways to fill the water tank:

1. **Top-Fill Method:** Simply pour clean, cool tap water directly into the top opening of the humidifier until it reaches the

'Max' line.

2. **Removable Tank Method:** Carefully lift the water tank from the base. Carry it to a sink, remove the lid, and fill it with clean, cool tap water. Replace the lid securely and place the tank back onto the base.

Note: Do not exceed the 'Max' fill line. Use distilled or demineralized water for best results and to minimize mineral buildup.

2 Formas de Llenado

Verter por Arriba o Quitar Tanque

Diseño de Llenado Superior Fácil



Tanque Extraíble Conveniente



The humidifier offers convenient top-filling or the option to remove the water tank for refilling and easy cleaning.

3. Initial Use

After filling the water tank, plug the power cable into a suitable electrical outlet. The humidifier is now ready for operation.

OPERATION

1. Power On/Off and Mist Output Adjustment

Turn the rotary knob on the front of the unit clockwise to turn the humidifier ON. Continue turning the knob to adjust the mist output from minimum (ON) to maximum (MAX). Turn the knob counter-clockwise to turn the humidifier OFF.

2. Aromatherapy Function

To use the aromatherapy function, add a few drops of **water-soluble** essential oil directly into the designated essential oil compartment located on the top of the unit. Do not add essential oils directly into the water tank, as this can damage the humidifier.

Compatible con Aceites Esenciales Refresca el Aire y el Ánimo



Nota: Solo aceites esenciales hidrosolubles. Los oleosos dañan el dispositivo

The humidifier doubles as an aromatherapy diffuser. Add water-soluble essential oils to the designated area to refresh the air and enhance your mood. Only use water-soluble oils to prevent damage.

3. LED Light Control

The humidifier features 7 adjustable LED colors. Press the 'OFF/ON' button located below the rotary knob to cycle through the light modes or turn the light off completely. This allows for a customizable ambient lighting experience, ideal


for night use.

Humidifica en tu Tono Favorito

Niebla Cambia Color – Sincroniza con tu Emoción



Luz RGB Ajustable:



Estudio



Juego



Sueño



Música



Meditación

Customize your environment with 7 adjustable LED colors. The RGB lighting can be set to match your mood or preference, creating a relaxing or stimulating atmosphere.

Humidificación Nocturna: Silencioso y Oscuro

Susurro-
Silencioso
25dB

Luz
Ajustable
(Apagable)

25dB
Nuestro Humidificador

20dB
Crujido de Hojas

35dB
Otros Humidificadores

Nota: 25 dB (prueba lab, mínimo ajuste). Ultra silencioso: modo baja velocidad

Designed for quiet night operation, the humidifier produces only 25dB of sound. The adjustable LED light can be turned off completely for an undisturbed sleep environment.

4. Automatic Shut-off

The humidifier is equipped with an automatic shut-off feature that activates when the water level is too low or the water tank is removed from the base. This ensures safety and prevents damage to the unit.

MAINTENANCE AND CLEANING

Regular cleaning is essential for optimal performance and hygiene.

1. Daily Maintenance

- Empty the water tank and rinse it with fresh water daily.
- Wipe the base unit with a clean, damp cloth.

2. Weekly Cleaning

- Unplug the humidifier and remove the water tank.
- Pour out any remaining water from the tank and base.
- Fill the water tank halfway with water and add 1-2 tablespoons of white vinegar. Shake gently and let it sit for 30 minutes.
- Clean the inside of the water tank and the base with a soft brush or cloth to remove any mineral buildup or residue.
- Rinse all components thoroughly with clean water until the vinegar smell is gone.
- Allow all parts to air dry completely before reassembling.

3. Storage

If the humidifier will not be used for an extended period, clean it thoroughly as described above, ensure all parts are dry, and store it in a cool, dry place.

TROUBLESHOOTING

Problem	Possible Cause	Solution
No mist or low mist output	Low water level Mineral buildup Mist outlet blocked	Refill water tank Clean the transducer and water tank Ensure mist outlet is clear
Unusual odor	Stagnant water New unit odor	Clean water tank and replace water The odor should dissipate after initial uses
Water leakage	Water tank not properly seated Overfilled tank Damaged tank	Ensure tank is correctly placed Do not overfill past 'Max' line Contact customer support if damaged
Humidifier not turning on	Not plugged in No power Water tank empty	Check power connection Check power outlet Refill water tank

SPECIFICATIONS

Feature	Specification
Brand	AROEVE
Model Number	DH-JSD06

Feature	Specification
Capacity	2.5 Liters
Mist Output	250 ml/h
Max Runtime	25 hours (on low setting)
Coverage Area	20-25 m²
Noise Level	25 dB (on low mode)
Special Features	Aroma Diffuser, 7-Color LED Light, Automatic Shut-off, Top-fill Design
Voltage	220 Volts (AC)
Dimensions (D x W x H)	17.6 x 17.6 x 29 cm
Weight	1.06 Kilograms
UPC	850070209588
Country of Origin	China

WARRANTY AND SUPPORT

AROEVE products are manufactured to high-quality standards. For warranty information or technical support, please refer to the contact details provided with your purchase or visit the official AROEVE website. Please have your model number (DH-JSD06) and purchase details ready when contacting support.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0FHWCCWVK>

More documents and user manuals: <https://manuals.plus/>