

[Manuals.plus](#) /

› [Dremel](#) /

› Dremel 8150 8V Cordless Rotary Tool Kit Instruction Manual

## Dremel 8150

# Dremel 8150 8V Cordless Rotary Tool Kit Instruction Manual

## 1. PRODUCT OVERVIEW

The Dremel 8150 is a compact, cordless 8V rotary tool designed for a variety of tasks. It features a powerful brushless motor and an integrated battery, providing performance for home improvement projects, crafting, and detailed work. This multi-tool is suitable for engraving, cutting, sanding, and sharpening, offering flexibility and control.



Figure 1: Dremel 8150 8V Cordless Rotary Tool with included accessories.

## Key Features:

- **8V Brushless Motor:** Provides consistent power and extended runtime for various applications.
- **Integrated LED Nose Cap:** Illuminates the work area for improved visibility during intricate tasks.
- **Variable Speed Control:** Adjustable speed range from 5,000 to 30,000 RPM for precise control over different materials and tasks.
- **USB-C Charging:** Offers convenient and universally compatible charging.
- **Ergonomic Design:** Features a pencil-like grip for enhanced comfort and control during use.
- **Accessory Compatibility:** Fully compatible with all Dremel rotary tool accessories and attachments.



Figure 2: Detailed view of Dremel 8150 features including LED, battery gauge, speed control, brushless motor, and USB-C charging port.

## 2. SETUP

## 2.1 Charging the Tool

Before first use, fully charge the Dremel 8150. The tool comes with a USB-C charging cable. Connect the cable to the tool's USB-C port and plug the other end into a compatible USB power adapter (not included). Ensure the power adapter meets the manual's specifications. Only use the provided charging cable to prevent damage or fire hazards. The battery indicator lights will show the charging status.



Figure 3: The Dremel 8150 connected for USB-C charging.

## 2.2 Installing Accessories

To install an accessory:

1. Ensure the tool is turned off.
2. Press and hold the shaft lock button.
3. Unscrew the collet nut.
4. Insert the desired accessory shank into the collet.

5. Tighten the collet nut securely while still holding the shaft lock button.
6. Release the shaft lock button.

Video 1: Unboxing and initial setup of the Dremel 8150 Rotary Tool Kit, demonstrating how to install accessories.

## 3. OPERATION

---

### 3.1 Power On/Off

To turn the tool on, press the power button. The LED light will illuminate, and the tool will start at the last used speed setting. To turn off, press the power button again.

### 3.2 Adjusting Speed

The Dremel 8150 features variable speed control. Use the speed adjustment dial or buttons to select the desired RPM (Revolutions Per Minute) for your task. Lower speeds (5,000-15,000 RPM) are suitable for delicate work like polishing or fine engraving, while higher speeds (15,000-30,000 RPM) are ideal for cutting, grinding, and deburring.



Figure 4: The adjustable LED Nose Cap and speed control mechanism on the Dremel 8150.

Video 2: Demonstrates the features and benefits of the Dremel 8150 Rotary Tool, including speed adjustment.

### 3.3 Common Applications

The Dremel 8150 is versatile and can be used for:

- **Cutting:** Use appropriate cutting wheels for various materials.
- **Sanding:** Utilize sanding bands or discs for smoothing surfaces.
- **Polishing:** Apply polishing accessories for a refined finish.
- **Grinding:** Use grinding stones for shaping and deburring.
- **Engraving:** Employ engraving cutters for detailed designs.
- **Drilling:** Compatible with small drill bits for precision holes.

# DREMEL 8150

## Small Tool, Big Utility



Figure 5: Visual examples of the Dremel 8150 in use for cutting, sanding, polishing, drilling, grinding, and engraving.

Video 3: An overview of the Dremel 8150 8V Rotary Tool, showcasing its capabilities and ease of use.

## 4. MAINTENANCE

Regular maintenance ensures optimal performance and extends the life of your Dremel 8150.

- **Cleaning:** Disconnect the power source before cleaning. Use a soft, dry cloth to wipe down the tool. Do not use harsh chemicals or abrasive cleaners.
- **Accessory Care:** Clean accessories after each use to remove debris and maintain their effectiveness. Store them in the provided accessory case.
- **Storage:** Store the tool in a dry, clean place, away from direct sunlight and extreme temperatures.

## 5. TROUBLESHOOTING

Refer to the table below for common issues and their solutions.

| Problem                   | Possible Cause              | Solution                                                                                                              |
|---------------------------|-----------------------------|-----------------------------------------------------------------------------------------------------------------------|
| Red light flashes 1 time  | Low power                   | Charge the machine.                                                                                                   |
| Red light flashes 2 times | Overcurrent / Short circuit | 1. The machine is blocked; check operating conditions. 2. Restart the machine. 3. If fault persists, send for repair. |
| Red light flashes 3 times | Temperature protection      | Cool down the machine to room temperature (approx. 25°C) and wait at least 30 minutes.                                |

## 6. SPECIFICATIONS

- **Brand:** Dremel
- **Model Number:** 8150-N/20
- **Voltage:** 8 volts
- **Power Source:** Battery Powered
- **Minimum Rotational Speed:** 5,000 rpm
- **Maximum Rotational Speed:** 30,000 rpm
- **Item Dimensions (LxWxH):** 8.27 x 1.77 x 1.38 inches
- **Number of Batteries:** 1 Nonstandard Battery (included)
- **Color:** Gray
- **Special Features:** Compact, LED Nose Cap

## 7. INCLUDED COMPONENTS & ACCESSORIES

The Dremel 8150 Kit includes the following:

- Dremel 8150 8V Cordless Rotary Tool
- USB-C Charging Cord
- Accessory Storage Case
- Assortment of 20 Rotary Tool Accessories, including:
  - 191 - Ball Profile Engraving Cutter
  - 932 - Aluminum Oxide Grinding Stone
  - 407 - 1/2 inch Sanding Band (Coarse)
  - 408 - 1/2 inch Sanding Band (Medium)
  - 432 - 1/2 inch Sanding Band (Fine)
  - 426 - 1-1/4 inch Fiberglass Reinforced Cut-Off Wheel

The tool is compatible with a wide range of other Dremel accessories and attachments, sold separately, to expand its functionality.

# DREMEL 8150

## Kit Contents



Figure 6: All components included in the Dremel 8150 Kit.

## 8. WARRANTY INFORMATION

The Dremel 8150 8V Cordless Rotary Tool Kit comes with a **Limited 2-Year Manufacturer's Warranty**. Please refer to the official Dremel warranty documentation for full terms and conditions, including coverage details and how to make a claim.

## 9. CUSTOMER SUPPORT

For further assistance, technical support, or to inquire about additional accessories, please visit the official Dremel website or contact Dremel customer service. Contact information can typically be found in the packaging or on the manufacturer's website.

## ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

### Name

Anonymous

### Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

### Question

Example: How do I reset this device or fix this error?

### Details

Model number, symptoms, what you tried, or the section of the manual you are using.

**Submit question**