

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

- › [Soundcore](#) /
- › [Soundcore Liberty Buds by Anker Instruction Manual](#)

Soundcore D1200

Soundcore Liberty Buds by Anker Instruction Manual

Model: D1200

Introduction	What's in the Box	Setup	Operating Instructions	Maintenance	Troubleshooting
		Specifications	Warranty & Support		

INTRODUCTION

This manual provides detailed instructions for the setup, operation, maintenance, and troubleshooting of your Soundcore Liberty Buds by Anker. Please read this manual thoroughly before using your earbuds to ensure optimal performance and longevity.

WHAT'S IN THE BOX

Verify that all items are present in the package:

- Soundcore Liberty Buds
- Charging Case
- Ear Fins (Sizes 0, 1, 2, 3)
- USB-C Cable



Image: Contents of the Soundcore Liberty Buds package.

SETUP

1. Wearing the Earbuds and Choosing Ear Fins

For optimal sound quality and comfort, it is crucial to select the correct ear fin size and ensure a secure fit. The Liberty Buds come with four sizes of ear fins (0, 1, 2, 3) to accommodate various ear shapes.

1. Open the package and take out the accessories from the box.
2. Choose the ear fin size that fits you best and remove the ear fin as per the instructions in the Quick Start Guide (QSG).
3. Hold the ear fin and pull outward, then install the right-sized ear fin onto the earbud.
4. Adjust the earbud so it fits snugly in your ear canal.
5. If you prefer the size 0 ear fin, remove the pre-installed size 2 ear fin and store it back in the appropriate slot.

Your browser does not support the video tag.

Video: Instructions on how to correctly wear Soundcore Liberty Buds and select the appropriate ear fin size.

All-Day Listening



ANC Off

7H per Charge
30H with Case


ANC On

6H per Charge
26H with Case

10 Mins = 4 Hrs
Fast Charging

Image: Diagram illustrating the process of selecting and installing ear fins for a secure fit.

Removable Ear Fins: More Secure Fit



Choose the fins size


step 1

Remove the
attached
ear fins.



step 2

Select your
ear fins.



step 3

Install them on the
earbuds and rotate to
the desired position.

*Note: A loose fit or gaps between the earbud and your ear canal may affect noise-cancellation performance. Adjust the angle and/or try different ear fins.

Image: Visual guide to checking the fit of the earbuds, demonstrating how a proper fit enhances noise cancellation.

2. Initial Bluetooth Pairing

1. Ensure the earbuds are in the charging case with the lid open.
2. On your device (smartphone, tablet, etc.), navigate to the Bluetooth settings.
3. Select "Soundcore Liberty Buds" from the list of available devices to pair.
4. Once connected, you will hear an audio prompt confirming successful pairing.

OPERATING INSTRUCTIONS

Adaptive Noise Cancelling (ANC)

The Liberty Buds feature Adaptive ANC, which monitors your surroundings in real time. It detects environmental sounds such as traffic, voices, and wind noise, then automatically adjusts the level of noise cancellation for optimal performance. This ensures a quieter listening experience tailored to your environment.




Image: Demonstrating the Real-Time Adaptive ANC feature in an outdoor setting.

Spatial Audio

Experience an immersive audio profile with Spatial Audio, providing a well-balanced sound across all frequencies. This feature enhances every layer and detail of your music, whether you are listening to pop, classical, or electronic genres.

Immersive Spatial Sound




Image: A user enjoying Immersive Spatial Sound with Soundcore Liberty Buds.

AI Translation

Break down language barriers with the real-time face-to-face translation feature, supporting over 100 languages. The earbuds accurately recognize complex sentences and diverse accents, with an accuracy rate exceeding 97%.

4-Mic AI Clear Calls

The smart noise reduction algorithm, combined with a 4-microphone array, precisely identifies and separates your voice from background noise. This ensures your calls are consistently clear and smooth, similar to a face-to-face conversation.

Battery Life and Charging

The Soundcore Liberty Buds offer extended battery life:

- **Standard Mode:** Up to 7 hours of playback on a single charge, and a total of 30 hours with the charging case.
- **ANC On:** Up to 6 hours of listening on a single charge, and up to 26 hours with the charging case.

The earbuds also support fast charging, providing 4 hours of playtime from just a 10-minute charge.

Designed for Comfort and Stability



Semi-in-ear fit with detachable ear fins for a secure, pressure-free experience.

Image: Overview of battery life and fast charging features.

Dual Device Connection

The Liberty Buds can connect to two devices simultaneously, allowing for seamless audio switching between them. This feature is particularly useful for users who frequently switch between a phone and a tablet or computer.

1. After connecting your earbuds to your primary device (e.g., phone), open the Soundcore app.
2. Navigate to **More Settings** > **Dual Connections** > **Connect New Device**. The earbuds will enter pairing mode, allowing them to connect to a new device.
3. On your second device (e.g., tablet), open Bluetooth settings and pair with "Liberty Buds".

Audio playback on the earbuds will seamlessly switch between the two devices based on which device is actively playing audio.

Your browser does not support the video tag.

Video: Guide on how to connect Soundcore Liberty Buds to two devices simultaneously.

Touch Controls

The Liberty Buds feature touch controls for managing playback, calls, and noise cancellation modes. Specific touch gestures can be customized via the Soundcore app.

- **Single Tap:** Play/Pause, Answer/End Call
- **Double Tap:** Next Track, Reject Call
- **Press and Hold:** Switch ANC modes (Noise Cancellation, Normal, Transparency), Activate Voice Assistant

Refer to the Soundcore app for detailed customization options for touch controls.

MAINTENANCE

Cleaning Your Earbuds

Regular cleaning helps maintain sound quality and hygiene. You will need alcohol wipes and a small cleaning brush.

1. Prepare a cleaning brush and alcohol wipes.
2. Gently brush the sound nozzle mesh/rear vent hole, mic hole, and pogo pin contacts for about 15 seconds to remove any debris.
3. Wipe clean using the alcohol wipes.
4. After cleaning, let the earbuds dry for about 5 minutes before reconnecting them to your phone for use.

Your browser does not support the video tag.

Video: Detailed instructions on how to deep clean Soundcore Liberty Buds.

Water Resistance

The Soundcore Liberty Buds are water resistant, providing protection against splashes and sweat. However, they are not designed for submersion in water. Ensure the earbuds are dry before placing them back in the charging case to prevent damage.

TROUBLESHOOTING

Resetting Your Earbuds

Some product issues, such as being unable to pair, no sound coming from one earbud, or touch controls not working, can be resolved by resetting the earbuds.

1. With the case's lid open, press the button on the charging case for 10 seconds to reset the earbuds.
2. The LED indicator will flash white quickly 3 times, indicating that the earbuds have been reset.

Your browser does not support the video tag.

Video: Instructions on how to reset Soundcore Liberty Buds.

Common Issues and Solutions

- **Poor Fit / Earbuds Falling Out:** Ensure you have selected the correct ear fin size. Experiment with different

sizes (0, 1, 2, 3) and adjust the earbud's position in your ear for a snug fit. A loose fit can negatively impact sound quality and noise cancellation.

- **ANC Not Effective:** The effectiveness of Adaptive ANC is highly dependent on a proper earbud fit. Re-adjust the earbuds and try different ear fin sizes to achieve a better seal.
- **Sound Quality Issues (Anemic/Weak Sound):** If the sound appears weak after turning on or after a period of inactivity, try toggling the ANC mode on and off, or playing loud/bassy audio to re-engage the full sound profile. Ensure the earbuds are clean and free of debris.
- **Connectivity Problems:** If earbuds fail to connect or maintain connection, try resetting them as described above. Ensure your device's Bluetooth is enabled and the earbuds are within range.

SPECIFICATIONS

Feature	Detail
Model Name	Liberty Buds
Model Number	D1200
Brand	Soundcore
Noise Control	Adaptive Noise Cancellation
Connectivity Technology	Wireless (Bluetooth)
Bluetooth Version	6.1
Audio Driver Type	Dynamic Driver
Audio Driver Size	11 Millimeters
Frequency Response	40 KHz
Sensitivity	122 dB
Impedance	14 Ohms
Battery Life (Standard Mode)	Up to 7 hours (earbuds), 30 hours (with charging case)
Battery Life (ANC On)	Up to 6 hours (earbuds), 26 hours (with charging case)
Control Type	Touch Control
Water Resistance Level	Water Resistant (IP55)
Item Weight	54.12 Grams (total)
Product Dimensions	2.22 x 2.13 x 1.05 inches
Special Features	AI Translation, Adaptive ANC, Semi-In-Ear Design
Included Components	Charging Case, Ear Fins (Sizes 0, 1, 2, 3), USB-C Cable, Soundcore Liberty Buds

WARRANTY & SUPPORT

Soundcore products are backed by a limited warranty. For detailed warranty information, product registration, and

technical support, please visit the official Soundcore website or contact customer service. Keep your purchase receipt for warranty claims.

Online Support: [Soundcore Support Page](#)