

[Manuals.plus](#) /

› [Voice Caddie](#) /

› Voice Caddie T11 LT GPS Golf Watch Instruction Manual

Voice Caddie T11 LT

Voice Caddie T11 LT GPS Golf Watch Instruction Manual

MODEL: T11 LT

Brand: Voice Caddie

INTRODUCTION

The Voice Caddie T11 LT GPS Golf Watch is designed to enhance your golf game with advanced features and precise yardage information. This manual provides detailed instructions for setup, operation, and maintenance to ensure you get the most out of your device.

Key Features:

- **GREEN UNDULATION TECHNOLOGY:** Accurately maps the terrain with heat maps and arrows to show green break direction and elevation changes, giving you a competitive edge in reading greens and planning your putts.
- **ADVANCED SHOT & PUTT TRACKING:** Automatically logs scores for both left- and right-handed golfers, letting you focus on your game without manual entries.
- **SMART GREEN & PUTT VIEW:** Shows pin placement, elevation, distance to pin, and green break direction using heat maps and arrows for better shot planning.
- **FULL-COLOR TOUCHSCREEN:** Provides clear, easy-to-read front, center, and back green yardages with intuitive visuals to improve gameplay accuracy.
- **OVER 40,000 PRELOADED COURSES:** Enjoy access to a vast library of courses worldwide, with no subscriptions or additional fees, for an uninterrupted golfing experience.

SETUP

1. Power On

To power on your T11 LT, press and hold the power button located on the top right side of the watch for 3 seconds. The Voice Caddie logo will appear, indicating the device is starting up.



Image: The T11 LT Golf Watch displaying the time and various functions on its main screen after powering on.

2. Bluetooth Connection

Swipe down on the watch face to access the quick settings menu. Tap the Bluetooth icon to enable Bluetooth. Once active, open the MyVoiceCaddie app on your smartphone and follow the on-screen prompts to pair your watch. This allows access to features like Quick GPS, wind direction/speed check, and action key settings.



DELIVERS PRO LEVEL FEATURES

1.2" TOUCH SCREEN

V-ALGORITHM 3.0

40,000 PRE LOADED
WORLDWIDE COURSES

GREEN UNDULATION

27 HOLE
BATTERY LIFE

LIGHTWEIGHT
1.70Z

LEFT-HANDED
COMPATIBILITY



Image: The T11 LT Golf Watch displaying the Bluetooth connection screen, showing the device ID and a toggle switch for activation.

3. Golf Mode Connection

From the main menu, tap the 'START' button to enter Golf Mode. The watch will automatically recognize the golf course and hole via GPS. If 'Start Golf Mode Directly' is enabled in settings, the watch will enter Golf Mode automatically upon power-on without intermediate steps.

Your browser does not support the video tag.

Video: A detailed overview of the T11 Pro's Golf Mode connection process, showing how to initiate a round and automatic course recognition.

OPERATING

1. Course View

The Course View displays the overall layout of the hole, including distances to the pin, previous shot distance, hole information (par), driver distance arc, dual pin arc, and wind direction/speed. Long-pressing on the Course View will zoom in for a more

detailed look at hazards and club recommendations.



Image: The T11 LT Golf Watch displaying the Course View with distances to the pin, driver arc, and wind speed.

Your browser does not support the video tag.

Video: Demonstrates the Course View, showing distances to the pin, previous shot distance, and other hole information. It also highlights the wind direction and speed feature.


2. Approach View

Swipe left from the Course View to access the Approach View. This screen provides distances to the back, middle, and front of the green, along with the previous shot distance. The Active Green View feature automatically rotates the green to show it according to your standing direction.

POWERED BY V.AI 3.0




**Experience Unmatched Yardage Accuracy
Through Cutting-Edge Technology**



**GREEN
UNDULATION**



**LCD
DISPLAY**



**AUTO
SLOPE**

Image: The T11 LT Golf Watch displaying the Approach View with distances to the front, middle, and back of the green, along with green undulation data.

Your browser does not support the video tag.

Video: Illustrates the Approach View, showing distances to various points on the green and how the view automatically adjusts based on the user's position.

3. Putt View

The Putt View automatically activates when you arrive on the green. It displays the distance to the pin and the slope towards the pin. You can tap the ball icon to fix its position and get precise distance readings. The Smart Putt View provides aiming directions for left/right and uphill/downhill slopes.

GREEN UNDULATION

DISPLAYS PRECISE FLOW DIRECTION AND CLEAR GREEN CONTOURS WITH ELEVEN DISTINCT COLOR LEVELS FOR ENHANCED VISUALIZATION



Image: The T11 LT Golf Watch displaying the Putt View with green undulation heat map, distance to pin, and slope information.

Your browser does not support the video tag.

Video: Shows the Putt View, demonstrating how to get distance and slope information for putting, including Smart Putt View aiming guidance.

4. Shot & Putt Tracking

The watch automatically recognizes and tracks your shots and putts. A red marker indicates a shot, and a blue marker indicates a putt. Up to 5 shot markings can be displayed, with older marks being deleted sequentially if more are recorded. This allows you to review your play record for the current hole.

ALL-IN-ONE GOLF COMPANION:

MYVOICECADDIE APP (MVC) PROVIDES ROUND STATISTICS, SCORECARD, TRACKING, PLUS MORE



Available on the
App Store

Available on
Google Play

Image: The T11 LT Golf Watch displaying the Shot & Putt Tracking feature, showing automatic shot detection and marking on the course map.

5. Tempo Practice Mode

Practice your swing with consistent tempo using the Tempo Practice Mode. The watch displays your backswing and downswing tempo, indicating if it's too fast (red), too slow (yellow), or optimal (blue). You can also input the club used to track shot data.

TEMPO PRACTICE MODE

DIAL IN YOUR SWING TEMPO WITH PRECISION—TEMPO PRACTICE MODE TIMES YOUR SWING SO YOU CAN TRAIN CONSISTENTLY, WHETHER YOU'RE INDOORS OR ON THE RANGE.



Image: The T11 LT Golf Watch displaying the Tempo Practice Mode with visual feedback for fast, optimal, and slow swing tempos.

MAINTENANCE

1. Device Charging

The T11 LT supports wireless charging via the included Smart Cradle. Attach the watch to the cradle and press the power button on the front of the cradle to begin charging. The battery level is indicated by color: red (1-29%), yellow (30-59%), and green (60-100%).



Image: The T11 LT Golf Watch placed on its charging cradle, showing the charging indicator on the watch face.

Your browser does not support the video tag.

Video: Demonstrates how to charge the T11 Pro using the Smart Cradle, showing the charging process and battery level indicators.

CUSTOMIZATION

1. Custom Screen Setting

Customize various features to your preferences by toggling them on or off via the MyVoiceCaddie app settings. This allows you to

turn on/off necessary functions according to the situation and display only the desired functions, such as common view, course view, approach view, etc.



Image: The T11 LT Golf Watch displaying a customizable screen with various toggles for features like Shot & Putt Indicator, Wind Direction/Speed, and Driver Distance Arc.

2. Action Key

The Action Key feature allows you to quickly access desired functions. Similar to custom screen settings, this feature can be configured in the MyVoiceCaddie app. You can set the power button to quickly access specific screens like V.AI, Move View, Quick Menu, Scorecard, or Club Input.



Image: The T11 LT Golf Watch displaying the Action Key settings menu within the MyVoiceCaddie app, showing options for quick access to various features.

3. Quick Menu

On the golf mode screen, swipe up to access the Quick Menu. This menu allows you to quickly access features such as Course Preview, Flashback (review previous hole records), Green Pointing (compass pointing to green center), and Golf Settings.



Image: The T11 LT Golf Watch displaying the Quick Menu with options like Pre-View, FlashBack, Pointing, and Golf Option.

4. Change Watch Face

Long-pressing on the watch face screen enables you to configure the watch face. You can swipe left or right to select the desired screen and tap to change the color. This allows for personalization of your device's appearance.



Image: The T11 LT Golf Watch displaying various watch face options, allowing the user to customize the appearance.

SPECIFICATIONS

Item Weight	1.7 ounces
Product Dimensions	1.8 x 1.8 x 0.52 inches
Item model number	T11 LT
Batteries	1 Nonstandard Battery batteries required.
Display Size	1.2 Inches
Battery Life	7 Hours
Voice command	Touchscreen

Special Feature	GPS, Lightweight, Touchscreen
Connectivity Technology	Bluetooth, USB
Map Type	Worldwide
Mounting Type	Wrist Mount
Operating System	Proprietary OS

WHAT'S IN THE BOX

- User Manual
- Charging Cable
- Watch Band

WARRANTY

The Voice Caddie T11 LT GPS Golf Watch comes with a 1-Year Manufacturer Warranty. Please refer to the warranty card included in the packaging for detailed terms and conditions.

SUPPORT

For technical assistance, troubleshooting, or any questions regarding your Voice Caddie T11 LT GPS Golf Watch, please visit the official Voice Caddie support website or contact customer service. Contact information can be found in the user manual included in the box.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question