



[Manuals.plus](#) /

> [nesture.](#) /

> nesture. Twin Over Twin Bunk Bed User Manual

**nesture. B0FJ1MBHCM**

# nesture. Twin Over Twin Bunk Bed User Manual

Model: B0FJ1MBHCM

## 1. INTRODUCTION

---

This user manual provides comprehensive instructions for the assembly, operation, and maintenance of your nesture. Twin Over Twin Bunk Bed. Please read this manual thoroughly before assembly and retain it for future reference.



Image: Fully assembled nesture. Twin Over Twin Bunk Bed in black, showcasing its robust design and space-saving structure.

## 2. SAFETY INFORMATION

---

Your safety is paramount. Please adhere to all safety guidelines to prevent injury or damage.

- Always follow assembly instructions carefully.
- Ensure all bolts and fasteners are securely tightened before use.
- Do not allow children under 6 years of age on the upper bunk.
- Use the provided wall anchoring device to prevent tipping.
- Regularly check all connections to ensure they remain tight.
- Do not use substitute parts. Only use parts provided by the manufacturer.
- Ensure the mattress thickness is appropriate for the bunk bed to maintain guardrail effectiveness.

# Anti-Tipping Device Mounted to the Wall

Keep family in safety



Image: Detail of the anti-tipping device, demonstrating how it secures the bunk bed to the wall for enhanced stability and safety.

## 3. PACKAGE CONTENTS

---

Verify that all components are present before beginning assembly. If any parts are missing or damaged, contact customer support.

- Bunk Bed Frame x 1
- Guardrails (pre-attached or separate)
- Robust Slats x 22
- Assembly Hardware (bolts, nuts, washers, etc.)
- Installation Manual
- Assembly Tools (Allen wrench, etc.)

# PRODUCT SIZE




Image: A diagram illustrating the overall dimensions of the bunk bed and indicating that all components are shipped in a single box.

## 4. SETUP AND ASSEMBLY

Assembly typically requires two adults. Follow the numbered steps in the included installation manual.

1. Unpack all components and lay them out on a clean, soft surface to prevent scratches.
2. Identify all parts using the provided parts list.
3. Begin by assembling the headboards and footboards for both the upper and lower bunks.
4. Attach the side rails to the assembled headboards and footboards.
5. Install the metal slats into the designated slots. Ensure mute buckles firmly secure slats for stability.
6. Assemble the ladder securely to the bunk bed frame.
7. Attach the anti-tipping device to the bed frame and secure it to a wall stud.
8. Double-check all connections and tighten all bolts.

## Enhanced Stability

With extra metal slats, the bed frame stays twist-free and keeps its shape - for safer, more stable sleep night after night.



Image: A visual representation of the bed's metal slat system and the "Easy Assembly" feature, highlighting how slats click into place effortlessly.

## 5. OPERATING INSTRUCTIONS

---

The nesture. Bunk Bed is designed for sleeping and resting.

- Ensure mattresses are properly sized for the twin bunks.
- The full-length guardrails are designed to prevent mattresses from sliding and provide safety.
- Use the integrated ladder for safe access to the upper bunk.
- The bed offers over 12 inches of under-bed clearance for storage.



Image: A close-up view illustrating the 12-inch storage space available beneath the lower bunk, ideal for boxes or bins.

## 6. MAINTENANCE

Regular maintenance will prolong the life of your bunk bed.

- **Cleaning:** Wipe down the metal frame with a soft, damp cloth. Avoid harsh chemicals.
- **Tightening:** Periodically check and re-tighten all bolts and screws to ensure structural integrity. This should be done every 3-6 months.
- **Inspection:** Inspect the bed frame for any signs of wear, damage, or loose parts. Address any issues promptly.

## 7. TROUBLESHOOTING

Common issues and their solutions.

Problem	Possible Cause	Solution
Bed feels wobbly or unstable.	Loose bolts or improper assembly.	Check and tighten all bolts. Ensure the anti-tipping device is securely installed.
Squeaking noises.	Loose connections or friction between metal parts.	Re-tighten all bolts. Apply a small amount of lubricant (e.g., silicone spray) to connection points if necessary.
Missing parts during unboxing.	Packaging error.	Contact nesture. customer support immediately with your purchase details.

## 8. SPECIFICATIONS

Feature	Detail
---------	--------

Feature	Detail
Size	Twin
Color	Black
Material	Metal & MDF Board
Assembled Dimensions (L x W x H)	77.5" x 41" x 63"
Box Spring Required	No
Weight Capacity	400 lbs (per bunk)
Under-bed Clearance	12 inches
Included Components	Bunk Bed Frame, Guardrails, 22 Robust Slats, Installation Manual, Assembly Tools



Image: A summary table detailing the key specifications of the nesture. bunk bed.

## 9. WARRANTY AND SUPPORT

---

For warranty information or technical support, please contact nesture. customer service.

- **Customer Service:** Refer to your purchase documentation or the manufacturer's website for contact details.
- **Online Resources:** Visit the official nesture. website for FAQs and additional support.