**WINGBO SYCF4805**

# WINGBO 48-Inch Flush Mount Ceiling Fan User Manual

Model: SYCF4805 | Brand: WINGBO

## Important Safety Instructions

Please read and understand all instructions before proceeding with installation or operation. Failure to follow these instructions may result in electric shock, fire, or personal injury.

- **Power Disconnection:** Always ensure the power supply is turned OFF at the circuit breaker before beginning installation, cleaning, or maintenance.
- **Qualified Installation:** Installation must be performed by a qualified electrician in accordance with all local and national electrical codes.
- **Secure Mounting:** The fan must be mounted to a ceiling joist or support structure capable of reliably supporting the fan's weight (approximately 11.18 lbs).
- **Clearance:** Maintain adequate clearance between the fan blades and any obstructions.
- **Blade Integrity:** Do not operate the fan if any blades are damaged or bent.
- **Indoor/Outdoor Use:** This fan is rated for both indoor and outdoor use. Ensure all electrical connections are properly sealed for outdoor installations.

## Package Contents

Carefully unpack all components and verify that you have received all items listed below. If any parts are missing or damaged, contact WINGBO customer support before proceeding.

- Ceiling Fan Motor Assembly
- Fan Blades (4)
- Remote Control (requires 2 AAA batteries, not included)
- Mounting Bracket
- Hardware Pack (includes screws, wire nuts, washers)
- Instruction Manual

## Product Overview

The WINGBO SYCF4805 is a 48-inch flush mount ceiling fan designed to provide efficient and quiet air circulation without a light fixture. It features a reversible DC motor and four solid wood blades, making it suitable for various room types and seasons.




Image: Overview of the WINGBO 48-inch flush mount ceiling fan, highlighting its key features: 6-speed adjustment, noiseless operation, 1/2/4/8 hour timer, remote control, reversible DC motor, and wood blades.

## Key Features:

- **Size:** 48-inch diameter, ideal for spaces such as bedrooms, living rooms, kitchens, and home offices. Recommended ceiling height: 7–10 ft.
- **Motor:** Equipped with a high-efficiency DC motor, ensuring quiet operation (under 30 dB) and energy savings of up to 80% compared to traditional AC motors.
- **Blades:** Features 4 premium solid wood blades, precisely cut to ensure balanced airflow and minimize wobble. The natural wood finish complements various decor styles.
- **Speed Settings:** Offers 6 adjustable speeds for customized airflow to suit your comfort needs.
- **Control:** Includes a remote control for comprehensive fan operation (ON/OFF, speed, direction, timer, natural wind

mode). The fan is also compatible with a standard wall switch for basic power ON/OFF (wall switch accessory not included).

- **Reversible Function:** A reversible motor allows for downward airflow in summer for cooling and upward airflow in winter to improve air circulation and reduce heat loss.
- **Design:** Modern aesthetic with a matte black finish and walnut wood blades.

## Setup and Installation

This section provides general guidance for installing your WINGBO ceiling fan. For detailed visual instructions, please refer to the official installation video provided below.

### Pre-Installation Steps:

1. **Turn off power:** Before starting any work, locate the main circuit breaker and turn off the power to the electrical box where the fan will be installed.
2. **Prepare mounting location:** Ensure the ceiling outlet box is securely fastened to the building structure and is rated for fan support.
3. **Unpack components:** Carefully remove all parts from the packaging. Keep small parts organized to prevent loss.

### Wiring Connection:

Connect the fan's electrical wires to the household wiring according to the provided wiring diagram and local electrical codes. Typically, this involves connecting the ground, neutral (white), and live (black) wires using wire nuts.

Your browser does not support the video tag.

Video: Official Wingbo installation guide for 48-inch and 54-inch ceiling fans. This video demonstrates the wiring and mounting process, providing visual steps for a successful installation.

### Mounting the Fan:

1. Attach the mounting bracket securely to the ceiling outlet box using the provided screws.
2. Carefully lift and attach the fan motor assembly to the mounting bracket.
3. Securely attach the four fan blades to the motor hub using the designated screws.
4. Ensure all connections are tight and secure before restoring power.





Image: Diagram illustrating the precise dimensions of the 48-inch WINGBO ceiling fan and its flush mount installation type. It also provides guidance on recommended room sizes for optimal performance.

## Operating Instructions

Your WINGBO ceiling fan is primarily controlled via the included remote control. Ensure 2 AAA batteries are correctly installed in the remote before use.

### Remote Control Functions:

- **ON/OFF Button:** Powers the fan on or off.
- **Speed Control (1-6):** Adjusts the fan speed from the lowest setting (1) to the highest setting (6).
- **Reverse Function:** Changes the direction of blade rotation. Use for summer (downward airflow) or winter (upward airflow) modes.

- **Timer Settings (1/2/4/8H):** Sets the fan to operate for a specified duration (1, 2, 4, or 8 hours) before automatically turning off.
- **Natural Wind Mode:** Activates a mode that simulates a natural breeze by varying fan speeds intermittently.





Image: Illustration detailing the two control methods: the included remote control with dedicated buttons for ON/OFF, speed, timer, and natural wind, and the optional wall switch for basic power control.

### Seasonal Operation (Reversible Function):

- **Summer Mode:** Blades rotate counter-clockwise, pushing air downwards to create a direct cooling breeze.
- **Winter Mode:** Blades rotate clockwise, drawing air upwards to circulate warm air trapped near the ceiling, helping to reduce heat loss.

## Maintenance

Regular and proper maintenance will ensure the optimal performance, safety, and longevity of your WINGBO ceiling fan.

- **Cleaning:** Periodically dust the fan blades and motor housing with a soft, lint-free cloth. For stubborn dirt, use a slightly damp cloth. Avoid using abrasive cleaners, solvents, or harsh chemicals, as these can damage the finish.
- **Blade Inspection:** Regularly inspect the fan blades for any signs of cracks, warping, or damage. Damaged blades should be replaced immediately to prevent imbalance and potential hazards.
- **Tightness Check:** Over time, vibrations can loosen screws. Periodically check all screws on the blade attachments, mounting bracket, and housing to ensure they are securely tightened.
- **Lubrication:** The DC motor in your WINGBO ceiling fan is permanently lubricated and does not require additional oiling or maintenance.

## Troubleshooting

If you encounter any issues with your WINGBO ceiling fan, refer to the table below for common problems and their solutions. If the problem persists, contact WINGBO customer support.

| Problem | Possible Cause | Solution |
| --- | --- | --- |

| Problem | Possible Cause | Solution |
|---|---|---|
| Fan does not start | No power to the fan; Loose electrical wiring; Remote control batteries are dead or incorrectly installed. | Check the circuit breaker and wall switch; Verify all wiring connections are secure; Replace remote control batteries (2 AAA). |
| Fan wobbles excessively | Loose fan blades or blade holders; Unbalanced blades; Loose mounting hardware. | Ensure all blade screws are tight; Check that the mounting bracket is securely fastened to the ceiling; Consider using a blade balancing kit (not included) if necessary. |
| Remote control not responding | Dead or weak batteries; Remote not paired with the fan; Obstruction between remote and receiver. | Replace AAA batteries; Refer to the remote control's specific pairing instructions (if applicable); Ensure a clear line of sight to the fan's receiver. |
| Noisy operation (humming, clicking) | Loose screws or components; Blades hitting an obstruction; Internal motor issue. | Check and tighten all visible screws; Ensure no wires or objects are touching the blades or motor housing; If motor noise persists, contact customer support. |

## Specifications

Detailed technical specifications for the WINGBO 48-inch Flush Mount Ceiling Fan (Model SYCF4805).

| Feature | Detail |
|---|---|
| Brand | WINGBO |
| Model Number | SYCF4805 |
| Size | 48 inches |
| Color | Matte Black + Walnut |
| Motor Type | DC Motor |
| Number of Blades | 4 |
| Blade Material | Solid Wood |
| Number of Speeds | 6 |
| Noise Level | 25 Decibels |
| Wattage | 30 watts |
| Voltage | 120 Volts |
| Mounting Type | Flush Mount |
| Control Method | Remote Control |
| Special Features | No Light, Remote Controlled, Timer, Wood Blades, Reversible Motor |

| Feature | Detail |
|---|---|
| Product Dimensions | 48"D x 48"W x 8.66"H |
| Item Weight | 11.18 lbs |
| Indoor/Outdoor Usage | Indoor, Outdoor |
| Certification | ETL |

## Warranty and Support

WINGBO is committed to providing high-quality products and excellent customer service. Your ceiling fan is covered by the following warranty:

- **Motor Warranty:** A 10-year free replacement warranty for the powerful DC motor, ensuring long-term reliability.
- **Whole Fan Warranty:** A 3-year warranty covers all other parts of the fan assembly.
- **Customer Service:** WINGBO offers 24-hour online support to provide prompt assistance and resolve any issues you may encounter.




Image: Graphic detailing WINGBO's service commitment, including 24-hour online reply, a 10-year motor warranty, and a 3-year whole fan warranty for other components.

For further assistance, please visit the WINGBO Store on Amazon or contact our customer support team directly.


## Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

**Submit question**