

Spolehli Basketball Scoreboard

Spolehli Ultra-Bright Cordless Basketball Scoreboard Instruction Manual

1. INTRODUCTION

Thank you for choosing the Spolehli Ultra-Bright Cordless Basketball Scoreboard. This manual provides essential information for the safe and efficient operation of your new scoreboard. Please read it thoroughly before use and retain it for future reference.

This scoreboard is designed for various sports and family games, offering a clear and dynamic display of scores, time, and game indicators. Its robust aluminum frame, long-lasting rechargeable battery, and versatile mounting options make it suitable for both indoor and outdoor environments.

2. PACKAGE CONTENTS

Upon opening your package, please ensure all items listed below are present and in good condition:

- 1x Spolehli Ultra-Bright Cordless Basketball Scoreboard
- 1x Remote Control
- 1x USB-C Charging Cable
- 1x Power Adapter
- 2x L-shaped Hooks (for wall/net mounting)
- Expansion Nuts and Screws (for mounting)
- User Manual



Figure 2.1: Included Components

3. SETUP

3.1 Charging the Scoreboard

Before initial use, fully charge the scoreboard using the provided USB-C charging cable and power adapter. The scoreboard features a built-in lithium battery that provides up to 10 hours of cordless operation. A low-battery alert will indicate when recharging is needed.



Figure 3.1: USB-C Charging Port and Low-Power Alert

3.2 Mounting Options

The scoreboard offers versatile mounting solutions:

- **Tabletop Placement:** Use the integrated stands for stable placement on any flat surface.
- **Wall Mounting:** Utilize the included L-shaped hooks, expansion nuts, and screws to securely mount the scoreboard to a wall.
- **Net Hanging:** The L-shaped hooks can also be used to hang the scoreboard on a net or fence.
- **Tripod Mounting:** For elevated and portable use, the scoreboard can be attached to a standard tripod (sold separately).

Mount Anywhere, Set Up in Seconds!

– Maximize flexibility with dual sliding top grooves and included L-shaped hooks



Figure 3.2: Versatile Mounting Options

4. OPERATING INSTRUCTIONS

The scoreboard is controlled via the included remote control. Familiarize yourself with the remote's layout for seamless game management.

Your browser does not support the video tag. This video demonstrates the remote control functions of the Spolehli Basketball Scoreboard.

Video 4.1: Spolehli Basketball Scoreboard Remote Control Function

4.1 Remote Control Functions

The remote control allows for comprehensive management of game parameters:

- **Power On/Off:** Use the red button to turn the scoreboard on or off.
- **Score Adjustment:** Use the '+1', '+2', '+3', and '-1' buttons for Home (H) and Guest (G) teams to adjust scores.
- **Game Timer:** Set the main game timer (e.g., 12 minutes) and use 'Start/Stop' to control it.
- **Shot Clock:** Customize the attack clock between 14s or 24s modes.
- **Period Indicator:** Adjust the current game period using the 'Period +/-' buttons.
- **Possession Arrow:** Change ball possession using the dedicated button.
- **Brightness Adjustment:** Adjust the display brightness across 6 levels using the brightness buttons.
- **Buzzer Control:** Turn the >85dB buzzer on or off for time-up alerts.
- **Score Reset:** Reset scores for Home or Guest teams individually, or reset the entire match.




Figure 4.1: Scoreboard Display and Remote Control

4.2 Display Features

The scoreboard features ultra-bright red and green LEDs for clear visibility up to 98.5 feet (30m). The 6-level adjustable brightness ensures optimal viewing in various lighting conditions, from bright daylight to indoor settings.

100Ft-Visibility Crystal-Clear Display

No dull yellow here! Vivid super bright red and green LEDs cut through glare and daylight



Figure 4.2: Vivid Display and Brightness Adjustment

5. MAINTENANCE

- **Cleaning:** Wipe the scoreboard surface with a soft, dry cloth. Avoid abrasive cleaners or solvents.
- **Storage:** Store the scoreboard in a cool, dry place when not in use.
- **Battery Care:** Recharge the built-in lithium battery regularly, even during periods of non-use, to maintain its lifespan. Avoid fully depleting the battery for extended periods.

6. TROUBLESHOOTING

- **Scoreboard not turning on:** Ensure the battery is charged. Connect the USB-C charger and try again.
- **Remote control not responding:** Check if the remote's batteries are correctly inserted and have sufficient power. Ensure there are no obstructions between the remote and the scoreboard.
- **Display too dim/bright:** Use the brightness adjustment buttons on the remote control to set the desired level.
- **Buzzer not sounding:** Check if the buzzer is enabled via the remote control.

7. SPECIFICATIONS

Feature	Detail
Brand Name	Spolehli
Model Name	Basketball Scoreboard
Material	Aluminum
Color	Black
Item Package Dimensions L x W x H	27.42 x 12.06 x 5.55 inches
Package Weight	3.41 Kilograms
Included Components	Remote, Scoreboard

8. WARRANTY AND SUPPORT

This Spolehli Ultra-Bright Cordless Basketball Scoreboard comes with a **2-Year Warranty**. For warranty claims, technical support, or any inquiries, please contact Spolehli customer service through the retailer where the product was purchased or visit the official Spolehli store online.

For more information and product updates, please visit the [Spolehli Store](#).