

## VEVOR 1120

# VEVOR Computerized Sewing Machine Model 1120 User Manual

Brand: VEVOR | Model: 1120

## 1. INTRODUCTION

This manual provides essential information for the safe and efficient operation of your VEVOR Computerized Sewing Machine Model 1120. Please read all instructions carefully before using the machine.



Image: VEVOR Computerized Sewing Machine Model 1120, highlighting ease of use.

The VEVOR Computerized Sewing Machine Model 1120 is designed for a wide range of sewing projects, from basic mending to intricate crafts. It features 200 unique built-in stitches, an LCD screen for easy selection, a foot pedal, and an LED light for enhanced visibility. Its heavy-duty metal frame and powerful motor allow it to handle various fabric thicknesses, including up to 6 layers of denim.

## 2. IMPORTANT SAFETY INSTRUCTIONS

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, or injury to persons.

- Read all instructions before using the sewing machine.
- Keep the machine away from water or wet surfaces.
- Unplug from the outlet when not in use, before cleaning, or when changing needles.
- Do not allow to be used as a toy. Close attention is necessary when the sewing machine is used by or near children.
- Use this appliance only for its intended use as described in this manual.
- Never operate this sewing machine if it has a damaged cord or plug, if it is not working properly, or if it has been dropped or damaged.
- Keep fingers away from all moving parts. Special care is required around the sewing machine needle.

### 3. PACKAGE CONTENTS

Your VEVOR Computerized Sewing Machine Model 1120 comes fully equipped with the following tools and accessories:



Image: VEVOR Computerized Sewing Machine with all included tools and accessories.

- Foot Pedal + Power Cord x 1
- Power Cord x 1
- User Manual x 1
- Test Fabric x 1
- Dust Cover x 1
- Buttonhole Foot x 1
- Needles (Size 14#, 1 Installed) x 4
- Twin Needle x 1
- Ripper / Brush x 1
- Bobbins (4 total-1 in machine) x 10
- Blind Hem Foot x 1
- Zipper Foot x 1
- Felt Pads x 2
- Auxiliary spool pin x 1
- Button Sewing Foot x 1

- Screwdriver for needle plate x 1
- Universal Presser Foot (Pre-Installed) x 1

## 4. PRODUCT OVERVIEW

Familiarize yourself with the various parts of your sewing machine for optimal use.



Image: Front view of the VEVOR Computerized Sewing Machine Model 1120, showing the needle, presser foot, and control panel.

The machine features a clear LCD display, intuitive control buttons, and clearly marked threading paths. The removable accessory box provides storage and converts the machine to free-arm mode.

## 5. SETUP

### 5.1. Power Connection

Connect the foot pedal and power cord to the designated ports on the right side of the machine. Plug the power cord into a suitable electrical outlet. Turn on the power switch located on the right side of the machine.

### 5.2. Threading the Machine

Follow the numbered guides on the machine for proper upper thread tension and path. The built-in automatic needle threader simplifies the final step of threading the needle.

### 5.3. Winding the Bobbin

Place a bobbin onto the bobbin winder spindle. Follow the threading path for bobbin winding. The clear horizontal bobbin system allows for easy monitoring and replacement of the lower thread.




Image: Close-up of the clear horizontal bobbin, illustrating its quick replacement feature.

## 6. OPERATING THE MACHINE

### 6.1. Stitch Selection

The LCD display allows you to easily select from 200 unique built-in stitches, including utility, decorative, letters, numbers, symbols, and 8 one-step buttonholes. Use the up/down arrow buttons to navigate and select

your desired stitch pattern.

# VEVOR Sewing Machine

200 Built-In Stitches to Choose Freely



Beginner-Friendly

- ✔ Max Stitch Width: 0.28 inch / 7 mm
- ✔ Max Stitch Length: 0.18 inch / 4.5 mm
- ✔ Adjustable Thread Tension
- ✔ Adjustable Stitch Width and Length

Image: VEVOR sewing machine in operation, showcasing the variety of 200 built-in stitches and user-friendly features.

# Easy to Use

## Preset Stitch Length and Width




Image: A visual guide to the 200 stitch applications, including utility, decorative, letters, numbers, and symbols.

### 6.2. Speed Control

Adjust the sewing speed using the slider control on the machine. You can choose between a high speed of 700 stitches/min or a low speed of 150 stitches/min, allowing for precise control for different tasks.

### 6.3. Stitch Length and Width

Preset needle position, stitch length, and width options are available to save setup time. Adjustable thread tension further simplifies operation for various fabric types.

### 6.4. Flexible Sewing

Switch to free arm mode by removing the accessory box. This mode is ideal for sewing cuffs, sleeves, pant hems, collars, and cylindrical items. The machine also supports twin-needle sewing for stronger seams.

## 360° Seam Around with Ease

Switch to Free-Arm Mode Anytime



Pants Hems



Cuffs



Collars



Round Cushions



Image: The VEVOR sewing machine configured in free-arm mode, perfect for sewing circular items like cuffs and pant hems.

## 7. KEY FEATURES

- **Multiple Stitches:** 200 unique built-in stitches, including utility, decorative, letters, numbers, symbols, and 8 one-step buttonholes.
- **Simple Operation:** Preset needle position, stitch length, and width. Adjustable thread tension and built-in automatic needle threader.

- **Handles Thick Fabrics:** Heavy-duty metal frame, stainless steel bed, and powerful motor. Sews through up to 0.16 inches (4 mm) thick fabrics, such as 6 layers of denim.
- **Flexible Sewing:** Converts to free arm mode for cuffs, sleeves, and other cylindrical items.
- **Practical Design:** Clear horizontal bobbin for easy thread monitoring. Supports twin-needle sewing. Built-in LED light brightens the workspace and reduces eye strain.

## Practical Features Make Sewing a Breeze



**Clear Horizontal Bobbin**  
Easy Thread View



**LED Light**  
Bright Workspace



**Auto Needle Threader**  
Save Time & Effort



**Model:1120**  
**Two Speed Control Options**  
Pedal & Button Control



**Twin Needle Support**  
More Secure Stitching



**Up Needle Stop Position**  
Easier Fabric Adjustment

Image: Infographic detailing practical features like clear horizontal bobbin, LED light, auto needle threader, two speed control options, twin needle support, and up needle stop position.

# Effortlessly Sews Through 6 Layers of Denim

Handles Thickness up to 0.16 inch / 4 mm



Both Thick and Thin Fabrics are Available



Chiffon



Cotton



Linen



Denim

Image: The VEVOR sewing machine demonstrating its ability to sew through thick fabrics like 6 layers of denim, as well as chiffon, cotton, and linen.

## 8. MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your sewing machine.

- **Cleaning:** Use the provided brush to regularly clean lint and dust from the bobbin area and feed dogs.
- **Lubrication:** Refer to the detailed instructions in the user manual for proper lubrication points and frequency.
- **Needle Replacement:** Replace needles regularly, especially if they are bent or dull, to prevent fabric damage and skipped stitches.

- **Storage:** When not in use, cover the machine with the provided dust cover to protect it from dust and debris.

## 9. TROUBLESHOOTING


If you encounter any issues with your sewing machine, refer to the following common problems and solutions:

- **Skipped Stitches:** Ensure the needle is inserted correctly and is not bent or dull. Check that the machine is properly threaded.
- **Thread Breakage:** Verify that the upper thread and bobbin thread are correctly tensioned. Use appropriate thread and needle size for your fabric.
- **Machine Jamming:** Check for tangled threads in the bobbin case or around the needle. Ensure the presser foot is lowered before sewing.
- **Uneven Stitches:** Adjust the thread tension and ensure the fabric is fed evenly.

For more detailed troubleshooting, consult the comprehensive user manual.

## 10. SPECIFICATIONS

Below are the technical specifications for the VEVOR Computerized Sewing Machine Model 1120:



Item Model Number: <b>1120</b>	Display: <b>LCD Screen</b>
Power: <b>36W(US)/36W(EU,AU)</b>	Max Stitch Width: <b>0.28 in / 7 mm</b>
Color: <b>White</b>	Max Stitch Length: <b>0.18 in / 4.5 mm</b>
Type: <b>Electric Home Sewing Machine</b>	Presser Foot Lift Height: <b>0.22 in / 5.5 mm</b>
Built-In Stitches: <b>200 Patterns</b>	Net Weight: <b>2.27 lbs / 5 kg</b>
Adjustable Speed: <b>700 rpm High, 150 rpm Low</b>	
Bobbin Style: <b>Horizontal Bobbin</b>	
Stitch Rate: <b>700 stitches/min</b>	
Max Fabric Thickness: <b>≤0.16 in / 4 mm (up to 6 layers of denim)</b>	
Product Dimensions: <b>16.14 x 6.5 x 12 in / 410 x 165 x 305 mm</b>	

Image: Detailed specifications and dimensions of the VEVOR Computerized Sewing Machine Model 1120.

- **Item Model Number:** 1120
- **Power:** 36W (US)/36W (EU, AU)
- **Color:** White
- **Type:** Electric Home Sewing Machine
- **Built-In Stitches:** 200 Patterns
- **Adjustable Speed:** 700 rpm High, 150 rpm Low
- **Bobbin Style:** Horizontal Bobbin
- **Max Fabric Thickness:** ≤ 0.16 in / 4 mm (up to 6 layers of denim)
- **Product Dimensions:** 16.14 x 6.5 x 12.01 inches (410 x 165 x 305 mm)
- **Stitch Rate:** 700 stitches/min
- **Display:** LCD Screen
- **Max Stitch Width:** 0.28 in / 7 mm

- **Max Stitch Length:** 0.18 in / 4.5 mm
- **Presser Foot Lift Height:** 0.22 in / 5.5 mm
- **Net Weight:** 11.02 pounds (5 kg)
- **Manufacturer:** VEVOR
- **ASIN:** B0FJ6ZB9HR
- **UPC:** 197988693086

## 11. WARRANTY AND SUPPORT

---

For warranty information or technical support, please refer to the contact details provided in your product packaging or visit the official VEVOR website. Keep your purchase receipt for any warranty claims. Protection plans may be available for extended coverage. Please check with your retailer for details.