



[Manuals.plus](#) /

> [Aobante](#) /

> Aobante 10-inch Android 15 Tablet User Manual

## Aobante 10.1

# Aobante 10-inch Android 15 Tablet User Manual

Model: 10.1

## INTRODUCTION

---

Welcome to the user manual for your new Aobante 10-inch Android 15 Tablet. This guide provides essential information on setting up, operating, and maintaining your device. Please read this manual thoroughly to ensure optimal performance and longevity of your tablet.

## SAFETY INFORMATION

---

- Do not expose the tablet to extreme temperatures, direct sunlight, or high humidity.
- Avoid dropping or subjecting the tablet to strong impacts.
- Use only the provided charger and accessories to prevent damage and ensure safety.
- Keep the tablet away from water and other liquids.
- Do not attempt to disassemble or repair the tablet yourself. Contact customer support for assistance.

## PACKAGE CONTENTS


---

Verify that all items are present in your package:

- Aobante 10-inch Android 15 Tablet
- Bluetooth Keyboard
- Mouse
- Stylus Pen
- Protective Case
- USB-C Charging Cable
- Power Adapter

# Extreme Performance-From the Inside Out

T615 octa-core processor, excellent performance, rapid response, bringing you a smooth operating experience.



**T615 Octa-core**  
**Mali -G57**



**Cortex-A55 x 6**  
**Cortex-A75 x2**



**12nm Process**  
**DynamIQ Architecture**

Image: The Aobante 10-inch tablet displayed with its full set of accessories, including the detachable keyboard, wireless mouse, stylus, and protective case.

## PRODUCT OVERVIEW

---

Familiarize yourself with the physical features of your Aobante tablet.



## All-round Navigation Service



## Face Security Unlocking- No Need to Wait

Image: A detailed view of the tablet's side, highlighting the Type-C charge port, indicating 5V/2A charging compatibility, and the 3.5mm headphone jack for audio connectivity.

### Key Components:

- **Power Button:** Located on the side, used to turn the tablet on/off or wake/sleep the screen.
- **Volume Buttons:** Adjust audio levels.
- **USB-C Port:** For charging and data transfer.
- **3.5mm Headphone Jack:** For connecting wired headphones.
- **Micro SD Card Slot:** For expandable storage up to 1TB.
- **Front Camera:** 5MP camera for video calls and selfies.
- **Rear Camera:** 8MP camera for photos and videos.
- **Speakers:** Integrated stereo speakers for audio output.

### SETUP

---

## 1. Charging the Tablet

Before first use, fully charge your tablet. Connect the USB-C cable to the tablet's USB-C port and the power adapter, then plug the adapter into a wall outlet. The battery indicator on the screen will show charging status.



Image: The tablet screen displaying a charging animation with a large '6000mAh' text, indicating its battery capacity and current charging status.

## 2. Powering On/Off

- **To Power On:** Press and hold the Power button until the Aobante logo appears.
- **To Power Off:** Press and hold the Power button until the power options appear on the screen, then select "Power off".
- **To Restart:** Press and hold the Power button, then select "Restart".

## 3. Initial Android Setup

Upon first power-on, follow the on-screen prompts to set up your Android 15 operating system. This includes selecting your language, connecting to Wi-Fi, and signing in with your Google account.

### Basic Navigation

The Aobante tablet features a responsive 10.1-inch IPS HD touchscreen (1280x800 resolution) for intuitive interaction.

- **Tap:** Select items or open applications.
- **Swipe:** Navigate through screens or scroll content.
- **Pinch-to-Zoom:** Enlarge or reduce images and web pages.

## Enjoy Higher Definition Viewing with a Larger Vivid Touch Screen

			
<b>10.1 Inch</b> Large Screen	<b>1280*800</b> Resolution	<b>16:10</b> Aspect Ration	<b>Eye-care</b> CareMode



Image: The tablet screen showcasing a colorful, high-definition image, emphasizing its 10.1-inch IPS display with 1280x800 resolution and 16:10 aspect ratio for optimal viewing.

### Connecting Peripherals

Your tablet supports Bluetooth 5.0 for connecting accessories like the included keyboard and mouse.

1. Go to **Settings > Connected devices > Bluetooth**.
2. Turn on Bluetooth.

3. Put your keyboard or mouse into pairing mode (refer to their respective manuals).
4. Select the device from the list of available devices on your tablet to pair.

## Extreme Performance-From the Inside Oout



24(8+16)GB



128 GB



TF Card Expanded 1TB  
(not included)

Image: The Aobante tablet positioned with its Bluetooth keyboard, demonstrating its capability for enhanced productivity and typing.

### Wi-Fi Connectivity

Connect to the internet via Wi-Fi (2.4G+5G) for browsing, streaming, and app downloads.

1. Go to **Settings > Network & internet > Wi-Fi**.
2. Turn on Wi-Fi.
3. Select your desired network from the list and enter the password if required.

### Storage Management

Your tablet comes with 128GB of internal storage and supports expansion up to 1TB via a Micro SD card (not included).

- **To insert a Micro SD card:** Locate the card slot on the side of the tablet and gently insert the card until it clicks into place.

- **To manage storage:** Go to **Settings > Storage** to view usage and manage files.

**Unisoc T615**

## Big Core Powerful Performance

ARM Cortex-A75 and Cortex-A55 dual-cluster architecture, combining performance with energy efficiency. With LPDDR4X, it enables smooth multitasking and fast read/write speeds.

<b>A75+A55</b> CPU Architecture	Cortex-A75 *2 <b>@2.0 GHZ</b>	Cortex-A55*6 <b>@1.8 GHZ</b>	GPU <b>Mali-G57</b>
------------------------------------	----------------------------------	---------------------------------	------------------------

Image: The tablet set up with its keyboard and mouse, visually emphasizing its large storage capabilities: 24GB RAM (8+16GB), 128GB ROM, and support for 1TB TF card expansion.

## Camera Functions

Capture moments with the 5MP front camera and 8MP rear camera.

1. Open the **Camera** application.
2. Tap the shutter button to take a photo.
3. Switch between front and rear cameras using the camera icon.

## Dual camera, record the beauty



5MP front + 8MP rear, take clear photos, smooth video calls, capture every wonderful moment in life.

Image: A collage showing people enjoying the tablet's camera features, with a close-up of the tablet's dual cameras (5MP front + 8MP rear) and examples of clear photos and video calls.

### Face Recognition

Unlock your tablet quickly and securely using face recognition technology.

1. Go to **Settings** > **Security & privacy** > **Face unlock**.
2. Follow the on-screen instructions to register your face.

### GPS Navigation

Utilize the built-in GPS for accurate location services and navigation.

- Ensure Location Services are enabled in **Settings** > **Location**.
- Use pre-installed or downloaded navigation apps for directions.

### Split Screen Functionality

Multitask efficiently by running two applications side-by-side using the split-screen feature of Android 15.

1. Open an app, then swipe up from the bottom of the screen and hold to access recent apps.
2. Tap the app icon at the top of the app's card and select **Split top**.
3. Choose a second app from your recent apps or app drawer to fill the other half of the screen.



Image: The tablet showcasing its Smart Split Screen feature, allowing two applications to run simultaneously, and illustrating Wireless Screen Cast functionality to an external display.

## MAINTENANCE

---

### Cleaning the Tablet

Use a soft, lint-free cloth to clean the screen and body of the tablet. Avoid using harsh chemicals or abrasive materials.

### Battery Care

- Avoid fully discharging the battery frequently.
- Do not leave the tablet charging for extended periods after it's fully charged.
- Store the tablet in a cool, dry place when not in use for long periods.

## TROUBLESHOOTING

---

### Tablet Not Turning On

- Ensure the tablet is sufficiently charged. Connect it to the charger for at least 30 minutes.
- Press and hold the Power button for 10-15 seconds to perform a forced restart.

### Poor Wi-Fi Connection

- Move closer to the Wi-Fi router.
- Restart your Wi-Fi router and the tablet.
- Check if other devices are experiencing similar issues.

### Applications Crashing or Freezing

- Close background applications.
- Clear the cache of the problematic app (**Settings > Apps > [App Name] > Storage & cache > Clear cache**).

- Update the app to its latest version.

## Battery Drains Quickly

- Reduce screen brightness.
- Close unused applications running in the background.
- Disable Wi-Fi, Bluetooth, and GPS when not in use.
- Check battery usage in **Settings > Battery** to identify power-hungry apps.

## SPECIFICATIONS

Detailed technical specifications for the Aobante 10-inch Android 15 Tablet.

### Latest operating **Android 15** System



**Android 15**



**10.1 inch**  
Touch Screen



**5G+2.4G**  
WiFi



**5MP+8MP**  
Camera



**6000mAh**  
Type-C



**24(8+16)GB RAM**  
128GB ROM



Image: An overview of the Aobante 10-inch Android tablet, highlighting its core specifications including Android 15, 10.1-inch HD display, T615 Octa-Core processor, 6000mAh battery, 24(8+16)GB RAM, 128GB ROM, 5MP+8MP cameras, and Type-C charging.

Feature	Specification
Model Number	10.1
Operating System	Android 15
Screen Size	10.1 Inches
Screen Resolution	1280 x 800 pixels (IPS HD)
Processor	2.0 GHz Octa-Core (SPRD T615)
RAM	24GB (8GB physical + 16GB virtual)
Internal Storage	128GB ROM
Expandable Storage	Up to 1TB via Micro SD card
Rear Camera	8MP
Front Camera	5MP

Feature	Specification
Battery Capacity	6000mAh
Connectivity	Wi-Fi 2.4G+5G, Bluetooth 5.0
Ports	USB-C, 3.5mm Headphone Jack
Special Features	GPS, Face Recognition, Widevine L1
Dimensions (LxWxH)	9.55 x 6.35 x 0.31 inches
Item Weight	3.1 pounds

## WARRANTY AND SUPPORT

---

For warranty information or technical support, please refer to the warranty card included in your package or contact Aobante customer service. Most questions are answered within 24 hours to ensure a positive experience with our products.