



[Manuals.plus](#) /

> [KYBOLT](#) /

> KYBOLT 10x13 Ft Outdoor Pergola with Retractable Canopy & Side Mesh Screen Instruction Manual

KYBOLT Regular 10x13 Ft

KYBOLT 10x13 Ft Outdoor Pergola Instruction Manual

Model: Regular 10x13 Ft

1. INTRODUCTION

This manual provides detailed instructions for the assembly, operation, and maintenance of your KYBOLT 10x13 Ft Outdoor Pergola. Please read all instructions carefully before beginning assembly and retain this manual for future reference.

2. SAFETY INFORMATION

- **Assembly:** Always assemble with multiple people on flat ground according to the installation manual.
- **Anchoring:** Ensure the gazebo is securely anchored to the ground to prevent it from tipping over in windy conditions or during heavy rain.
- **Inspection:** Regularly inspect the frame and canopy for any signs of wear or damage, and perform necessary maintenance to ensure the product's safety and longevity.
- **UV Protection:** The retractable polyester canopy offers UPF 50+ sun shade, blocking 99% of harmful UV rays.
- **Water Resistance:** The fine side mesh screens and canopy are designed to keep rainwater out while allowing airflow.

3. PACKAGE CONTENTS

Verify all parts are present before beginning assembly. Refer to the included parts list in your package. All parts are numbered for quick identification.



Image: All components of the pergola, including aluminum frame pieces, hardware, and the canopy fabric, are laid out on a black tarp, ready for assembly. Instructions and small bags of screws are visible.

4. SETUP AND ASSEMBLY

Assembly is recommended with multiple people on flat ground. The process may take 1.5-2 hours to complete.

4.1 Frame Assembly

Begin by assembling the main aluminum alloy frame. The frame features a powder coating for rust and corrosion resistance.



UPGRADED BASE COLUMN DESIGN

Reinforced on all four sides for comprehensive stability
increasing stability by 50%

Image: A close-up view of the upgraded base column design, showing the reinforced base with bolts for enhanced stability. The column is dark gray, and the base is secured to the ground.

WOOD GRAIN FRAME



**Wood
Appearance**



**All-aluminum
Material**



**Powder Coating
Reinforcement**




Image: A detailed view of the pergola's frame, labeled "WOOD GRAIN FRAME," indicating its wood appearance, all-aluminum material, and powder coating reinforcement for durability.

4.2 Canopy Installation

Once the frame is erected, install the retractable canopy. The canopy is designed for easy sliding to control the shaded area.

RETRACTABLE CANOPY

Easy to slide and control the shaded area



Image: An illustration showing the retractable canopy mechanism, with arrows indicating its ability to slide open and close along the pergola's top frame.




Image: A diagram illustrating the step to connect the movable canopy to the pulley system and then install the crossbeams that connect the mesh on both sides of the pergola.



Image: A diagram showing the final steps of assembly: securing the Velcro on the mesh to the crossbeam and using ground stakes to anchor the aluminum pergola to the ground.

5. OPERATING INSTRUCTIONS

5.1 Retractable Canopy

The canopy can be easily retracted or extended manually to adjust the amount of shade desired. Use the integrated hook locking design to secure the canopy in place, preventing unwanted movement.




Image: A close-up view of the "HOOK LOCKING DESIGN" feature, which secures the retractable canopy to the top frame, ensuring stability and preventing it from sliding open unintentionally.

5.2 Side Mesh Screens

The fine side mesh screens can be deployed to provide additional rain protection and airflow. They can be tied back when not needed.

6. MAINTENANCE

- **Cleaning:** Clean the aluminum frame with a mild soap and water solution. Rinse thoroughly and dry.
- **Canopy Care:** The Oxford cloth canopy is durable. For cleaning, use a soft brush and mild detergent. Allow to air dry completely before retracting for extended periods.
- **Seasonal Storage:** In areas with harsh winter weather, it is recommended to remove the canopy and store it indoors to prolong its lifespan.
- **Fastener Check:** Periodically check all bolts and fasteners to ensure they are tight and secure.

7. TROUBLESHOOTING

- **Canopy not retracting smoothly:** Check for any obstructions in the tracks or debris on the canopy fabric. Ensure the pulley system is clean and free of entanglement.
- **Pergola instability:** Verify that all frame connections are securely tightened and that the base is properly anchored to the ground. Re-check ground stakes if applicable.
- **Water pooling on canopy:** Ensure the canopy is properly tensioned and angled to allow for water runoff. Adjust as necessary.

8. SPECIFICATIONS

Feature	Detail
Brand	KYBOLT
Model	Regular 10x13 Ft
Material	Aluminum Frame, Oxford Cloth Canopy
Product Dimensions (Packaged)	58.27"L x 17.44"W x 8.46"H
Item Weight	81.8 Pounds
Water Resistance Level	Water Resistant
Ultraviolet Light Protection	Yes (UPF 50+)
Assembly Required	Yes
UPC	199641394828
ASIN	B0FJ889FLY

9. WARRANTY AND SUPPORT

For warranty information or customer support, please refer to the contact details provided with your purchase or visit the official KYBOLT website. Protection plans are available for purchase separately.

10. ADDITIONAL PRODUCT VIEWS

Here are some additional views of the KYBOLT Outdoor Pergola in various settings.



Image: The KYBOLT 10x13 Ft Outdoor Pergola, featuring a retractable blue canopy and white side mesh screens, set up on a wooden deck. Outdoor seating and a golden retriever are visible, showcasing the pergola's use in a backyard setting.

OUTDOOR PERGOLA

10FT x 13FT



Image: A detailed diagram of the KYBOLT Outdoor Pergola, labeled "OUTDOOR PERGOLA 10FT x 13FT," showing its overall dimensions and the measurements of its posts and height.



Image: The KYBOLT Outdoor Pergola with its retractable canopy extended, providing shade over a hot tub in a lush, tropical outdoor environment with palm trees.