

[Manuals.plus](#) /

› [AGLUCKY](#) /

› AGLUCKY Countertop Ice Maker Machine User Manual

AGLUCKY AGLUCKY

AGLUCKY Countertop Ice Maker Machine User Manual

Model: AGLUCKY

Brand: AGLUCKY

INTRODUCTION

Thank you for choosing the AGLUCKY Countertop Ice Maker Machine. This compact and efficient appliance is designed to provide you with fresh bullet ice cubes quickly and conveniently. With its rapid ice-making capability, self-cleaning function, and quiet operation, it is an ideal addition to your home, kitchen, or office. Please read this manual thoroughly before operation to ensure proper use, maintenance, and safety.

IMPORTANT SAFETY INSTRUCTIONS

To reduce the risk of fire, electric shock, or injury when using your ice maker, follow these basic precautions:

- Read all instructions before use.
- Do not touch the evaporator or ice blades when the unit is in operation.
- Do not immerse cord, plug, or any part of the unit in water or other liquids.
- Close supervision is necessary when the appliance is used by or near children.
- Avoid using attachments not recommended by the manufacturer.
- Do not operate the appliance if it has a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- Use only potable water for ice making.
- Do not block any ventilation openings.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Unplug the appliance before cleaning or performing any maintenance.
- Do not use outdoors.

PACKAGE CONTENTS

Upon unpacking, please ensure all items listed below are present and undamaged:

- AGLUCKY Countertop Ice Maker Machine
- Ice Basket
- Ice Scoop
- User Manual



The AGLUCKY ice maker with icons indicating its features: 26lbs/24H ice production, 2L water tank, and 9 pieces of ice in 6-8 minutes. An ice basket and scoop are shown next to the machine.

PRODUCT OVERVIEW

Familiarize yourself with the main components of your ice maker:



AGLUCKY Countertop Ice Maker Machine in green, with a glass of iced drink and an ice scoop filled with bullet ice cubes.

Control Panel Indicators:

- **ADD WATER:** Illuminates when the water reservoir needs refilling.
- **ICE FULL:** Illuminates when the ice basket is full.
- **POWER:** Indicates the unit is powered on.
- **S (Small):** Indicates small size ice cubes are selected.
- **L (Large):** Indicates large size ice cubes are selected.

Buttons:

- **ON/OFF:** Press to turn the unit on or off.
- **SELECT:** Press to choose between small (S) and large (L) ice cube sizes.

SETUP

1. **Unpacking:** Carefully remove all packaging materials and check for any damage. Keep packaging for future storage if needed.
2. **Placement:** Place the ice maker on a flat, stable surface away from direct sunlight and heat sources. Ensure there is at least 4 inches of space around the unit for proper ventilation.



The AGLUCKY ice maker placed on a countertop, showing its compact dimensions of 8.86 inches width, 12.6 inches depth, and 12.6 inches height.

3. **Initial Cleaning:** Before first use, clean the interior of the ice maker.
 - Remove the ice basket.
 - Clean the interior with a soft cloth dampened with warm water and a mild detergent.
 - Rinse thoroughly and wipe dry.
 - Run a self-cleaning cycle (refer to Maintenance section) before making ice for consumption.
4. **Power Connection:** Plug the power cord into a grounded electrical outlet.

OPERATING INSTRUCTIONS

Follow these steps to start making ice:

1. **Add Water:** Open the lid and pour potable water into the water reservoir up to the MAX fill line. Do not overfill.

Easy To Operate

Step 1:

Add Water



Step 2:

Press "ON/OFF"



Step 3:

Enjoy The Ice



Step 1: Add water to the reservoir of the ice maker.

2. **Power On:** Press the **ON/OFF** button to turn on the ice maker. The POWER indicator will illuminate.
3. **Select Ice Size:** Press the **SELECT** button to choose your desired ice cube size:
 - **S (Small):** For smaller, quicker ice cubes.
 - **L (Large):** For larger, longer-lasting ice cubes.

The corresponding indicator (S or L) will light up.

Easy To Operate

Step 1:

Add Water



Step 2:

Press "ON/OFF"



Step 3:

Enjoy The Ice



Step 2: Press the ON/OFF button on the control panel to begin ice production.

4. **Ice Production:** The ice maker will begin its cycle. The first batch of ice cubes will be ready in approximately 6-8 minutes. Subsequent batches may be faster.
5. **Ice Full Indicator:** When the ice basket is full, the **ICE FULL** indicator will illuminate, and the ice making process will pause. Remove ice from the basket to resume operation.
6. **Add Water Indicator:** If the water level in the reservoir is too low, the **ADD WATER** indicator will illuminate, and the unit will stop making ice. Add more water to resume.
7. **Enjoy Your Ice:** Use the provided ice scoop to retrieve ice from the basket.

Easy To Operate

Step 1:

Add Water



Step 2:

Press "ON/OFF"



Step 3:

Enjoy The Ice



Step 3: Enjoy the freshly made ice cubes.

8. **Power Off:** To turn off the ice maker, press the **ON/OFF** button again.

The AGLUCKY ice maker operates with a low noise level, typically around 40dB, ensuring a quiet environment.

Low Noise



The AGLUCKY ice maker on a counter, with a graph illustrating its low noise level (≤ 40 dB) compared to speaking (42dB) and a hair dryer (60dB). A person is sleeping peacefully in the background.

MAINTENANCE

Regular cleaning and maintenance will prolong the life of your ice maker and ensure hygienic ice production.

Self-Cleaning Function:

The ice maker features a convenient self-cleaning function:

1. Ensure the unit is in the shutdown state (powered off).
2. Press and hold the **SELECT** button for approximately 5 seconds.
3. The self-cleaning cycle will begin and last for about 30 minutes.
4. Once the cycle is complete, drain any remaining water from the reservoir.

Self-Cleaning Function

Press and hold "ON/OFF" for about 5 seconds



A transparent view of the AGLUCKY ice maker demonstrating the self-cleaning water circulation, with a glass of water and lemon slices in the foreground.

Regular Cleaning:

- **Daily:** After each use, remove the ice basket and wipe the interior with a clean, damp cloth.
- **Weekly/Bi-weekly:** For thorough cleaning, unplug the unit. Remove the ice basket. Clean the water reservoir and ice-making components with a solution of warm water and mild vinegar (1:1 ratio) or a mild detergent. Use a soft brush for hard-to-reach areas. Rinse thoroughly with clean water.
- **Draining Water:** To drain water, locate the drain plug at the bottom of the unit (if applicable, otherwise, carefully tilt to empty).
- **Exterior Cleaning:** Wipe the exterior with a soft, damp cloth. Do not use harsh chemicals or abrasive cleaners.

Storage:

If the ice maker will not be used for an extended period, drain all water, clean the unit thoroughly, and allow it to air dry completely before storing in a cool, dry place.

TROUBLESHOOTING

Before contacting customer support, please refer to the following common issues and solutions:

Problem	Possible Cause	Solution
"ADD WATER" indicator is on.	Water reservoir is empty or low.	Add potable water to the MAX fill line.
"ICE FULL" indicator is on.	Ice basket is full.	Remove ice from the basket.
Ice maker not producing ice.	No water, ice full, or unit not powered on.	Check water level, empty ice basket, ensure unit is plugged in and powered on.
Ice cubes are too small or clumpy.	Water temperature too high, or unit needs cleaning.	Use colder water. Perform a self-cleaning cycle or manual cleaning.
Unusual noise during operation.	Normal operation sounds (compressor, water pump) or unit not level.	Ensure unit is on a flat, stable surface. If noise is excessive or unusual, contact support.

SPECIFICATIONS

- **Brand:** AGLUCKY
- **Model Name:** AGLUCKY
- **Product Dimensions:** 12.6"D x 8.86"W x 12.6"H (32 x 22.5 x 32 cm)
- **Capacity:** Up to 26 lbs of ice per 24 hours
- **Water Tank Capacity:** Approximately 1.5L
- **Ice Production Time:** 9 bullet ice cubes in 6-8 minutes
- **Ice Cube Sizes:** Small (S) and Large (L) bullet ice
- **Wattage:** 150 watts
- **Noise Level:** ≤40dB

WARRANTY AND SUPPORT

For warranty information or technical support, please contact AGLUCKY customer service. Refer to the product packaging or the official AGLUCKY website for the most up-to-date contact details.

Note: Keep your purchase receipt as proof of purchase for warranty claims.

