

[Manuals.plus](#) /

› [Reaks](#) /

› Reaks Heated Blanket Throw (Model TH001) - Instruction Manual


Reaks TH001

Reaks Heated Blanket Throw (Model TH001) - Instruction Manual

IMPORTANT SAFETY INSTRUCTIONS

Please read all instructions carefully before using your Reaks Heated Blanket Throw. Retain this manual for future reference.

- Do not use with infants, children, incapacitated persons, or anyone insensitive to heat.
- Do not use if the blanket is wet.
- Avoid folding or bunching the blanket tightly during use to prevent overheating.
- Do not insert pins or other metallic objects into the blanket.
- Always disconnect the power cord from the outlet when not in use or before cleaning.
- This blanket is equipped with ETL and FCC certifications, ensuring it meets strict safety standards.
- The blanket features an automatic shut-off function after 3 hours to prevent overheating and conserve energy.



The Reaks Heated Blanket Throw is designed with multiple safety features, including FCC and ETL certifications, and built-in overheat protection.



Internal structure of the blanket showing the soft flannel surface, wire fixing layer, NTC/PTC heating wires, and cozy sherpa back for even heat distribution and comfort.

PRODUCT OVERVIEW

The Reaks Heated Blanket Throw provides customizable warmth and comfort. It features ultra-soft flannel and sherpa fabric, a user-friendly digital controller, and multiple heat and timer settings.



The Reaks Heated Blanket Throw, 50x60 inches, draped over a sofa, ready for use.

THICK FLANNEL & SHERPA FABRIC



Detailed view of the thick flannel and sherpa fabric, highlighting its soft and comfortable texture.

SETUP

1. **Unpack:** Carefully remove the heated blanket and controller from its packaging.
2. **Connect Controller:** Locate the connector on the blanket and firmly plug in the controller cord. Ensure a secure connection.
3. **Position Blanket:** Place the blanket on your desired surface (sofa, bed, chair). Ensure it is spread out evenly and not bunched up.
4. **Plug In:** Connect the power cord from the controller to a standard 120V AC electrical outlet.

SMART CONTROL



Digital
Controller



3 Hours
Auto Off



10 Heat
Levels



1-9H Timer
Settings



The digital controller for the Reaks Heated Blanket, showing its intuitive button layout for heat and timer adjustments.

OPERATION

1. **Power On:** Press the power button (⏻) on the controller to turn on the blanket. The display will illuminate.
2. **Adjust Heat:** Use the '+' and '-' buttons to cycle through the 10 heat settings (ranging from 85°F to 115°F). Select your desired warmth level.
3. **Set Timer:** Press the timer button (⌚) to adjust the automatic shut-off timer. You can choose settings from 1 to 9 hours.
4. **Automatic Shut-Off:** The blanket will automatically turn off after the set timer duration or after 3 hours if no specific timer is selected.
5. **Power Off:** Press the power button (⏻) again to turn off the blanket.

A woman with blonde hair is sitting on a white sofa, wrapped in a green and white heated blanket. She is holding a white mug and has her eyes closed, appearing to be relaxing. A digital controller for the blanket is visible on the sofa next to her.

Enjoy the warm afternoon time

A user enjoying the warmth of the Reaks Heated Blanket Throw while relaxing on a sofa.

CARE AND MAINTENANCE

To ensure the longevity and proper functioning of your heated blanket, follow these care instructions:

1. **Disconnect Power:** Always unplug the blanket from the wall outlet and detach the controller from the blanket before cleaning.
2. **Machine Wash:** The blanket is machine washable. Use a gentle cycle with cold water.
3. **Detergent:** Use a mild detergent. Do not use bleach.
4. **Rinse:** Rinse thoroughly.
5. **Drying:** Line dry or tumble dry on a low heat setting. Ensure the blanket is completely dry before reconnecting the controller and using it.

Do NOT: Dry clean, iron, or bleach the blanket. Do not wring or twist the blanket.



MACHINE WASHABLE

Unplug the controller before putting the blanket in front of the washing machine.

Instructions for machine washing the blanket, emphasizing the detachment of the controller before washing.

TROUBLESHOOTING

If you encounter any issues with your Reaks Heated Blanket Throw, please refer to the following common solutions:

- **Blanket Not Heating:**

- Ensure the power cord is securely plugged into a working electrical outlet.
- Verify that the controller cord is firmly connected to the blanket.
- Check if the power button on the controller has been pressed to turn the blanket on.

- **Controller Display Not Working:**

- Confirm the blanket is plugged into a live power source.
- Try unplugging and re-plugging the blanket from the wall outlet to reset the controller.

- **Blanket Overheating or Shutting Off Unexpectedly:**


- Ensure the blanket is spread out flat and not folded or bunched, which can trigger safety shut-off.
- The blanket has a built-in 3-hour auto-off safety feature. If it shuts off after this period, it is operating as designed.

If these steps do not resolve the issue, please contact customer support.

SPECIFICATIONS

Feature	Detail
Model Name	TH001
Size	50 x 60 inches
Material	Polyester (Flannel & Sherpa)
Color	Green
Heat Settings	10 levels (85°F–115°F)
Timer Settings	1-9 hours
Auto Shut-Off	Yes (3 hours default)
Safety Certifications	ETL, FCC
Care Instructions	Machine Washable

SIZE & USAGE SCENARIO



For Chair



For Couch



For Knee



For Shoulder



Visual representation of the blanket's dimensions (50x60 inches) and suggested uses for different scenarios.

WARRANTY AND SUPPORT

Reaks is committed to providing high-quality products and excellent customer service.

- **Warranty:** Please refer to the product packaging or the official Reaks website for specific warranty details.
- **Customer Support:** If you have any questions, concerns, or require assistance with your heated blanket, our professional support team is available 24/7.
- **Contact:** For support, please visit the Reaks store on Amazon or contact us through the platform where you purchased the product.

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question