



[Manuals.plus](#) /

› [VERMESS](#) /

› VERMESS 50 Inch L Shaped Desk Instruction Manual

VERMESS 50 Inch L Shaped Desk

VERMESS 50 Inch L Shaped Desk Instruction Manual

Model: 50 Inch L Shaped Desk

INTRODUCTION

This manual provides detailed instructions for the assembly, operation, and maintenance of your VERMESS 50 Inch L Shaped Desk. Please read all instructions carefully before beginning assembly and retain this manual for future reference. Proper assembly and care will ensure the longevity and optimal performance of your desk.

SAFETY INFORMATION

For your safety and to prevent damage to the product, please adhere to the following guidelines:

- Always ensure that the desk is properly assembled according to the instructions provided.
- Do not place heavy objects on the desk that exceed its weight capacity of 176 lbs (80 kg).
- Avoid standing or sitting on the desk surfaces.
- Keep small parts away from children during assembly to prevent choking hazards.
- Use the desk on a flat, stable surface to prevent tipping.
- Regularly check all fasteners to ensure they remain tight.

PACKAGE CONTENTS

Before assembly, verify that all components listed below are present and undamaged. If any parts are missing or damaged, please contact customer support.

- Desk Panels (Main, Side, Corner)
- Metal Frame Components (Legs, Support Bars)
- Movable CPU Stand
- Storage Bag
- Assembly Hardware (Screws, Bolts, Allen Wrench)

- Instruction Manual

SETUP AND ASSEMBLY

The VERMESS 50 Inch L Shaped Desk is designed for easy assembly. It can be configured in either a left-hand or right-hand L-shape to suit your space. All necessary tools are included.

Step 1: Unpack and Identify Parts

Carefully unpack all components and lay them out on a clean, soft surface to prevent scratches. Refer to the parts list in your included paper manual to identify each piece.

Step 2: Assemble the Metal Frame

Attach the metal legs to the main support bars using the provided screws and Allen wrench. Ensure all connections are secure but do not overtighten initially.



Image: Close-up view of the X-brace design on the metal frame, illustrating structural support.

Step 3: Attach Desk Panels

Place the desk panels onto the assembled frame. Align the pre-drilled holes and secure the panels to the frame using the appropriate screws. You can choose to assemble the desk in a left-hand or right-hand L-shape configuration at this stage.



Image: The desk shown in two different L-shaped configurations, demonstrating its reversible design.

Step 4: Install Movable CPU Stand and Storage Bag

The movable CPU stand can be placed on either side of the desk or underneath. The storage bag attaches to the side of the desk using its integrated hooks or fasteners. Refer to the diagram for optimal placement.



**Reversible
Installation Free to Match**

Image: A detailed view of the movable CPU stand positioned under the desk and a storage basket on the side.

Step 5: Final Tightening

Once all components are in place and aligned, gradually tighten all screws and bolts. Do not overtighten to avoid stripping the threads or damaging the material.

OPERATING INSTRUCTIONS

Your VERMESS L Shaped Desk offers versatility for various uses.

Reversible Configuration

The desk can be assembled with the longer section on either the left or right side, allowing it to fit different room layouts. This flexibility enables you to optimize your workspace for gaming, office work, or studying.



Image: A spacious office setup demonstrating the desk's ability to form a U-shape for multiple users or extensive workspace.

Using the Storage Bag and CPU Stand

The included storage bag provides convenient access to accessories, headphones, or documents. The movable CPU stand keeps your computer tower off the floor, protecting it from dust and improving airflow.




Image: A close-up of the fabric storage bag hanging from the desk, showing its capacity for various items.



Image: A computer tower resting on the movable CPU stand, highlighting its function.

MAINTENANCE

To maintain the appearance and functionality of your VERMESS desk, follow these simple care instructions:

- **Cleaning:** Wipe the desk surfaces with a dry cloth. For stubborn marks, use a slightly damp cloth and mild soap, then dry immediately. Avoid harsh chemicals or abrasive cleaners.
- **Spills:** The desk surface is waterproof. In case of spills, wipe them immediately to prevent any potential long-term damage or staining.



Image: Water beads on the desk surface, illustrating its waterproof feature.

- **Fasteners:** Periodically check all screws and bolts to ensure they are tight. Retighten if necessary to maintain stability.
- **Avoid Heat:** Do not place hot items directly on the desk surface without protection.

TROUBLESHOOTING

If you encounter any issues with your desk, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Desk is wobbly	Loose fasteners; uneven floor.	Ensure all screws and bolts are tightened. Adjust the desk's feet if available, or place shims under the legs on an uneven floor.
Parts do not align during assembly	Incorrect orientation of parts; fasteners overtightened prematurely.	Review the assembly diagrams. Loosen fasteners, realign parts, then retighten gradually.

Problem	Possible Cause	Solution
Missing hardware or damaged parts	Shipping damage; packaging error.	Contact VERMESS customer support with your purchase details for replacement parts.

SPECIFICATIONS

- **Brand:** VERMESS
- **Model:** 50 Inch L Shaped Desk
- **Shape:** L-Shape (Reversible)
- **Product Dimensions:** 110D x 127W x 75H Centimetres (43.3D x 50W x 29.5H Inches)
- **Color:** Black
- **Style:** Modern
- **Base Material:** Metal
- **Top Material Type:** Plastic
- **Finish Type:** Painted
- **Special Features:** Reversible, Rust Resistant, Movable CPU Stand, Side Storage Bag
- **Weight Capacity:** 176 lbs (80 kg)
- **Assembly Required:** Yes (Tools Included)

Reversible L-Shape Desk

weight Capacity: 176LBS




Image: A detailed diagram illustrating the dimensions of the VERMESS L Shaped Desk.

WARRANTY AND SUPPORT

VERMESS products are manufactured with quality and durability in mind. For specific warranty information, please refer to the documentation included with your purchase or contact VERMESS customer support directly. If you have any questions, require assistance with assembly, or need replacement parts, please reach out to our support team through the retailer's platform or the official VERMESS website.