

Virubi 77 Inch Mid Century Modern TV Stand

Virubi 77 Inch Mid Century Modern TV Stand User Manual

Model: 77 Inch Mid Century Modern TV Stand

1. PRODUCT OVERVIEW

The Virubi 77 Inch Mid Century Modern TV Stand is designed to accommodate televisions up to 85 inches, offering a blend of retro charm and modern functionality. This entertainment center features ample storage solutions, including drawers and cabinets, to help organize your living space.

Key Features:

- Mid-Century Modern Design:** Walnut finish with fluted glass doors and angled wooden legs.
- Large TV Compatibility:** Suitable for TVs ranging from 65 to 85 inches.
- Smart Storage:** Includes two drawers, one soft-closing cabinet, and sliding doors for media devices, DVDs, and books.
- Durable Construction:** Made from high-quality engineered wood and solid legs for stability.
- Easy Assembly & Maintenance:** Designed for straightforward setup and simple cleaning.



This image displays the fully assembled Virubi 77 Inch Mid Century Modern TV Stand in a living room environment, showcasing its walnut finish, fluted sliding doors, and overall aesthetic.

2. SAFETY INFORMATION

Please read and follow all safety instructions carefully to prevent injury or damage to the product.

- Always assemble the TV stand securely to the wall using appropriate anti-tip hardware (not included) to prevent tip-overs, especially in households with children or pets.
- Do not place heavy items on the top shelves or in a manner that could cause instability.
- Keep the TV stand away from children and pets during assembly and use to prevent injuries from sharp edges or small parts.
- Ensure all screws and fasteners are tightened securely before use. Periodically check and re-tighten as needed.
- Do not exceed the maximum weight capacity of the TV stand. Refer to the specifications section for details.

3. SETUP AND ASSEMBLY

This TV stand is designed for easy assembly. Please follow the detailed instructions provided in the separate assembly guide included with your product. Ensure all components are present before beginning assembly.

Assembly Steps (General):

1. Unpack all components and verify against the parts list in the assembly guide.
2. Identify and separate hardware.
3. Assemble the main frame of the TV stand according to the numbered steps.
4. Attach the solid wood legs securely.
5. Install drawers, cabinet doors, and sliding doors.
6. Ensure all connections are tight and the stand is stable.



This image highlights key construction details of the TV stand, including the high-quality MDF board, the smooth operation of the drawer sliding rails, a dedicated cable hole for wire management, and the sturdy solid wood legs that provide support.



This image focuses on the aesthetic and functional details of the TV stand, showing the elegant handles, the premium soft-closing hinges for smooth operation, the distinctive waveform pattern on the glass doors, and the textured design of the solid cabinet door.

4. OPERATING INSTRUCTIONS

Once assembled, the TV stand is ready for use. Place your television centrally on the top surface, ensuring it is stable and within the recommended size and weight limits.

Storage Features:

- Drawers:** Utilize the two deep drawers for storing smaller items such as remote controls, game controllers, or accessories.
- Soft-Closing Cabinet:** The cabinet with a soft-closing door provides concealed storage for various items.
- Sliding Glass Doors:** The central section features sliding glass doors, ideal for displaying or storing media devices like soundbars, gaming consoles, or decorative items while allowing remote control signals to pass through.
- Cable Management:** Use the integrated cable holes at the back of the stand to route and organize

power cords and media cables, keeping your setup tidy.

Multiple Storage Space



Soft-Closing Door Storage

Sliding Glass Doors Cabinet

2 Deep Drawers

This image illustrates the versatile storage options of the TV stand, featuring a cabinet with a soft-closing door, a central cabinet with sliding glass doors, and two deep drawers, all designed to organize media devices and accessories.

Color Difference

Images may differ slightly due to environment, monitors, and timing.

Color variations are normal. Please refer to the actual product.



BrightLight



Cool Light



Natural Light



Warm Light

This image provides a view into the interior storage capabilities of the TV stand, demonstrating how items like books and small storage boxes can be neatly arranged within its various compartments.



This image shows the TV stand in its intended use, supporting a large television (up to 85 inches) and featuring additional decorative items like a record player and a small potted plant, highlighting its functional and aesthetic integration into a living space.

5. MAINTENANCE

Proper care will ensure the longevity and appearance of your TV stand.

- **Cleaning:** Wipe the surface with a soft, damp cloth. Avoid using harsh chemicals, abrasive cleaners, or polishes that may damage the finish.
- **Spills:** Immediately wipe up any spills to prevent staining or water damage.
- **Sunlight:** Avoid prolonged exposure to direct sunlight, which can cause fading or discoloration.
- **Heat:** Do not place hot items directly on the surface. Use coasters or protective pads.
- **Hardware:** Periodically check all screws and fasteners to ensure they remain tight. Re-tighten if necessary.

6. TROUBLESHOOTING

If you encounter any issues with your TV stand, refer to the following common solutions:

- **Wobbly Stand:** Ensure all assembly screws are fully tightened. Check that the stand is placed on a level surface. Adjust leg levelers if present.
- **Drawers/Doors Not Closing Smoothly:** Verify that the drawer slides or door hinges are correctly installed and free of obstructions. Check for any loose hardware.
- **Missing Parts:** If any parts were missing during assembly, contact customer support immediately for replacements.
- **Damage During Shipping:** If the product arrived damaged, document the damage with photos and contact customer support before attempting assembly.

7. SPECIFICATIONS

Feature	Detail
Brand	Virubi
Model	77 Inch Mid Century Modern TV Stand
Material	Engineered Wood, Walnut Wood
Color	Walnut
Shape	Rectangular
Overall Width	77 inches (approx. 195.6 cm)
TV Size Compatibility	Up to 85 inches
Storage	2 Drawers, 1 Soft-Closing Cabinet, Sliding Glass Doors

size: inch






This technical drawing provides precise measurements of the TV stand in inches, detailing the overall width, height, and depth, as well as the dimensions of individual compartments, drawers, and doors for accurate planning.


8. WARRANTY AND SUPPORT

For warranty information or customer support, please refer to the documentation included with your purchase or contact Virubi customer service directly. Ensure you have your purchase details and product model information ready when contacting support.

For further assistance, please visit the official Virubi website or contact their customer service department.

Related Documents - 77 Inch Mid Century Modern TV Stand

 <p>Assembly Instructions-Please keep for future reference.</p> <p>DIMENSIONS width-70.87inch depth-16.5inch height-20.8inch</p> <p>Important-Please read these instructions fully before starting assembly.</p> <p>page 1 of 13</p>	<p>Lark Manor Jacynth Media Console Assembly Instructions (Model cshn6356)</p> <p>Detailed assembly guide for the Lark Manor Jacynth media console, model cshn6356. Includes a comprehensive list of parts, hardware, and step-by-step instructions for building the furniture.</p>
 <p>WLIVE</p> <p>ADSG025 Wood TV Stand with Leg</p>	<p>WLIVE ADSG025 Wood TV Stand with Leg Assembly Instructions</p> <p>Step-by-step assembly instructions for the WLIVE ADSG025 Wood TV Stand with Leg, including parts list, guidelines, and adjustment tips.</p>
 <p>Assembly Instruction</p> <p>Trouble shooting:</p> <ul style="list-style-type: none">Missing / Wavy / Broken parts and installation issuesSend email with your question pic, order NO. and screenshot of order detailsRespond within 24 hoursIssue resolved	<p>Ebern Designs TV Stand Assembly Instructions Modern Entertainment Center Guide</p> <p>Comprehensive assembly instructions for the Ebern Designs TV Stand. This guide provides detailed steps, a parts list, hardware inventory, safety information, and troubleshooting tips for assembling your modern entertainment center.</p>
 <p>Assembly Instructions - Please keep for future reference.</p> <p>DIMENSIONS width-78.7inch depth-16.5inch height-20.8inch</p> <p>Important - Please read these instructions fully before starting assembly.</p> <p>page 1 of 13</p>	<p>Mercer41 TV Stand Assembly Instructions - Model fpae2109</p> <p>Comprehensive assembly instructions and care guide for the Mercer41 78.7-inch minimalist TV stand (Model fpae2109), including dimensions, parts list, hardware details, step-by-step assembly, and hinge adjustment.</p>
 <p>ASSEMBLY INSTRUCTIONS</p> <p>Corrigan Studio® 59.4" Wide Sideboard Assembly Instructions</p>	<p>Comprehensive assembly guide for the Corrigan Studio® 59.4" wide sideboard, featuring a mid-century modern design with 3 drawers and 2 doors. Includes detailed parts list, hardware specifications, and step-by-step visual instructions for safe and correct assembly.</p>



[Sapa Mid-Century Modern 4-Door TV Stand Assembly Instructions | NTC NCAC1104](#)

Assembly instructions for the Sapa Mid-Century Modern Solid Wood TV Stand 4-Door Media Console. This guide provides a detailed component list, hardware breakdown, step-by-step assembly procedures, and instructions for adjusting door hinges and floor levelers.