

[Manuals.plus](#) /

> [FANMIS](#) /

> FANMIS Vintage Rectangular Women's Watch Model 1085 User Manual

FANMIS 1085

FANMIS Vintage Rectangular Women's Watch Model 1085 User Manual

PRODUCT OVERVIEW

The FANMIS Vintage Rectangular Women's Watch Model 1085 is a stylish timepiece featuring a Japanese quartz analog movement for accurate timekeeping. It is designed with a durable hardened mineral glass watch face and a comfortable leather strap. This watch is suitable for various daily activities.





Image 1: Front view of the FANMIS Vintage Rectangular Women's Watch, featuring a silver case, white dial with Roman numerals, blue hands, and a black leather strap.

SETUP INSTRUCTIONS

Follow these steps to set up your new FANMIS watch:

1. **Unpack the Watch:** Carefully remove the watch from its packaging. Ensure all protective films are removed from the watch face and case.
2. **Set the Time:**

- Pull the crown (the small knob on the side of the watch case) outwards to the first or second position (depending on the model, usually the second position for time setting).
- Rotate the crown to adjust the hour and minute hands to the correct time.
- Once the time is set, push the crown back into its original position to start the watch movement.

3. Adjust the Strap:

- Place the watch on your wrist.
- Thread the leather strap through the buckle and adjust it to a comfortable fit. The strap should be snug but not too tight, allowing for slight movement.

Your browser does not support the video tag.

Video 1: A demonstration of the watch's features and how to wear it. This video is provided by the seller, FORWATCH.

OPERATING INSTRUCTIONS

Your FANMIS watch is designed for simple operation:

- **Timekeeping:** The watch operates continuously once the crown is pushed in after setting the time. The quartz movement ensures accurate time display.
- **Daily Wear:** The watch is suitable for daily wear. Its comfortable leather strap and durable construction make it ideal for various indoor and outdoor activities.



Image 2: The FANMIS watch worn on a wrist, highlighting its rectangular design and comfortable fit.

MAINTENANCE GUIDELINES

Proper care will extend the life and appearance of your watch:

- **Cleaning:** Wipe the watch case and strap with a soft, dry cloth regularly to remove dust and dirt. For the leather strap, avoid harsh chemicals.
- **Water Resistance:** This watch is 3ATM water resistant, meaning it can withstand splashes, accidental rain, or hand washing. **Do not press any buttons underwater.** It is not suitable for bathing, swimming, diving, or prolonged water exposure. Excessive water contact will shorten the watch's life.
- **Temperature:** Avoid exposing the watch to extreme hot or cold temperatures, as this can affect the battery and movement.
- **Storage:** When not in use, store the watch in a dry place, away from direct sunlight and strong magnetic fields.
- **Battery Replacement:** The watch uses 1 CR123A battery. When the watch stops or runs inaccurately, replace the battery promptly. It is recommended to have battery replacement

performed by a qualified watch technician to ensure proper sealing and water resistance.

Your browser does not support the video tag.

Video 2: A promotional video showcasing the watch's design and features, including its water resistance. This video is provided by the seller, TimeYear.

TROUBLESHOOTING GUIDE

Refer to the table below for common issues and their solutions:

Problem	Possible Cause	Solution
Watch stops or runs slowly.	Low battery.	Replace the battery (1 CR123A). Consult a professional for replacement.
Mist or droplets inside the watch face.	Moisture ingress, possibly due to improper sealing or exposure to extreme temperature changes.	Contact the manufacturer or a qualified watch repair service immediately to prevent corrosion of internal components. Avoid further water exposure.
Time is inaccurate.	Crown not fully pushed in after setting, or battery is low.	Ensure the crown is fully pushed in. If the problem persists, replace the battery.
Strap discomfort or irritation.	Strap too tight, or skin sensitivity to material.	Adjust the strap for a looser fit. If irritation continues, consider replacing the strap with a different material.

PRODUCT SPECIFICATIONS

Brand: FANMIS

Model Number: 1085

Movement: Imported Japanese Quartz Analog

Case Material: Zinc Alloy

Watch Band Material: Leather

Band Clasp Type: Buckle

Case Diameter: 30mm

Case Thickness: 9mm

Watch Length: 22cm

Band Width: 20mm

Water Resistance: 3ATM (98 FT) - Suitable for hand washing, rain, splashes. Not for bathing, swimming, diving.

Battery: 1 CR123A (included)

Watch Glass: Hardened Mineral Glass (Impact and scratch resistant)

WARRANTY AND SUPPORT

This product is covered by a standard return policy of 30 days for refund or replacement. For specific warranty details, please refer to the documentation included with your purchase or contact the seller directly.

For technical support or inquiries, please visit the [FANMIS Store on Amazon](#) or contact your retailer.