

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Bestier](#) /

› [Bestier Criss Cross Office Chair H200671A Instruction Manual](#)

Bestier H200671A

Bestier Criss Cross Office Chair H200671A Instruction Manual

Model: H200671A

Brand: Bestier

1. INTRODUCTION

Thank you for choosing the Bestier Criss Cross Office Chair H200671A. This manual provides essential information for the safe assembly, operation, and maintenance of your new chair. Please read these instructions thoroughly before use and retain them for future reference.

2. SAFETY INFORMATION

To ensure safe operation and prevent injury, please observe the following warnings:

- When the armrests are laid flat at 180°, it is not permitted to stand or place heavy objects on the armrests.
- Ensure all screws and bolts are securely tightened before using the chair. Periodically check and re-tighten as necessary.
- Do not use the chair on uneven surfaces.
- Do not exceed the maximum weight recommendation of 350 pounds.

3. PACKAGE CONTENTS

Verify that all components listed below are present in your package. If any parts are missing or damaged, please contact customer support.

Adjustable Armrest Flip Function

Armrests can be adjusted from **90°** to **180°**



Image: All chair components laid out for assembly.

- Backrest Cushion (A)
- Seat Cushion (B)
- Footrest Cushion (C)
- Armrests (E x2)
- Chair Base (T)
- Casters (J x5)
- Gas Lift Cylinder (I)
- Gas Lift Cover (O)
- Mechanism (F)
- Footrest Frame (R)
- Side Covers (D x2)
- Screws, Washers, and Allen Wrench (Various sizes, K, N, S, L, M, P)

4. SETUP AND ASSEMBLY

Follow these steps to assemble your Bestier Criss Cross Office Chair. It is recommended to have a second person for assistance during certain steps.

Assembly Video Guide

Your browser does not support the video tag.

Video: Detailed assembly instructions for the Bestier Criss Cross Chair.

- Assemble the Chair Base:** Attach the five legs to the central hub of the chair base (T) using the provided screws (S). Insert the casters (J) into the ends of each leg.
- Install the Gas Lift:** Place the gas lift cylinder (I) into the center hole of the assembled chair base. Cover it with the gas lift cover (O).
- Attach the Mechanism:** Secure the mechanism (F) to the underside of the seat cushion (B) using the specified screws (L). Ensure the "FRONT" arrow on the mechanism aligns with the front of the seat.
- Connect Armrests:** Attach the armrests (E) to the sides of the seat cushion (B) and the backrest cushion (A) using the appropriate screws (M). Pay attention to the orientation of the armrests.
- Attach Backrest to Seat:** Secure the backrest cushion (A) to the seat cushion (B) using the remaining screws (M).
- Install Footrest:** Attach the footrest frame (R) to the underside of the seat cushion (B) using screws (K). Then, attach the footrest cushion (C) to the footrest frame.
- Mount the Seat to the Base:** Carefully place the assembled seat onto the gas lift cylinder. Press down firmly to ensure it is securely seated.
- Final Checks:** Ensure all connections are tight and the chair functions correctly before use.

5. OPERATING INSTRUCTIONS

Adjustable Armrests



Image: Armrests can be adjusted from 90° to 180° to expand seat width.

The chair features unique flip-up armrests that can be adjusted from 90° to 180°. To adjust, gently push the armrest inward, flatten it to 180°, and then raise it to lock at your desired angle. When flattened, the seat width extends from 16" to 46", providing ample space for sitting cross-legged or sharing with pets.

Reclining Function and Height Adjustment

Reclining Office Chair with Footrest

Adjustable at any angle from **90°** to **135°** and locking backrest for flexible adjustment



Image: Reclining positions from 90° to 135° and 360° swivel.

The thick backrest can be adjusted within a range of 90° to 135°. Use the lever located under the seat to recline the backrest to your preferred angle for working, gaming, or resting. The same lever also controls the seat height, offering a 4-inch adjustment range to match various desk heights.

Retractable Footrest



Image: The retractable footrest provides leg support for relaxation.

The chair includes a padded retractable footrest. To extend, pull the footrest out from under the seat. To retract, push it back in until it is fully stored. This feature allows you to stretch out and relax while reclining.

360° Swivel and Casters

The chair is equipped with 5 silent and smooth 360° rolling casters, allowing for easy mobility across your workspace. The chair also features a full 360° swivel for convenient movement and access.

Side Pockets

Two side pockets are integrated into the armrests, providing convenient storage for small items like remote controls, phones, or magazines, keeping them within easy reach.

Feature Overview Video

Your browser does not support the video tag.

Video: Overview of the Bestier Cross Legged Office Chair features, including armrests, recline, and footrest.

6. MAINTENANCE

Proper care will extend the life and appearance of your chair:

- **Cleaning:** Wipe clean with a damp cloth. Avoid harsh chemicals that may damage the PU leather surface.
- **Cushion Care:** The removable seat cushion allows for effortless daily cleaning and maintenance.
- **Hardware:** Periodically check all screws and bolts to ensure they remain tight. Re-tighten as needed to maintain stability.

7. TROUBLESHOOTING

If you encounter any issues with your chair, please refer to the following common solutions:

- **Chair feels wobbly:** Check that all assembly screws are securely tightened. Ensure the chair is on a flat, even surface.
- **Gas lift not adjusting height:** Ensure the height adjustment lever is fully engaged or disengaged as required. If the issue persists, the gas lift may need replacement.
- **Recline function not working:** Verify that the recline lock lever is disengaged. Check for any obstructions in the reclining mechanism.
- **Footrest not extending/retracting smoothly:** Check for any obstructions in the footrest mechanism. Ensure it is pulled or pushed along its tracks correctly.

For further assistance, please contact Bestier customer support.

8. SPECIFICATIONS

Feature	Detail
Brand	Bestier
Model Name	H200671A
Color	Beige
Material	Faux Leather, Memory Foam
Product Dimensions	18.11"D x 20.47"W x 42.91"H
Seat Height	18.11 Inches
Seat Depth	18.11 inches
Seat Length	20.47 Inches

Back Style	High Back
Special Features	Flippable Armrests, Reclining, Side Pocket
Reclining Positions	4 (90° to 135°)
Maximum Weight Recommendation	350 Pounds
Product Care Instructions	Wipe Clean
Item Weight	51.5 pounds
UPC	840408642330

9. WARRANTY AND SUPPORT

Bestier is committed to providing high-quality products and customer satisfaction. While specific warranty details are not provided in this manual, we offer a hassle-free purchase experience.

If you have any concerns before purchasing or after receiving your package, please do not hesitate to contact Bestier customer support. We aim to reply to all inquiries within 24 hours to ensure you receive prompt and helpful assistance.

For assembly questions, you may also refer to the installation video provided in the Setup section.