

## BEYOND HEAT 1500W Digital Electric Convection Baseboard Heater

# BEYOND HEAT 1500W Digital Electric Convection Baseboard Heater Instruction Manual

Model: 1500W Digital Electric Convection Baseboard Heater

## 1. INTRODUCTION

---

Thank you for choosing the BEYOND HEAT 1500W Digital Electric Convection Baseboard Heater. This manual provides essential information for the safe and efficient operation of your new heater. Please read all instructions carefully before use and retain this manual for future reference.

This electric baseboard heater is designed to provide consistent and comfortable heat for indoor spaces, featuring an adjustable digital thermostat, two heat settings, and advanced safety features.

## 2. IMPORTANT SAFETY INFORMATION

---

**WARNING: To reduce the risk of fire, electric shock, or injury, read and understand all instructions before using this heater.**

- **Overheat Protection:** The heater is equipped with an automatic overheat protection system. If the internal components reach a certain temperature, the heater will automatically shut off. Unplug the heater and allow it to cool down before restarting.
- **Tip-over Protection:** A safety tip-over switch is integrated into the base of the heater. If the heater is accidentally knocked over, it will automatically power off to prevent hazards. Ensure the heater is placed on a stable, flat surface.
- **Electrical Safety:** Always plug the heater directly into a 120V AC electrical outlet. Do not use extension cords or power strips. Ensure the electrical circuit is not overloaded.
- **Placement:** Place the heater on a firm, level surface. Maintain a minimum distance of 3 feet (0.9 meters) from walls, furniture, curtains, and other combustible materials. Do not block air inlets or outlets.
- **Moisture:** Do not use the heater in wet or damp locations, such as bathrooms or laundry areas. Keep away from water sources.
- **Supervision:** Do not leave the heater unattended while in operation. Keep children and pets away from the heater.
- **Maintenance:** Unplug the heater before cleaning or performing any maintenance. Refer to the maintenance section for proper cleaning procedures.

### 3. PRODUCT FEATURES

- **Digital Adjustable Thermostat:** Customize your warmth with two heat settings and a digital display for precise temperature control.
- **Two Heat Settings:** Offers 750W for moderate heating and 1500W for maximum warmth, suitable for small to medium-sized rooms.
- **Quiet Convection Heating:** Utilizes convection technology for silent operation, making it ideal for bedrooms, offices, and other quiet indoor spaces.
- **Overheat Protection:** Automatically shuts off if the unit overheats, ensuring safety.
- **Tip-over Protection:** Automatically powers off if the heater is accidentally tipped over.
- **Compact & Portable Design:** With dimensions of 29.25 x 5.25 x 9.25 inches, it fits easily into various spaces and is lightweight for portability.
- **ETL Approved:** Certified for safety and reliability in the US market.



Image: The digital display and control panel of the BEYOND HEAT 1500W Digital Electric Convection Baseboard Heater, highlighting the digital display, two heat settings, quiet operation, and timer function icons.

## Personalized Comfortable

**Power:** Low Heat (750W) ,High Heat (1,500W)  
**Timer adjustment range:**1 to 12 hours




Image: An illustration demonstrating the heater's tip-over protection feature, showing the unit automatically powering off if it falls.

## 4. SETUP AND INSTALLATION

---

1. **Unpacking:** Carefully remove the heater from its packaging. Retain packaging for storage or shipping if needed.
2. **Placement:** Place the heater on a stable, level, and heat-resistant surface. Ensure it is at least 3 feet (0.9 meters) away from any walls, furniture, drapes, or other flammable materials.
3. **Power Connection:** Plug the heater directly into a standard 120V AC, 60Hz electrical outlet. Do not use extension cords, power strips, or surge protectors.
4. **Initial Use:** During the first few minutes of initial use, a slight odor may be detected. This is normal and will quickly disappear.

## 5. OPERATING INSTRUCTIONS

---

The BEYOND HEAT baseboard heater features a digital control panel for easy operation.



Image: A detailed view of the heater's control panel, showing the temperature display screen, UP/DOWN buttons, MODE button, and ON/OFF button. It also indicates the power settings (Low Heat 750W, High Heat 1500W) and timer adjustment range (1 to 12 hours).

### Control Panel Functions:

- **ON/OFF Button:** Press to turn the heater on or off.
- **MODE Button:** Cycles through available heat settings (e.g., Low Heat 750W, High Heat 1500W).
- **UP/DOWN Buttons (▲ / ▼):** Adjust the desired temperature setting on the digital display.
- **Timer Function:** Set the operating time from 1 to 12 hours. The heater will automatically shut off once the set time expires.

### Setting the Temperature:

1. Turn on the heater using the ON/OFF button.
2. Use the UP (▲) or DOWN (▼) buttons to select your desired room temperature. The digital display will show the set temperature.
3. The heater will automatically maintain the set temperature, cycling on and off as needed.

### Selecting Heat Mode:

1. With the heater on, press the MODE button to switch between the 750W (Low Heat) and 1500W (High Heat) settings.
2. Choose the appropriate setting based on your heating needs and room size.

### Using the Timer:

1. Press the Timer button to activate the timer function.
2. Use the UP (▲) or DOWN (▼) buttons to set the desired operating duration (1-12 hours).
3. The timer indicator will illuminate, and the heater will operate for the set duration before automatically turning off.

## 6. MAINTENANCE

---

Regular cleaning and maintenance will help ensure the longevity and efficient operation of your heater.

1. **Before Cleaning:** Always unplug the heater from the electrical outlet and allow it to cool completely before cleaning.
2. **Exterior Cleaning:** Wipe the exterior surfaces of the heater with a soft, damp cloth. Do not use abrasive cleaners, polishes, or any chemical solutions as these may damage the finish.
3. **Dust Removal:** Use a vacuum cleaner with a brush attachment to remove dust and lint from the air intake and exhaust grilles.
4. **Storage:** If storing the heater for an extended period, clean it thoroughly and place it back in its original packaging. Store in a cool, dry place.

## 7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Heater does not turn on.	No power to the unit.	Ensure the heater is securely plugged into a working 120V outlet. Check the circuit breaker.
Heater turns off unexpectedly.	Overheat protection activated.	Unplug the heater, allow it to cool for 30 minutes, and ensure air inlets/outlets are not blocked.
Heater turns off unexpectedly.	Tip-over protection activated.	Ensure the heater is on a stable, level surface. If it was tipped, place it upright and it should resume operation.
Heater is not producing enough heat.	Low heat setting selected or thermostat set too low.	Increase the temperature setting or switch to the 1500W (High Heat) mode. Ensure the room size is appropriate for the heater's output.
Unusual odor during initial use.	Normal for new heaters.	This will dissipate after a few minutes of operation. Ensure adequate ventilation.

## 8. SPECIFICATIONS

Feature	Detail
Brand	BEYOND HEAT
Model	1500W Digital Electric Convection Baseboard Heater
Power Output	750W / 1500W
Voltage	120 Volts
Dimensions (L x W x H)	29.25 x 5.25 x 9.25 inches (78D x 18W x 28H Centimetres)
Item Weight	2.84 kg
Heating Method	Convection
Special Features	Overheat Protection, Tip-over Protection, Adjustable Thermostat with Digital Display

Feature	Detail
Safety Certification	ETL Approved (US)
Indoor/Outdoor Usage	Indoor

## 9. WARRANTY AND SUPPORT

---

For warranty information or customer support, please refer to the product packaging or contact BEYOND HEAT customer service directly. Keep your purchase receipt as proof of purchase.