

JUMMICO LR25-0815

JUMMICO Electric Recliner Chair LR25-0815 User Manual

Model: LR25-0815 | Brand: JUMMICO

1. INTRODUCTION

Thank you for choosing the JUMMICO Electric Recliner Chair. This manual provides essential information for the safe assembly, operation, and maintenance of your new recliner. Please read these instructions carefully before use and retain them for future reference.

This electric recliner features an adjustable backrest and extendable footrest, controlled by a remote. It is designed for relaxation, reading, gaming, and sleeping in various indoor settings such as living rooms, bedrooms, or offices.

2. SAFETY INFORMATION

WARNING: Always follow the assembly and operating instructions carefully. Failure to do so may result in injury or damage to the product.

- Ensure all components are securely fastened before use.
- Do not allow children to play on or around the recliner unsupervised.
- Keep hands and feet clear of moving parts during operation.
- Do not exceed the maximum weight capacity of 136 kg (300 lbs).
- Only use the recliner indoors.
- If you have any questions or concerns, please contact customer service for assistance.

3. PACKAGE CONTENTS

Your JUMMICO Electric Recliner Chair package should include the following components:

- Recliner base
- Backrest

- Armrests (if separate)
- Power adapter and remote control
- Assembly hardware (screws, bolts, etc.)
- Instruction manual

Note: The recliner is delivered in one carton and requires assembly.



Image showing the recliner's dimensions, 136kg weight capacity, and indicating delivery in one carton with easy assembly.

4. SETUP AND ASSEMBLY

Assembly is designed to be simple and quick, typically taking around 30 minutes. No specific tools are required beyond what may be included.

1. Unpack all components from the carton and verify against the package contents list.
2. Place the recliner base in the desired location, ensuring sufficient space for reclining.
3. Attach the backrest to the base, aligning the brackets and securing them with the provided hardware.
4. Attach the armrests (if separate) following the detailed instructions in the included manual.
5. Connect the power adapter to the recliner and plug it into a suitable power outlet.
6. Ensure all connections are secure and the recliner is stable before first use.

Protective pads are included to prevent floor damage and enhance stability.

5. OPERATING INSTRUCTIONS

The JUMMICO Electric Recliner Chair is operated using the wired remote control.

Simple d'utilisation

Que ce soit pour un réglage continu ou une sélection rapide assis/allongé



Image illustrating the remote control for the electric recliner, with buttons for continuous adjustment and quick selection for sitting or lying down positions.

5.1 Remote Control Functions

- **Quick Sit Button:** Press to quickly return the recliner to the upright sitting position.
- **Quick Lie Down Button:** Press to quickly extend the footrest and recline the backrest to a fully relaxed position.
- **Continuous Adjustment Buttons (Up/Down Arrows):** Use these buttons for precise, continuous adjustment of the backrest and footrest to your desired angle. The chair can recline between 105° (reading) and 155° (siesta/sleeping).

Important Note: The backrest and footrest operate simultaneously. They cannot be adjusted independently.



Image demonstrating the adjustable angles of the electric recliner: 105° for reading, 120° for TV, and 155° for napping. It also notes that the backrest and armrests adjust simultaneously.

5.2 Recommended Uses

Votre compagnon de détente



Image showing different scenarios for using the recliner, including watching TV, reading, napping, playing video games, and listening to music, with angle indicators.

- **Reading:** Adjust to a comfortable upright position (approx. 105°).
- **Watching TV/Gaming:** A slightly reclined position (approx. 120°) is often preferred.
- **Relaxation/Napping:** Fully recline to 155° for maximum comfort.

6. MAINTENANCE

Regular maintenance will help prolong the life of your JUMMICO Electric Recliner Chair.

- **Cleaning:**
 - Wipe the fabric with a soft, damp cloth.
 - For spills, blot immediately with a clean, dry cloth. Do not rub.
 - Avoid using harsh chemicals or abrasive cleaners.

- **Frame:** Periodically check all bolts and screws to ensure they are tight. Tighten if necessary.
- **Electrical Components:** Keep the power cord and remote control away from water and sharp objects. Do not attempt to repair electrical components yourself.

7. TROUBLESHOOTING

If you encounter any issues with your recliner, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Recliner does not operate.	No power supply.	Check if the power cord is securely plugged into the wall outlet and the recliner. Ensure the outlet is functional.
Recliner makes unusual noises.	Loose connections or components.	Check all assembly bolts and screws and tighten if loose. Ensure no objects are obstructing the mechanism.
Recliner movement is jerky or slow.	Overload or power issue.	Ensure the weight limit (136 kg) is not exceeded. Check power supply for fluctuations.

If the problem persists after attempting these solutions, please contact JUMMICO customer service.

8. SPECIFICATIONS

Feature	Detail
Brand	JUMMICO
Model Number	LR25-0815
Color	Grey
Material	Metal, Fabric
Filling Material	Foam
Overall Dimensions (Upright)	Approx. 62 cm (W) x 55 cm (D) x 101 cm (H)
Overall Length (Reclined)	Approx. 99 cm
Seat Depth	55 cm
Chair Back Width	55 cm
Item Weight	30 Kilograms
Recommended Max Load	136 kg (300 lbs)
Special Features	Adjustable backrest, Electric recliner, Reclining, Side pocket, Adjustable lumbar support
Reclining Positions	Continuous adjustment from 105° to 155°
Assembly Required	Yes
Recommended Uses	Sleeping, Relaxation, Gaming, Reading

Feature	Detail
Indoor/Outdoor Use	Indoor
Motor Performance	Standby consumption < 1W, Noise < 55 dB, Rated power < 60W



Image displaying detailed measurements of the recliner in both upright and fully reclined positions, including seat depth, backrest height, and overall length when extended.

Moteur Sans Balais Haute Performance



< 1W

Consommation Veille



< 55 dB

Moins de bruit



≤ 60 W

Puissance nominale du moteur




Image detailing the high-performance brushless motor specifications: standby consumption less than 1W, noise level less than 55 dB, and rated motor power less than 60W.

9. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the specific warranty card included with your product or contact JUMMICO customer service directly.

Contact Information: Please visit the official JUMMICO website or refer to your purchase documentation for the most up-to-date customer service contact details.



