Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

JUMMICO LR25-0815

JUMMICO Electric Recliner Chair User Manual

Model: LR25-0815 | Brand: JUMMICO

1. Product Overview

The JUMMICO Electric Recliner Chair, Model LR25-0815, is designed to provide enhanced comfort and relaxation. This armchair features an adjustable backrest and footrest, operated by an electric motor for smooth transitions between sitting and reclining positions. It includes high-density foam padding, skin-friendly fabric, and a convenient side pocket. The chair is suitable for various settings such as living rooms, bedrooms, and home offices.
Key features include:

- **Electric Recline Function:** Effortlessly adjust the backrest and footrest to any angle between 90° and 170° using the remote control.
- **Padded Comfort:** High-density foam and durable fabric ensure a comfortable and supportive seating experience.
- **Side Pocket:** A convenient storage pocket is integrated for remote controls, magazines, or other small items.
- **Durable Design:** Constructed for longevity and stability, equipped with protective feet to safeguard floors.

2. Safety Instructions

Please read and follow these safety instructions carefully to prevent injury or damage to the product.

- **Maximum Weight Capacity:** Do not exceed the maximum weight recommendation of 136 kg (300 lbs).
- **Children and Pets:** Keep children and pets away from the recliner's moving parts, especially during operation.
- **Power Cord:** Ensure the power cord is not pinched, tangled, or placed under the chair where it could be damaged. Unplug the chair from the power outlet when not in use or before cleaning/maintenance.
- **Stable Surface:** Place the recliner on a flat, stable surface to prevent tipping.
- **Avoid Standing:** Do not stand on the footrest or armrests.
- **Liquid Spills:** Avoid spilling liquids on the chair, especially near electrical components.
- **Professional Repair:** Do not attempt to repair the electrical components or motor yourself. Contact qualified service personnel for repairs.

3. Package Contents

Before assembly, verify that all components are present and undamaged. If any parts are missing or damaged, please

contact customer support.

- Seat Base with Armrests
- Backrest
- Power Adapter and Cord
- Remote Control
- Instruction Manual (this document)

4. Assembly Instructions

Assembly of the JUMMICO Electric Recliner Chair is designed to be quick and straightforward, typically taking around 30 minutes with no special tools required.

1. **Unpack Components:** Carefully remove all parts from the packaging. Place them on a soft, clean surface to prevent scratches.
2. **Attach Backrest:** Align the metal brackets on the backrest with the corresponding slots on the seat base. Slide the backrest down firmly until it clicks securely into place. Ensure both sides are fully engaged.
3. **Connect Power:** Locate the power cable extending from the chair's base. Connect it to the power adapter, then plug the adapter into a standard electrical outlet.
4. **Remote Control Connection:** Ensure the remote control cable is securely plugged into the designated port on the chair's side or under the seat.
5. **Final Check:** Before use, gently push and pull on the backrest to confirm it is securely attached. Ensure all cables are neatly tucked away to avoid tripping hazards.




Figure 4.1: Side view of the recliner, illustrating its structure for assembly.

5. Operating Instructions

The JUMMICO Electric Recliner Chair is operated using a wired remote control, allowing for smooth and precise adjustments.

5.1 Remote Control Functions

The remote control features several buttons for adjusting the chair's position:

- **Up Arrow (Backrest/Footrest Extend):** Press and hold to extend the footrest and recline the backrest simultaneously. Release to stop at your desired position.
- **Down Arrow (Backrest/Footrest Retract):** Press and hold to retract the footrest and bring the backrest to an upright position simultaneously. Release to stop at your desired position.
- **Upright Position Button (Chair Icon):** Press this button to automatically return the chair to its fully upright sitting position (approximately 90°).

- **Recline Position Button (Reclined Figure Icon):** Press this button to automatically move the chair to a near-flat reclining position (approximately 170°).

5.2 Adjusting the Recliner

1. **Power On:** Ensure the chair is plugged into a working electrical outlet.
2. **Reclining:** To recline, press and hold the **Up Arrow** button. The footrest will extend, and the backrest will recline. Release the button when you reach your desired angle. The chair offers infinitely customizable positions between 90° and 170°.
3. **Returning Upright:** To return to an upright position, press and hold the **Down Arrow** button. The footrest will retract, and the backrest will move forward. Release the button when you are in the desired sitting position.
4. **Automatic Positions:** For quick adjustments, use the dedicated **Upright Position Button** or **Recline Position Button**.



Figure 5.1: Remote control and illustration of the chair's recline capabilities.



Figure 5.2: User demonstrating the full recline position of the electric armchair.

Figure 5.3: Visual guide to the electric reclining function and weight limit.

6. Maintenance and Care

Proper care will extend the life and appearance of your JUMMICO Electric Recliner Chair.

- **Cleaning:** For general cleaning, wipe the PU fabric with a soft, damp cloth. For stubborn stains, use a mild soap solution and then wipe with a clean, damp cloth. Avoid harsh chemicals or abrasive cleaners.
- **Dusting:** Regularly dust the chair with a soft, dry cloth.
- **Power Disconnection:** Always unplug the chair from the power outlet before cleaning or performing any maintenance.
- **Inspection:** Periodically check all connections and fasteners to ensure they are tight. Do not overtighten.
- **Avoid Direct Sunlight:** Prolonged exposure to direct sunlight can cause the fabric to fade.

7. Troubleshooting

If you encounter issues with your recliner, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Chair does not recline or move.	No power supply. Power cord or adapter is loose/damaged. Remote control cable is disconnected.	Ensure the power cord is securely plugged into both the chair and the wall outlet. Check the power adapter for any visible damage. Verify the remote control cable is firmly connected to the chair.
Motor makes unusual noise.	Obstruction in mechanism. Loose components.	Inspect under the chair for any objects obstructing the mechanism. If noise persists, discontinue use and contact customer support.
Chair is unstable or wobbly.	Loose assembly bolts. Uneven floor.	Check and tighten all assembly bolts. Ensure the chair is placed on a flat, level surface.

If the problem persists after attempting these solutions, please contact JUMMICO customer support for further assistance.

8. Specifications

Detailed specifications for the JUMMICO Electric Recliner Chair, Model LR25-0815:

- **Brand:** JUMMICO
- **Model Number:** LR25-0815
- **Product Dimensions (D x W x H):** 25.59" x 23.62" x 40.55" (65 cm x 60 cm x 103 cm)
- **Item Weight:** 30 kg (66 lbs)
- **Maximum Weight Recommendation:** 136 kg (300 lbs)
- **Frame Material:** PU
- **Fill Material:** Foam, Polyester
- **Recline Angle:** Approximately 90° (upright) to 170° (fully reclined)
- **Additional Features:** Adjustable Backrest, Back Support, Power Recliner, Reclining, Side Pocket
- **UPC:** 788418914439

Figure 8.1: Product dimensions in centimeters for the JUMMICO Electric Recliner Chair.

9. Warranty and Support

For warranty information, please refer to the documentation provided at the time of purchase or contact your retailer. JUMMICO is committed to customer satisfaction.
If you have any questions, require technical assistance, or need to report a missing/damaged part, please contact JUMMICO customer support through the retailer where the product was purchased or visit the official JUMMICO website for contact details.

© 2026 JUMMICO. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FJFD4GJK

More documents and user manuals: **https://manuals.plus/**