

Akitas X7

Akitas X7 600W Spot Cleaner User Manual

Model: X7

1. IMPORTANT SAFETY INSTRUCTIONS

Please read and understand all safety instructions before operating your Akitas X7 Spot Cleaner. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- Always unplug the appliance from the electrical outlet when not in use or before performing any maintenance or cleaning.
- Do not immerse the appliance in water or other liquids.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory, or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Use only cleaning solutions specifically designed for spot cleaners. Do not use flammable or combustible liquids.
- Do not use water hotter than 60°C (140°F) in the clean water tank, as this can damage the unit. Use room temperature water.
- Do not pick up anything that is burning or smoking, such as cigarettes, matches, or hot ashes.
- Do not use without tanks in place.
- Keep hair, loose clothing, fingers, and all parts of the body away from openings and moving parts.
- Inspect the power cord for damage before each use. Do not use if the cord or plug is damaged.

2. PRODUCT OVERVIEW

The Akitas X7 Spot Cleaner is a powerful and compact cleaning device designed for effective removal of embedded dirt, liquids, and stains from various surfaces such as carpets, upholstery, mattresses, and car interiors. It features a 600W motor and 14kPa suction for thorough cleaning.



Image 2.1: The Akitas X7 Spot Cleaner, highlighting its 600W motor for powerful performance.

Key Features:

- **Powerful Cleaning:** 600W motor and 14kPa suction for deep cleaning.
- **Dual Tank System:** Separate tanks for clean water (1.8L) and dirty water (1L) ensure hygienic cleaning.
- **Self-Cleaning Function:** A dedicated button for rinsing the suction hose to prevent odors.
- **Compact Design:** Easy to store and transport with dimensions of 36x22x28cm and a weight of 3.4kg.
- **Versatile Accessories:** Includes a spray brush, upholstery nozzle, and pet brush for various cleaning tasks.



Image 2.2: The Akitas X7 Spot Cleaner showing its 1.8L clean water tank and 1L dirty water tank.

3. SETUP AND ASSEMBLY

Follow these steps to prepare your Akitas X7 Spot Cleaner for use.

1. **Unpack the Unit:** Carefully remove all components from the packaging. Ensure all parts are present: main unit, flexible hose, cleaning nozzle, and any included accessories.
2. **Attach the Hose and Nozzle:** Connect the flexible hose to the designated port on the main unit. Securely attach the desired cleaning nozzle (e.g., spray brush) to the end of the hose.
3. **Fill the Clean Water Tank:** Remove the clean water tank (usually marked or clear) from the unit. Open the cap and fill it with clean, room-temperature water. You may add a recommended cleaning solution according to the solution's instructions. Do not exceed the 'MAX' fill line. Reattach the tank securely.

Ouvertures larges
Pour un remplissage et un nettoyage faciles



Image 3.1: Demonstrating how to easily fill the clean water tank and empty the dirty water tank.

**Solution de nettoyage bonus incluse –
Livré avec une bouteille gratuite de 115 ml de détergent de nettoyage**



Image 3.2: The Akitas X7 Spot Cleaner with an included bottle of cleaning detergent, ready for use.

4. OPERATION

Follow these steps for effective spot cleaning.

General Cleaning Process:

1. **Plug In:** Connect the power cord to a suitable electrical outlet.
2. **Pre-treat (Optional):** For tough stains, you may pre-treat the area with a suitable cleaning solution before using the spot cleaner.
3. **Spray:** Hold the cleaning nozzle over the stained area. Press the spray trigger to release the cleaning solution onto the stain.
4. **Brush:** Gently scrub the stained area with the brush on the nozzle to agitate the dirt and allow the solution to penetrate.
5. **Absorb/Vacuum:** Release the spray trigger and slowly pull the nozzle over the treated area to vacuum up the dirty solution. Repeat this step until the area is clean and as dry as possible.



Image 4.1: Visual representation of the three-step cleaning process: Spray, Brush, and Absorb.

Your browser does not support the video tag.

Video 4.1: A demonstration of the Akitas X7 Spot Cleaner's spray, brush, and absorb cleaning action on a surface.



Image 4.2: The Akitas X7 in action, effectively removing a stain from a carpet.

Using Accessories:

- **Upholstery Nozzle:** Ideal for cleaning sofas, chairs, and other fabric furniture.
- **Pet Brush:** Use this specialized brush for cleaning pet messes and removing pet hair from carpets and upholstery.



Image 4.3: Cleaning a sofa with the Akitas X7 Spot Cleaner, demonstrating its versatility for upholstery.



Image 4.4: The Akitas X7 being used to clean the interior of a car, highlighting its suitability for vehicle upholstery.



Image 4.5: Cleaning carpeted stairs with the Akitas X7, showing its adaptability for different surfaces.



Image 4.6: The specialized pet brush attachment, useful for cleaning pet-related messes.

Self-Cleaning Function:

After each use, it is recommended to use the self-cleaning function to rinse the hose and prevent odors.

1. Ensure the clean water tank has some water.
2. Place the cleaning nozzle into a sink or bucket.
3. Press the dedicated self-cleaning button (refer to your unit for exact button location). The unit will spray clean water through the hose and vacuum it back into the dirty water tank.
4. Continue until the water being vacuumed appears clean.



Image 4.7: Illustration of the self-cleaning function, which rinses the hose to prevent residue buildup and odors.

5. MAINTENANCE AND STORAGE

Proper maintenance ensures the longevity and optimal performance of your spot cleaner.

After Each Use:

1. **Empty Dirty Water Tank:** Remove the dirty water tank and carefully pour out the contents. Rinse the tank thoroughly with clean water.
2. **Rinse Clean Water Tank:** If any solution remains, empty and rinse the clean water tank.
3. **Clean Nozzle and Hose:** Perform the self-cleaning function. Additionally, detach the cleaning nozzle and rinse it under running water to remove any debris.
4. **Wipe Down Unit:** Wipe the exterior of the unit with a damp cloth.

Storage:

Ensure the unit and all tanks are completely dry before storing. Store the Akitas X7 in a cool, dry place, away from direct sunlight and extreme temperatures. Its compact design allows for easy storage in cabinets or small spaces.



Image 5.1: The compact design of the Akitas X7 allows for easy storage in small spaces and convenient portability.

6. TROUBLESHOOTING

If you encounter issues with your Akitas X7 Spot Cleaner, refer to the table below for common problems and solutions.

Problem	Possible Cause	Solution
No power	Unit unplugged; power outlet not working; damaged power cord.	Ensure unit is securely plugged in; test outlet with another device; inspect power cord for damage.
No spray or weak spray	Clean water tank empty; spray nozzle clogged; tank not seated correctly.	Refill clean water tank; clean spray nozzle; ensure tank is securely in place.

Problem	Possible Cause	Solution
Poor suction	Dirty water tank full; dirty water tank not seated correctly; hose or nozzle clogged; filter dirty.	Empty dirty water tank; ensure tank is securely in place; clear any clogs in hose/nozzle; clean filter.
Water leaking	Tanks not properly sealed; dirty water tank overfilled; damaged seals.	Ensure tanks are correctly seated and sealed; do not overfill dirty water tank; check seals for damage.
Unusual noise	Obstruction in hose/nozzle; motor issue.	Check for and remove any obstructions; if noise persists, contact customer support.

7. SPECIFICATIONS

Technical details for the Akitas X7 Spot Cleaner.

Feature	Specification
Brand	Akitas
Model Number	AKX7
Color	Black
Motor Power	600W
Suction Power	14kPa
Clean Water Tank Capacity	1.8 Liters
Dirty Water Tank Capacity	1 Liter
Product Dimensions (L x W x H)	36 x 22 x 28 cm
Item Weight	3.4 Kilograms
Hose Length	1.5 meters
Power Cord Length	5 meters
Power Source	Corded Electric