K&F CONCEPT S225A0+BH-25L

K&F CONCEPT Mini Desk Tripod S225A0+BH-25L User Manual

Model: S225A0+BH-25L

1. Introduction

Thank you for choosing the K&F CONCEPT Mini Desk Tripod S225A0+BH-25L. This compact and versatile tripod is designed for photographers and videographers seeking a portable yet stable support solution for DSLR cameras, mirrorless cameras, and smartphones. Crafted from durable aluminum, it offers flexible height and angle adjustments, a 360° ball head, and a reversible center column for various shooting scenarios.

2. What's in the Box

- Mini Camera Tripod x 1
- Quick Release Plate x 1
- Phone Holder x 1
- Instruction Manual x 1



Image: Contents of the K&F CONCEPT Mini Desk Tripod package, including the tripod, quick release plate, phone holder, and instruction manual.

3. Setup Instructions

3.1 Unfolding the Tripod Legs

1. Gently pull the tripod legs outwards from their folded position.
2. Adjust each leg to your desired angle. The tripod offers three adjustable leg angles for stability on various surfaces.



Image: The tripod illustrating its three adjustable leg angles (80°, 55°, 22°) for versatile positioning.

3.2 Adjusting Leg Height

1. To extend a leg section, turn the quick lock counter-clockwise to unlock.
2. Pull the leg section outwards to the desired length.
3. Turn the quick lock clockwise to secure the leg section in place. Repeat for all 5 sections of each leg as needed.



Image: Diagram showing the 5-section legs and the twist-lock mechanism for height adjustment, from 22.5cm to 55cm.

3.3 Attaching the Quick Release Plate

1. Locate the 1/4"-20 quick-release plate on the ball head.
2. Attach your camera or phone holder to the quick-release plate by screwing it onto the 1/4" screw. Ensure it is tightened securely.
3. Slide the quick-release plate with your device into the clamp on the ball head until it locks into place.




Image: Close-up of the ball head showing the quick release plate and its locking mechanism.

3.4 Using the Phone Holder

The universal phone holder can be attached to the quick-release plate for smartphone photography or videography. It expands to accommodate most smartphone sizes.




Image: The tripod demonstrating compatibility with DSLR cameras, mirrorless cameras, and smartphones using the included phone holder and quick release plate.

4. Operating Instructions

4.1 Ball Head Adjustments

The 360° ball head allows for precise positioning of your camera. Loosen the main locking knob to adjust the angle and tilt. Tighten the knob to secure your device in the desired position. The ball head also features a 90° vertical tilt for portrait orientation and a panoramic scale for accurate 360° rotation.



Image: Detailed view of the ball head, highlighting the 1/4" screw, quick release plate knob, 90° tilt lock knob, 360° pan lock knob, and panoramic scale for precise adjustments.

4.2 Reversible Center Column for Macro Photography

For extreme low-angle shots or macro photography, the center column can be reversed. Unscrew the knob at the base of the center column, remove it, invert it, and reinsert it into the tripod. This allows your camera to be positioned very close to the ground.




Image: The tripod configured with its reversible center column for low-angle macro photography, showing a camera positioned close to the ground.

4.3 Spirit Level

The built-in spirit level on the ball head helps ensure your camera is perfectly level for straight horizons and balanced compositions.

5. Maintenance

- **Cleaning:** Wipe the tripod with a soft, dry cloth after each use to remove dust and dirt. For stubborn grime, use a slightly damp cloth and mild soap, then dry thoroughly.
- **Lubrication:** Periodically check the leg locks and ball head mechanisms. If they feel stiff, apply a small amount of silicone-based lubricant.
- **Storage:** Store the tripod in a dry, cool place away from direct sunlight and extreme temperatures.
- **Inspection:** Regularly inspect all screws, knobs, and leg locks to ensure they are tight and functioning

correctly.

6. Troubleshooting

Problem	Possible Cause	Solution
Tripod is unstable.	Legs not fully extended or locked; uneven surface; excessive load.	Ensure all leg sections are fully extended and twist-locked. Adjust leg angles for stability on uneven ground. Verify device weight is within the 13.22 lbs (6 kg) limit.
Ball head does not hold position.	Locking knob not tightened sufficiently; excessive load.	Tighten the main locking knob firmly. Reduce the load if it exceeds the recommended capacity.
Leg sections are stiff or difficult to extend/retract.	Dirt or debris in leg locks; lack of lubrication.	Clean leg sections and locks. Apply a small amount of silicone-based lubricant to the moving parts.

7. Product Specifications

Feature	Detail
Model Name	S225A0+BH-25L
Brand	K&F CONCEPT
Material	Aluminum
Color	Black
Item Weight	645 Grams (1.42 lbs)
Weight Limit	13.22 Pounds (6 KG)
Maximum Height	55 Centimeters (21.65 inches)
Minimum Height	22.5 Centimeters (8.86 inches)
Folded Size	23.5 Centimeters (9.25 inches)
Number of Leg Sections	5
Tripod Head Type	Ball Head
Compatible Devices	Camera, Smartphone
Special Feature	Compact

8. Warranty and Support

This K&F CONCEPT Mini Desk Tripod S225A0+BH-25L comes with a**One Year Warranty** from the date of purchase. This warranty covers manufacturing defects and workmanship under normal use.

For warranty claims, technical support, or any inquiries regarding your product, please contact K&F CONCEPT customer service through their official website or the retailer where the product was purchased. Please retain your proof of purchase for warranty validation.

For more information and support, visit the officialK&F CONCEPT Store on Amazon.

© 2026 K&F CONCEPT. All rights reserved.
This manual is for informational purposes only. K&F CONCEPT reserves the right to change product specifications without prior notice.