

TAGRY H37

TAGRY AI Translation Earbuds H37 User Manual

Model: H37

INTRODUCTION

This manual provides detailed instructions for the setup, operation, maintenance, and troubleshooting of your TAGRY AI Translation Earbuds Model H37. Please read this manual thoroughly before using the product to ensure optimal performance and longevity.

PACKAGE CONTENTS

- TAGRY AI Translation Earbuds (L/R)
- Charging Case
- USB Charging Cable
- User Manual



Image: The TAGRY AI Translation Earbuds, showing both earbuds and the open charging case with an LED battery display.

SETUP

1. App Download and Installation

The TAGRY AI Translation Earbuds require the "Ear Dance" application for full functionality. Follow these steps to download and install the app:

1. **Method 1:** Search for "Ear Dance" in the Google Play Store (for Android) or Apple App Store (for iOS) and download the application.
2. **Method 2:** Scan the QR code provided in the physical user manual or on the product packaging to directly access the app download page.

Note: The "Ear Dance" software is free to use for a lifetime and does not require any fees.



Translate via Camera

Powerful photo translation in 20 languages. Seamlessly fits your work and life.



Image: A visual guide demonstrating the steps to download the "Ear Dance" app and connect the earbuds, including QR codes for app download and a screenshot of the app's connection interface.

For direct app download, visit: earjoy-dance.com/app-download-h5

2. Initial Pairing and Connection

After installing the "Ear Dance" app, follow these steps to pair your earbuds:

1. Open the "Ear Dance" app and tap the "Connect" button to access the Bluetooth settings interface within the app.
2. Ensure Bluetooth is enabled on your smartphone. Locate and select "H37" from the list of available devices to connect.
3. Return to the "Ear Dance" app.
4. Navigate to the "Mine" page within the app, then select "Bind device". Grant camera permission if prompted.
5. Scan the QR code located on the charging case or in the physical user manual to complete the binding process.

The earbuds are designed for a secure and comfortable fit. They feature a C-shaped ear clip design and a Titanium Memory Core for flexibility and stability.



Image: A close-up view of the earbud's C-shaped design, highlighting its lightweight and secure fit.



Image: An illustration demonstrating the flexibility of the earbud's Titanium Memory Core.

OPERATING INSTRUCTIONS

The TAGRY H37 earbuds offer 8 primary functions, accessible through the "Ear Dance" app and smart touch controls.

1. Translation Modes

The earbuds support real-time translation for 164 languages with high accuracy and low latency.

164 Languages at Your Command





164 Languages...



Seamlessly break down language barriers anytime, anywhere.

Image: A visual representation of the global language support, showing various country flags and people from different regions, indicating the 164 languages available for translation.

Real-time & Precise Translation

99%
Accuracy

0.3s
Delay



Hey, where are we going to party tonight?



Oye, ¿adónde vamos a salir esta noche?



¡Estamos yendo a la casa de María!



We're heading to Maria's place!

Image: An illustration highlighting the 99% accuracy and 0.3-second delay of the real-time translation feature, with people engaged in conversation.

AI Dialogue Mode

Engage with an AI assistant for language practice or instant questions and answers. This mode functions as a multilingual AI assistant.



Image: Screenshots of the AI Chatbot interface within the "Ear Dance" app, showing a conversation with the AI assistant.

Free Talk (Dual Ear) Mode

Allows two individuals, each wearing an earbud, to engage in real-time translated conversations. Both parties can speak and hear translations simultaneously.



Free Talk Mode

Both wearing earbuds, real-time translation, free communication



Image: Two individuals, one taking a selfie and the other waving, demonstrating the use of earbuds for real-time communication in Free Talk mode.

Translation Machine Mode

Utilize the earbuds as a dedicated translation device, translating spoken words into the selected target language.

Photo Translation

Translate text from images by taking a photo through the "Ear Dance" app. This is useful for menus, signs, and documents.




Image: A smartphone screen demonstrating the photo translation feature, showing a menu being translated from English to Spanish.

2. Communication Functions

Audio/Video Call Translation

The earbuds enable real-time translation during audio and video calls, facilitating communication across language barriers.

Audio & Video HD Call Translation

Speak freely across languages, video and voice calls made easy




Image: A woman smiling while using the earbuds during a video call, with a phone screen displaying a translated conversation.

Headphones + Phone Mode

Use the earbuds for standard phone calls and audio playback, seamlessly integrating with your smartphone's functions.

3. Other Functions

Voice Notes

Record voice notes directly through the earbuds, managed via the "Ear Dance" app.

Sleep-Aid Soundtracks

Access a selection of 40 built-in sleep-aiding music tracks designed to promote relaxation.

How to Connect the AI Earbuds with the "Ear Dance"

APP Download

Method 1: Please search "Ear Dance" in Google Play or Apple Store to Download the APP.




Method 2: Scan the QR Code below to download and install the Ear Dance APP. The QR code is in the user manual.



Tips: This software is free to use for a lifetime and does not charge any fees


1: Download the "Ear Dance" app.



2: Click "Connect" to Bluetooth settings interface in the APP.



3: Turn on "Bluetooth", connect "H37", return to "Ear Dance" APP.



4: Go to "Mine" page, click "Bind device" then click "📷" (allow camera permission), Scan the QR Code below to bind device.

Image: A display of various album covers representing the 40 built-in sleep-aiding music tracks available.

4. Smart Touch Controls

The earbuds feature intuitive touch controls for managing various functions:

- **Single Tap:** Play/Pause music, Answer/End call.
- **Double Tap (Left Earbud):** Previous track.
- **Double Tap (Right Earbud):** Next track.
- **Triple Tap (Left Earbud):** Volume down.
- **Triple Tap (Right Earbud):** Volume up.
- **Long Press:** Activate voice assistant, Reject call.

Titanium Memory Core

Unbreakable flex, universal fit and stability.



Image: A visual guide illustrating the various smart touch gestures and their corresponding functions on the earbuds.

MAINTENANCE AND CARE

- **Cleaning:** Regularly clean the earbuds and charging case with a soft, dry cloth. Avoid using liquids or abrasive cleaners.

- **Storage:** Store the earbuds in their charging case when not in use to protect them and ensure they remain charged.
- **Battery Care:** To prolong battery life, avoid fully discharging the earbuds frequently. Charge them regularly. The charging case provides up to 56 hours of playtime with multiple charges, while a single charge offers 7 hours of use. The LED display on the case indicates battery levels.

Long Battery, All-day Support



7Hrs
On Single Charge



56Hrs
With Charging Case

56H



Image: The earbuds and charging case, illustrating the battery life: 7 hours on a single charge and 56 hours with the charging case.

TROUBLESHOOTING

If you encounter issues with your TAGRY AI Translation Earbuds, refer to the following common solutions:

Problem	Possible Cause	Solution
Earbuds not pairing/connecting	Bluetooth off, earbuds not in pairing mode, app issue.	Ensure Bluetooth is enabled on your device. Place earbuds back in the case, close, then reopen to reset pairing mode. Restart the "Ear Dance" app and your smartphone. Forget "H37" in your phone's Bluetooth settings and re-pair.
Translation not working or inaccurate	Poor internet connection, incorrect language settings, app malfunction.	Verify a stable internet connection (Wi-Fi or mobile data). Check language settings in the "Ear Dance" app to ensure correct source and target languages. Ensure clear speech and minimal background noise. Update the "Ear Dance" app to the latest version.
No sound from earbuds	Low battery, disconnected, volume too low.	Charge the earbuds fully. Ensure earbuds are properly connected to your device via Bluetooth. Increase volume on both your device and using the earbud touch controls.
App crashing or unresponsive	Software bug, insufficient device resources.	Close and reopen the "Ear Dance" app. Clear the app's cache (Android) or reinstall the app. Ensure your smartphone's operating system is up to date.

SPECIFICATIONS

Feature	Detail
Model Number	H37
Product Dimensions	2.56 x 1.18 x 2.13 inches (Charging Case)
Item Weight	1.59 ounces
Battery Type	Lithium Ion (3 required, included)
Single Charge Playtime	Up to 7 hours
Total Playtime (with Charging Case)	Up to 56 hours
Translation Languages	164 languages
Translation Accuracy	99%
Translation Response Time	0.3 seconds
Connectivity	Bluetooth 5.4

Feature	Detail
Manufacturer	TAGRY

Mini & Portable



Image: A diagram illustrating the dimensions of the TAGRY H37 earbuds and their charging case.

WARRANTY INFORMATION

Specific warranty details are typically provided with the product packaging or available on the manufacturer's official

website. Please refer to the documentation included with your purchase for comprehensive warranty terms and conditions.

CUSTOMER SUPPORT

For further assistance, technical support, or inquiries regarding your TAGRY AI Translation Earbuds H37, please contact TAGRY customer service through their official website or the contact information provided in your product packaging. You may also visit the [TAGRY Store on Amazon](#) for additional product information and support resources.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0FJFR7XQK>

More documents and user manuals: <https://manuals.plus/>