

[Manuals.plus](#) /

› [OWIPAW](#) /

› OWIPAW Farmhouse Coffee Table GMT003 User Manual

OWIPAW GMT003

OWIPAW Farmhouse Coffee Table User Manual

Model: GMT003 | Brand: OWIPAW

1. INTRODUCTION

Thank you for choosing the OWIPAW Farmhouse Coffee Table. This modern rustic wooden center table, Model GMT003, is designed to enhance your living space with its functional two-tier storage and durable construction. This manual provides essential information for assembly, operation, maintenance, and specifications to ensure optimal use and longevity of your product.



Image 1.1: The OWIPAW Farmhouse Coffee Table in a living room, featuring a laptop and book on its surface.

2. SAFETY INFORMATION

- Always follow the assembly instructions provided in this manual.
- Do not exceed the weight-bearing capacity of **250 pounds** to maintain stability and prevent damage.
- Keep small parts away from children during assembly to avoid choking hazards.
- Place the coffee table on a flat, stable surface.
- Avoid placing extremely hot items directly on the table surface without protection.

3. PACKAGE CONTENTS

Before beginning assembly, please ensure all components listed below are present and undamaged. If any parts are missing or damaged, please contact customer support.

- Assembly Guide
- Installation Tool (Allen Key, Screw Driver)
- All necessary table components (labeled)



Image 3.1: A diagram illustrating the overall dimensions of the coffee table.

4. ASSEMBLY INSTRUCTIONS

Assembly of the OWIPAW Farmhouse Coffee Table is designed to be straightforward. Each component is labeled, and the package includes all necessary tools. Please follow the step-by-step instructions provided in the included Assembly Guide for a smooth process. Typically, assembly can be completed in approximately 30 minutes.

1. Unpack all components and verify against the parts list.
2. Attach the legs to the tabletop using the provided screws and tools. Ensure all connections are secure.
3. Install the lower shelf, aligning it with the pre-drilled holes in the legs.
4. Tighten all screws firmly, but do not overtighten.
5. Attach the protective feet pads to the bottom of the legs to prevent floor scratches.



Image 4.1: Close-up details showing the protective feet pads and metal bracket accents, which contribute to the table's sturdy construction.

5. OPERATING INSTRUCTIONS

The OWIPAW Farmhouse Coffee Table is designed for versatile use in your living space.

5.1 Two-Tier Storage

Utilize the two-tier open storage for easy access and organization. The spacious lower shelf is ideal for storing items such as books, magazines, remote controls, or decorative baskets. The tabletop provides ample space for drinks, snacks, and other essentials.



Image 5.1: The coffee table demonstrating its two-tier storage capability with various items.

5.2 Surface Use

The table's surface is scratch-resistant and waterproof, making it suitable for daily use. It can accommodate various items, from decorative pieces to beverages and snacks. The distressed wood look helps to conceal minor imperfections that may occur over time.

Classic Wood Grain



Scratch-Resistant



Waterproof



Image 5.2: A chess board on the table surface, illustrating its scratch-resistant and waterproof properties.

6. MAINTENANCE AND CARE

To maintain the appearance and longevity of your coffee table, follow these simple care instructions:

- **Cleaning:** Simply wipe the surface with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners, as these may damage the finish.
- **Spills:** Although the surface is waterproof, promptly wipe up any spills to prevent potential staining or damage.
- **Protection:** Use coasters under drinks and placemats under hot dishes to further protect the surface.
- **Movement:** When moving the table, lift it rather than dragging it to prevent damage to the legs and floor.



Image 6.1: Visual representation of the table's easy-to-clean surface and floor-friendly pads.

7. TROUBLESHOOTING

If you encounter any issues with your OWIPAW Farmhouse Coffee Table, please refer to the following common solutions:

- **Wobbling Table:** Ensure all screws are securely tightened. Check that the table is placed on an even surface. Adjust protective feet if necessary.
- **Missing Parts:** Double-check the packaging. If parts are genuinely missing, contact customer support with your purchase details.
- **Surface Damage:** For minor scratches, wood repair kits can be used. For significant damage, contact customer support for advice.

8. PRODUCT SPECIFICATIONS

Feature	Specification
Brand	OWIPAW
Model Number	GMT003
Product Dimensions (D x W x H)	23.62"D x 47.24"W x 16.34"H
Color	Rustic Oak
Material Type	Engineered Wood
Item Weight	49 Pounds
Weight Capacity	250 Pounds
Table Design	Coffee Table
Included Components	Assembly Guide, Installation Tool

9. WARRANTY AND SUPPORT

OWIPAW is committed to providing quality products and customer satisfaction. This product comes with a **365-day warranty** against manufacturing defects. If you have any questions, concerns, or require assistance with your OWIPAW Farmhouse Coffee Table, please do not hesitate to contact our customer support team. We offer 24-hour after-sale service to provide satisfactory solutions.

Please refer to your purchase documentation for specific contact information or visit the official OWIPAW website.



Image 9.1: Information regarding 24-hour after-sale service and a 365-day warranty.

© 2025 OWIPAW. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question