realme 15 Pro 5G

realme 15 Pro 5G Smartphone User Manual

Model: 15 Pro 5G

Introduction

This user manual provides essential information and instructions for the realme 15 Pro 5G smartphone. Please read this manual thoroughly to understand the proper use, setup, and maintenance of your device. Keep this manual for future reference.

Device Overview

Familiarize yourself with the physical components and layout of your realme 15 Pro 5G smartphone.



Figure 1: Front view of the realme 15 Pro 5G, showcasing the display and key feature highlights.



Figure 2: Angled view of the realme 15 Pro 5G, displaying both the front screen and the rear camera module.



Figure 3: Rear view of the realme 15 Pro 5G, highlighting the triple AI camera system and the realme logo.



Figure 4: Side view of the realme 15 Pro 5G, illustrating the placement of the power button and volume controls.



Figure 5: Top and bottom views of the realme 15 Pro 5G, detailing the SIM card slot, USB-C charging port, and speaker grille.

Setup

1. Inserting SIM Cards

1. Locate the SIM card tray on the side of your device (refer to Figure 5).
2. Insert the SIM ejector tool into the small hole next to the tray and push gently until the tray pops out.
3. Place your Nano-SIM cards into the designated slots on the tray. Ensure the gold contacts face downwards. This device supports Dual SIM functionality.
4. Carefully reinsert the SIM tray into the phone until it clicks into place.

2. Initial Power On and Setup

1. Press and hold the Power button (located on the side, refer to Figure 4) until the realme logo appears.
2. Follow the on-screen instructions to complete the initial setup process. This includes selecting your language,

connecting to a Wi-Fi network, setting up your Google account, and configuring security features like fingerprint and face recognition.

Operating Your Device

Android 15 Operating System

Your realme 15 Pro 5G runs on Android 15, offering a user-friendly interface and access to a wide range of applications via the Google Play Store. Navigate using gestures or on-screen buttons, customize your home screen, and manage notifications through the settings menu.

Display Features

- **6.8" FHD+ AMOLED Display:** Enjoy vibrant colors and deep blacks on the large, high-resolution screen.
- **120Hz Refresh Rate:** Experience smooth scrolling and fluid animations. Adjust the refresh rate in display settings for battery optimization.

Biometric Security

- **Fingerprint Recognition:** Register your fingerprints in the Security settings for quick and secure unlocking.
- **Face Recognition:** Set up face unlock for convenient access to your device.

Camera Features

The realme 15 Pro 5G is equipped with a versatile camera system designed to capture high-quality photos and videos.

- **Triple 50MP AI Rear Camera:** Features a Sony IMX896 main sensor, a 50 MP ultra-wide lens, and an additional 50 MP sensor for detailed and versatile photography.
- **50MP Selfie Camera:** Capture high-resolution self-portraits.
- **Camera Modes:** Explore various modes such as Portrait, Night, Pro, Panorama, and AI enhancements for optimal results in different scenarios.
- **Video Recording:** Record videos at various resolutions and frame rates, including 4K 60FPS.

Battery and Charging

- **7000mAh Battery:** The device is powered by a large capacity battery for extended usage.
- **80W Fast Charging:** Utilize the included 80W charger for rapid battery replenishment. Ensure you use realme-approved charging accessories for safety and optimal performance.
- **Battery Optimization:** Manage battery usage through settings to extend battery life.

Maintenance

Cleaning Your Device

- Use a soft, lint-free cloth to clean the screen and body of the phone.
- Avoid using harsh chemicals, abrasive cleaners, or aerosol sprays.
- Keep ports free of dust and debris.

Software Updates

Regularly check for and install software updates to ensure your device has the latest features, security patches, and performance improvements. You can find update options in the Settings menu under "About phone" or "Software update."

Storage Management

Your device comes with 256GB of internal storage. To optimize performance, regularly review and delete unnecessary files, apps, and media. Cloud storage options are also available for backing up your data.

Troubleshooting

- **Device not turning on:** Ensure the battery is charged. Connect the charger and wait a few minutes before attempting to power on again.
- **Apps crashing or freezing:** Close and reopen the app. If the issue persists, clear the app's cache and data in Settings, or uninstall and reinstall the app.
- **Poor network connectivity:** Check your SIM card insertion. Try restarting the device. Ensure mobile data or Wi-Fi is enabled and you are within network coverage.
- **Slow performance:** Close background applications. Clear cache. Consider a factory reset as a last resort (back up your data first).
- **Fingerprint/Face unlock issues:** Ensure your fingers/face are clean and dry. Re-register your biometrics in settings if problems persist.

For more complex issues, please refer to the official realme support website or contact customer service.

Specifications

Feature	Detail
Brand	realme
Model	15 Pro 5G
Operating System	Android 15
RAM Memory Installed Size	8 GB
Memory Storage Capacity	256 GB
CPU Model	Snapdragon (Snapdragon 7 Gen 4)
CPU Speed	2.8 GHz
Screen Size	6.8 Inches
Display Type	AMOLED
Refresh Rate	120 Hz
Resolution	1920 x 1080 (FHD+)
Rear Camera Resolution	50 MP (Triple AI Camera)
Front Camera Resolution	50 MP

Feature	Detail
Battery Capacity	7000 Milliamp Hours
Charging	80W Fast Charging
SIM Card Slot Count	Dual SIM
Biometric Security	Fingerprint Recognition, Face Recognition
Cellular Technology	5G
Item Dimensions (L x W x H)	16.2 x 7.6 x 0.8 Centimeters
Headphones Jack	No headphone jack
Water Resistance Level	Not Water Resistant

Warranty and Support

Your realme 15 Pro 5G smartphone comes with a limited manufacturer's warranty. Please refer to the warranty card included in your product packaging for detailed terms and conditions, including warranty period and coverage.

For technical support, service, or further inquiries, please visit the official realme support website or contact their customer service department. Contact information can typically be found on the realme official website or in your product documentation.

© 2026 realme. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question