

Ice Maker Replacement

Generic Ice Maker Replacement Manual for Kenmore Refrigerators

Installation, Operation, and Maintenance Instructions

1. INTRODUCTION

This manual provides detailed instructions for the safe and effective installation, operation, and maintenance of your new Generic Ice Maker Replacement. Please read this manual thoroughly before beginning installation to ensure proper function and to prevent potential damage or injury.

1.1 Product Compatibility

This ice maker is designed as a replacement part for various Kenmore refrigerator models. Please verify your refrigerator's model number against the following list to confirm compatibility:

- Kenmore 795.71012.010, 795.71012.011, 795.71012.012
- Kenmore 795.71013.010, 795.71013.011, 795.71013.012
- Kenmore 795.71014.010, 795.71014.011, 795.71014.012
- Kenmore 795.71016.010, 795.71016.011, 795.71016.012
- Kenmore 795.71019.010, 795.71019.011, 795.71019.012
- Kenmore 795.71042.010, 795.71042.011, 795.71042.012, 795.71042.013
- Kenmore 795.71043.010, 795.71043.011, 795.71043.012, 795.71043.013
- Kenmore 795.71049.010, 795.71049.011, 795.71049.012, 795.71049.013
- Kenmore 795.71302.010, 795.71302.011, 795.71302.012
- Kenmore 795.71303.010, 795.71303.011, 795.71303.012
- Kenmore 795.71304.010, 795.71304.011, 795.71304011, 795.71304012
- Kenmore 795.71306.010, 795.71306.011, 795.71306.012, 795.71306011
- Kenmore 795.71309.010, 795.71309.011, 795.71309011, 795.71309012
- Kenmore 795.71312310, 795.71312311, 795.71312312, 795.71312313, 795.71312314
- Kenmore 795.71313310, 795.71313311, 795.71313312, 795.71313313, 795.71313314
- Kenmore 795.71314212, 795.71314310, 795.71314311, 795.71314312, 795.71314313, 795.71314314
- Kenmore 795.71319310, 795.71319311, 795.71319312, 795.71319313, 795.71319314
- Kenmore 795.71322410, 795.71322411, 795.71322412, 795.71322413
- Kenmore 795.71323410, 795.71323411, 795.71323412, 795.71323413

- Kenmore 795.71329410, 795.71329411, 795.71329412, 795.71329413
- Kenmore 795.71602.010, 795.71602.011, 795.71602.012
- Kenmore 795.71603.010, 795.71603.011, 795.71603.012
- Kenmore 795.71604.010, 795.71604.011, 795.71604.012
- Kenmore 795.71606.010, 795.71606.011, 795.71606.012
- Kenmore 795.71609.010, 795.71609.011, 795.71609.012
- Kenmore 795.72122210, 795.72123210, 795.72129210
- Kenmore 795.72302210, 795.72303210, 795.72309210
- Kenmore 795.73033410
- Kenmore 795.76202.900, 795.76202.901
- Kenmore 795.76203.900, 795.76203.901
- Kenmore 795.76204.900, 795.76204.901
- Kenmore 795.76209.900, 795.76209.901
- Kenmore 795.78022310, 795.78022312
- Kenmore 795.78023310, 795.78023311, 795.78023312
- Kenmore 795.78024310, 795.78024311, 795.78024312
- Kenmore 795.78029310, 795.78029311, 795.78029312
- Kenmore 795.78042310, 795.78042312
- Kenmore 795.78043310
- Kenmore 795.78044310
- Kenmore 795.78049310
- Kenmore 795.78272.900, 795.78274.900, 795.78279.900, 795.78279901
- Kenmore 795.78542.807, 795.78543.806, 795.78543.807, 795.78544.807, 795.78546.806, 795.78546.807, 795.78549.807
- Kenmore 795.79022310, 795.79022311, 795.79022312, 795.79022313
- Kenmore 795.79023310, 795.79023311, 795.79023312

1.2 Package Contents

Upon unpacking, ensure all items are present and undamaged:

- 1 x Ice Maker Replacement Unit

2. SAFETY INFORMATION

Always prioritize safety when performing appliance repairs. Failure to follow these safety guidelines may result in electric shock, injury, or property damage.

- **Disconnect Power:** Always unplug the refrigerator from the power outlet before attempting any installation, repair, or maintenance.
- **Wear Protective Gear:** Use work gloves to protect hands from sharp edges and safety glasses to protect eyes.
- **Handle with Care:** The ice maker may have sharp edges or delicate components. Handle carefully.
- **Professional Assistance:** If you are unsure about any step or uncomfortable performing the installation, consult a qualified appliance technician.
- **Keep Area Clear:** Ensure the work area is clean, dry, and well-lit.

3. SETUP AND INSTALLATION

3.1 Tools Required

- Screwdriver (Phillips head and/or flathead, depending on your refrigerator model)
- Nut driver or wrench (if applicable)
- Work gloves

3.2 Preparation

1. **Disconnect Power:** Unplug the refrigerator from the electrical outlet.
2. **Access Ice Maker:** Open the freezer door and locate the existing ice maker assembly.
3. **Remove Ice Bucket:** Remove the ice storage bucket to gain clear access to the ice maker.

3.3 Installation Steps

Follow these steps to replace the ice maker. Specific steps may vary slightly depending on your refrigerator model.

1. **Disconnect Wiring:** Carefully disconnect the electrical wire harness from the old ice maker. There may be a tab or clip that needs to be pressed to release the connector.
2. **Remove Mounting Screws:** Locate and remove the screws that secure the old ice maker to the freezer wall or ceiling. Support the ice maker as you remove the last screw to prevent it from falling.
3. **Remove Old Ice Maker:** Carefully pull the old ice maker out of the freezer compartment.
4. **Install New Ice Maker:** Position the new ice maker in the freezer compartment, aligning it with the mounting holes.
5. **Secure New Ice Maker:** Insert and tighten the mounting screws to secure the new ice maker in place. Do not overtighten.
6. **Connect Wiring:** Reconnect the electrical wire harness to the new ice maker. Ensure the connection is firm and secure.



Figure 1: Top-down view of the ice maker replacement unit, illustrating the ice mold and wiring harness connection point.



Figure 2: Side view of the ice maker replacement unit, showing the integrated ON/OFF switch for manual control.

4. OPERATING INSTRUCTIONS

After installation, follow these steps to initiate ice production:

1. **Restore Power:** Plug the refrigerator back into the electrical outlet.
2. **Activate Ice Maker:** Locate the ON/OFF switch on the ice maker (refer to Figure 2). Ensure it is in the "ON" position.
3. **Initial Cycle:** The ice maker will typically perform an initial fill and harvest cycle within a few hours. Discard the first few batches of ice to flush any manufacturing residues from the water lines.
4. **Monitor Production:** Allow 24 hours for the freezer to reach optimal temperature and for the ice maker to begin consistent ice production.

5. MAINTENANCE

Regular maintenance helps ensure optimal performance and longevity of your ice maker.

- **Clean Ice Bucket:** Periodically empty and wash the ice storage bucket with mild soap and warm water. Rinse thoroughly and dry before returning it to the freezer.

- **Inspect Water Line:** Occasionally check the water supply line for any kinks, leaks, or blockages.
- **Clean Ice Maker:** If mineral deposits or debris accumulate on the ice maker components, disconnect power and gently wipe the surfaces with a damp cloth. Avoid using abrasive cleaners.

6. TROUBLESHOOTING

If your ice maker is not functioning as expected, refer to the following common issues and solutions:

Problem	Possible Cause	Solution
No ice production	Ice maker switch is OFF	Ensure the ON/OFF switch is in the "ON" position.
No ice production	Refrigerator not plugged in or power outage	Check power connection and household circuit breaker.
No ice production	Water supply issue (e.g., valve closed, line kinked, filter clogged)	Verify water supply to the refrigerator is open and clear. Check water filter.
Small or hollow ice cubes	Low water pressure or partially clogged water line	Check water supply pressure and inspect water lines for obstructions.
Ice maker making unusual noises	Normal operation sounds or minor obstruction	Some operational noises are normal. Check for any ice buildup or foreign objects interfering with the mechanism.

If troubleshooting steps do not resolve the issue, contact customer support for further assistance.

7. SPECIFICATIONS

The following are general specifications for the Generic Ice Maker Replacement unit:

Feature	Detail
Brand	Generic
Model Name	Ice Maker
Product Dimensions (D x W x H)	1"D x 1"W x 1"H
Capacity	1 Liters (of ice production per cycle, approximate)
Voltage	1V (This value appears to be a placeholder or incorrect in the source data. Refer to your refrigerator's specifications for actual voltage requirements.)

Feature	Detail
Included Components	Ice Maker Unit

8. WARRANTY AND SUPPORT

Specific warranty information for this Generic Ice Maker Replacement is not provided in this manual. For details regarding warranty coverage, returns, or technical support, please refer to the product listing where you purchased the item or contact the seller directly.

When contacting support, please have your purchase details and refrigerator model number readily available.