



[Manuals.plus](#) /

> [HOUROM](#) /

> HOUROM 9-Drawer Double Dresser Instruction Manual

HOUROM 9-Drawer Double Dresser

HOUROM 9-Drawer Double Dresser Instruction Manual

Model: 9-Drawer Double Dresser

INTRODUCTION

Thank you for choosing the HOUROM 9-Drawer Double Dresser. This manual provides essential information for the safe assembly, proper use, and maintenance of your new furniture. Please read these instructions carefully before beginning assembly and retain them for future reference.

SAFETY INFORMATION

WARNING: Furniture tip-over can cause serious or fatal crushing injuries. To prevent tip-over, this furniture must be permanently attached to the wall using the anti-tipping devices provided. Always ensure the dresser is placed on a level surface.

- Always use the anti-tipping devices included with your dresser.
- Do not allow children to climb on drawers or shelves.
- Place heaviest items in the lowest drawers.
- Never open more than one drawer at a time.
- Keep small parts away from children during assembly.

PACKAGE CONTENTS

Before assembly, verify that all parts and hardware are present. Refer to the detailed parts list and hardware diagram included in your product packaging. If any components are missing or damaged, please contact customer support immediately.

SETUP AND ASSEMBLY

Assembly typically requires two adults and can be completed in approximately 60 minutes. Follow the step-by-step instructions provided in the separate assembly guide included in your package. Ensure all accessories are labeled correctly for easy identification.

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, soft surface to prevent scratches.
2. **Identify Parts:** Match each component with the corresponding labels in the assembly guide.
3. **Assemble Frame:** Follow the guide to construct the main frame of the dresser.
4. **Install Drawer Glides:** Attach the drawer glides to the dresser frame and to the drawer sides as instructed.
5. **Assemble Drawers:** Construct each of the 9 drawers, ensuring they are square and sturdy.
6. **Insert Drawers:** Carefully slide the assembled drawers into the glides on the dresser frame.
7. **Attach Knobs:** Secure the black metal knobs to each drawer front.
8. **Install Anti-Tipping Device:** Securely attach the anti-tipping device to the back of the dresser and to a wall stud using the provided hardware. This step is critical for safety.

OPERATING INSTRUCTIONS

The HOUROM 9-Drawer Double Dresser is designed for versatile storage in various home environments, including bedrooms, hallways, and entryways. Its spacious drawers and wide tabletop offer practical functionality.



Image: The dresser features large capacity storage drawers, suitable for organizing a wide range of personal items and clothing.

- **Drawer Usage:** Each of the 9 drawers is equipped with smooth metal glides for easy opening and closing.

Distribute weight evenly within drawers.

- **Tabletop Functionality:** The wide tabletop (59.1" W x 15.7" D) provides ample space for decorative items, lamps, books, or even a television up to 60 inches. The tabletop has a weight capacity of 150 lbs.
- **Storage Capacity:** The dresser is ideal for organizing clothing, documents, jewelry, and other personal items. Each drawer can hold up to 40 lbs.



Image: The dresser's wide top surface can accommodate various television sizes, functioning as a TV stand.

MAINTENANCE

Proper care will ensure the longevity and appearance of your HOUROM dresser.



**Waterproof
Tabletop**

**Metal
Drawer Knobs**



**Smooth
Metal Glide**

Image: Details highlighting the waterproof tabletop, durable metal knobs, and smooth drawer glides.

- **Cleaning:** The dresser is coated with a water-based varnish, making it waterproof and easy to clean. Wipe surfaces with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals.
- **Spills:** Promptly wipe up any spills to prevent staining or damage to the finish.
- **Hardware:** Periodically check and tighten all screws and fasteners to ensure stability.
- **Drawer Glides:** If drawers become stiff, a small amount of silicone lubricant can be applied to the glides.

TROUBLESHOOTING

If you encounter any issues with your dresser, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Drawers do not slide smoothly.	Misaligned glides, loose screws, debris in glides.	Check glide alignment, tighten screws, clean glides. Apply silicone lubricant if needed.
Dresser feels wobbly.	Loose fasteners, uneven floor, anti-tipping device not installed.	Ensure all assembly screws are tight. Place on a level surface or use shims. Install the anti-tipping device securely.

Problem	Possible Cause	Solution
Knobs are loose.	Normal wear.	Tighten the screws from the inside of the drawer front.

SPECIFICATIONS



Image: Detailed product dimensions and weight capacities for the dresser and its drawers.

Feature	Detail
Brand	HOUROM
Model	9-Drawer Double Dresser
Color	Black
Material	Engineered Wood
Finish Type	Painted (Water-based varnish)
Overall Dimensions (D x W x H)	15.75" x 59" x 31.5"

Feature	Detail
Number of Drawers	9
Drawer Weight Capacity	40 lbs per drawer
Tabletop Weight Capacity	150 lbs
Mounting Type	Floor Mount (with anti-tipping device)
Assembly Required	Yes

WARRANTY INFORMATION

For detailed warranty information, please refer to the documentation included with your purchase or contact HOUROM customer support directly. Warranty terms and conditions may vary.

CUSTOMER SUPPORT

If you have any questions regarding the assembly, operation, or maintenance of your HOUROM 9-Drawer Double Dresser, please do not hesitate to contact our customer support team. We are committed to providing assistance and will respond to your inquiries within 24 hours.

Contact Information: Refer to your purchase documentation or the HOUROM brand store on Amazon for the most current contact details.