

Manuals.plus /

› Coleshome /

› Coleshome Narrow Chest of Drawers with 4 Fabric Drawers - Assembly and Care Manual

Coleshome 4-Drawer Narrow Chest (B0FJQLRRNK)

Coleshome Narrow Chest of Drawers with 4 Fabric Drawers

Model: 4-Drawer Narrow Chest (B0FJQLRRNK) | **Brand:** Coleshome

INTRODUCTION

This instruction manual provides comprehensive guidance for the assembly, safe operation, maintenance, and troubleshooting of your Coleshome Narrow Chest of Drawers. Please read this manual thoroughly before assembly and use to ensure proper function and longevity of your product. Keep this manual for future reference.

SAFETY INFORMATION

- **Anti-Tip Hazard:** To prevent tipping, this chest of drawers should be securely anchored to a wall using the provided anti-tip kit (if included). Serious or fatal crushing injuries can occur from furniture tip-over.
- **Weight Limits:** Do not exceed the recommended weight capacity for the top surface or individual drawers. Overloading can compromise stability and structural integrity.
- **Assembly:** Assemble the unit on a soft, clean surface to prevent scratches. Ensure all parts are correctly installed and fasteners are tightened before use.
- **Children Safety:** Keep small parts and packaging materials away from children during assembly. Do not allow children to climb on or play with the chest of drawers.
- **Placement:** Place the chest on a level surface. Use the adjustable feet to stabilize the unit on uneven floors.

PACKAGE CONTENTS

Before beginning assembly, verify that all components are present and undamaged. If any parts are missing or damaged, please contact customer support.

- Steel Frame Components
- Wooden Top Panel
- 4 Fabric Drawers
- Adjustable Feet
- Assembly Hardware (screws, bolts, Allen wrench, etc.)
- Anti-Tip Kit

SETUP AND ASSEMBLY INSTRUCTIONS

Follow these steps carefully to assemble your Coleshome Narrow Chest of Drawers.

1. **Unpack Components:** Carefully remove all parts from the packaging. Lay them out on a clean, soft surface to prevent scratches.
2. **Assemble the Steel Frame:** Connect the vertical and horizontal steel frame components according to the diagram in your separate assembly guide. Ensure all connections are secure.
3. **Attach X-Shaped Crossbar:** Install the X-shaped crossbar at the back of the frame for enhanced stability, as indicated in the assembly instructions.
4. **Install Adjustable Feet:** Screw the adjustable feet into the bottom of the steel frame. Do not fully tighten yet, as adjustments may be needed later.
5. **Secure the Wooden Top Panel:** Place the wooden top panel onto the assembled steel frame and secure it using the provided screws.
6. **Assemble Fabric Drawers:** Fold and assemble the fabric drawers. Insert the bottom panel into each drawer to give it shape and stability.
7. **Insert Drawers:** Slide the assembled fabric drawers into their respective slots in the frame.
8. **Adjust Leveling Feet:** Once the chest is in its desired location, adjust the leveling feet to ensure the unit is stable and does not wobble on uneven floors.
9. **Install Anti-Tip Kit:** For safety, attach the anti-tip kit to the back of the chest and secure it to a wall stud following the kit's instructions.





Figure 1: Fully assembled Coleshome Narrow Chest of Drawers, showcasing its retro design and four fabric drawers.

OPERATING INSTRUCTIONS

- **Drawer Usage:** Gently pull and push the fabric drawers to open and close them. Avoid forcing the drawers, especially when heavily loaded.
- **Storage Capacity:** The four fabric drawers provide ample storage for various items such as clothing, accessories, books, or small household goods.
- **Top Surface:** The wooden top panel can be used to display decorative items, lamps, or other lightweight objects. Ensure items placed on top do not exceed the weight limit to maintain stability.
- **Weight Distribution:** Distribute weight evenly within the drawers and on the top surface to prevent imbalance.



Figure 2: View of the open fabric drawers, illustrating their capacity for storing various items like socks, t-shirts, pants, and toys.

MAINTENANCE AND CARE

- **Cleaning the Frame and Top:** Wipe the steel frame and wooden top panel with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners that could damage the finish.
- **Cleaning Fabric Drawers:** The fabric drawers can be spot cleaned with a mild detergent and a damp cloth. Allow them to air dry completely. Do not machine wash or tumble dry.
- **Regular Checks:** Periodically check all screws and fasteners to ensure they remain tight. Re-tighten if necessary to maintain stability.
- **Avoid Moisture:** Do not expose the chest of drawers to excessive moisture or direct sunlight, which can cause damage or discoloration.



Figure 3: Detailed view of the durable wooden top panel and the texture of a fabric drawer, highlighting the quality materials.

TROUBLESHOOTING

- **Wobbly Unit:** If the chest of drawers feels unstable, check that all assembly screws are tightened. Adjust the leveling feet at the bottom of the frame to compensate for uneven flooring.
- **Drawers Not Sliding Smoothly:** Ensure the fabric drawers are correctly assembled and inserted into their slots. Check for any obstructions or items caught in the drawer runners.
- **Missing Parts:** If you find any parts missing during assembly, refer to the "Package Contents" section and contact Coleshome customer support for assistance.

SPECIFICATIONS

Attribute	Detail
Brand	Coleshome
Model	4-Drawer Narrow Chest
Dimensions (Width x Depth x Height)	40 cm x 30 cm x 80.2 cm (approx. 15.75 in x 11.81 in x 31.57 in)
Weight	5.85 Kilograms (12.9 lbs)
Number of Drawers	4
Material	Steel Frame, Wooden Top, Fabric Drawers
Color	Retro
Assembly Required	Yes

Produktabmessungen



Figure 4: Detailed product dimensions, including overall height, width, depth, and individual drawer measurements.

WARRANTY AND SUPPORT

Coleshome offers a **30-day return and exchange guarantee** for this product. Our professional customer service team is available 24/7 to provide efficient solutions and support for any inquiries or issues you may encounter.

For assistance, please contact Coleshome customer support through your purchase platform or the official Coleshome website.

